



Model **SP08**



Model #: _____

Serial #: _____

Date of
Purchase: _____



Instruction Manual for the Globe Mixer Model **SP08**

For all after sales support, visit www.globefoodequip.com

- Complete the Warranty Registration
- Find an Authorized Servicer
- View Parts Catalogs

For additional Technical Support call Globe at 1-866-260-0522.

- IMPORTANT SAFETY NOTICE -

This manual contains important safety instructions which must be strictly followed when using this equipment.

Maintain and use this manual as a reference for training.

Index

ATTENTION OWNERS AND OPERATORS.....	4
KEY COMPONENTS OF THE MIXER.....	5
INSTALLATION	6
OPERATING INSTRUCTIONS.....	7-9
CLEANING INSTRUCTIONS	10
IMPORTANT POINTS	11
CAPACITY CHART.....	12
TROUBLESHOOTING	14-15



GLOBE FOOD EQUIPMENT COMPANY
2153 DRYDEN RD.
DAYTON, OH 45439
PHONE: 937-299-5493
TOLL FREE: 800-347-5423
E-MAIL: info@globefoodequip.com
WEBSITE: www.globefoodequip.com

Attention Owners and Operators

Globe's equipment is designed to provide safe and productive processing of food products as long as the equipment is used in accordance with the instructions in this manual and is properly maintained. Unless the operator is adequately trained and supervised there is a possibility of serious injury. Owners of this equipment bear the responsibility to make certain that this equipment is used properly and safely, strictly following all the instructions contained in this manual and the requirements of local, state or federal law.

Owners should not permit anyone to touch this equipment unless they are over 18 years old, are adequately trained and supervised, and have read and understood this manual. Owners should also ensure that no customers, visitors or other unauthorized personnel come in contact with this equipment. Please remember that Globe cannot anticipate every circumstance or environment in which its equipment will be operated. It is the responsibility of the owner and the operator to remain alert to any hazards posed by the function of this equipment. If you are ever uncertain about a particular task or the proper method of operating this equipment, ask your supervisor.

This manual contains a number of precautions to follow to help promote safe use of this equipment. Throughout the manual you will see additional warnings to help alert you to potential hazards.

Warnings affecting your personal safety are indicated by:



or




Warnings related to possible damage to the equipment are indicated by:




If any warning labels or this manual are misplaced, damaged, or illegible, or if you require additional copies, please contact your nearest representative or Globe directly for these items at no charge.

Please remember that this manual or the warning labels do not replace the need to be alert, to properly train and supervise operators, and to use common sense when using this equipment.

Key Components of the Mixer



FRONT VIEW



SIDE VIEW

Installation

UNPACKING

Unpack the mixer immediately after receipt. If the machine is found to be damaged, immediately contact us at help@globefoodequip.com or call 1-800-347-5423 ext. 256. Please include your name, serial #, item that is damaged, explanation of the damage and photographs if possible. The damage must be reported to Globe within 7 days from the time of shipment. Refer to Globe's Freight Damage policy for more information. <https://globefoodequip.com/support/order-return-policy.html>

⚠️ WARNING

TO AVOID SERIOUS PERSONAL INJURY:

- ALWAYS install equipment in work area with adequate lighting and space.
- ONLY operate on a solid, level, nonskid surface that is nonflammable.
- NEVER bypass, alter, or modify this equipment from its original condition. Doing so can create hazards and will void warranty.
- NEVER operate mixer without all warning labels attached.

INSTALLATION

1. Read this manual thoroughly before installation and operation. DO NOT proceed with installation and operation if you have questions or do not understand anything in this manual. Contact your local representative or Globe first.
2. Remove mixer from the box.
3. Select a location for mixer that has a level, solid, nonskid surface that is nonflammable and is in a well-lighted work area away from children and visitors.
4. Inspect mixer to make sure all parts have been provided (i.e., bowl, beater, whip, and hook).

⚠️ WARNING PROPER GROUNDING

THIS MACHINE IS PROVIDED WITH A THREE-PRONG GROUNDING PLUG. THE OUTLET TO WHICH THIS PLUG IS CONNECTED MUST BE PROPERLY GROUNDED. IF THE RECEPTACLE IS NOT THE PROPER GROUNDING TYPE, CONTACT AN ELECTRICIAN. DO NOT UNDER ANY CIRCUMSTANCES CUT OR REMOVE THE THIRD GROUND PRONG FROM THE POWER CORD OR USE ANY ADAPTER PLUG (Fig. 6-1 and Fig. 6-2).



Fig. 6-1 Correct



Fig. 6-2 Incorrect

5. Complete the warranty registration online at www.globefoodequip.com/support/warranty-registration-form
6. Clean mixer before use. Refer to Cleaning Instructions on page 10. NOTE: It is normal for the factory to apply a generous amount of grease in and on the machine before initial use. Excess high pressured grease (brownish-black) can also be found on planetary shaft and some drippings can be found in bowl.

Operating Instructions

WARNING

TO AVOID SERIOUS PERSONAL INJURY:

- **DO NOT** operate mixer before reading the instruction manual first.
- **ALWAYS** disconnect or unplug electrical power before cleaning, servicing, or adjusting parts or attachments.
- **ALWAYS** keep hands, hair and clothing away from moving parts.

ATTACHING BOWL TO MIXER

NOTE: Install bowl BEFORE attaching agitators.

1. Lower bowl by pushing bowl lift lever backward and down to its resting position.
2. Lift bowl by bowl handle.
 - a. Slowly position the locking pin (located on rear of bowl) into hole in the middle rear of cradle (Fig. 7-1).
 - b. Lower bowl onto pins located on either side of bowl cradle.
3. Once bowl is positioned on cradle, secure bowl by pulling both bowl clamps forward until bowl is locked tight (Fig. 7-2).



Fig. 7-1



Fig. 7-2

ATTACHING AGITATOR TO MIXER (i.e., Beater, Hook, Whip)

NOTE: It is easier to install agitator before adding ingredients into bowl.

1. The bowl must be in lowered position and splash cover must be removed (Fig. 7-3).
2. Slide agitator slowly upwards onto planetary shaft, fitting shaft pin through the slot in agitator (Fig. 7-4).
3. Rotate agitator clockwise to secure it onto planetary shaft (Fig. 7-5).



Fig. 7-3

MIXING INGREDIENTS

Follow the capacity chart located on page 12 in this owners manual.
Overloading or not following this chart will damage mixer and void the warranty.

IMPORTANT: Make sure the speed control lever is on the first (1) speed.



Fig. 7-4



Fig. 7-5

Operating Instructions

1. Add appropriate mixing ingredients into bowl.
2. Put splash cover on top of bowl and align the arrow on splash cover with notch on rim of bowl (Fig. 8-1).
3. Secure splash cover by squeezing both metal clamps while pressing down on splash cover (Fig. 8-2).
4. Lift completely up on bowl lift lever until bowl locks into position (Fig. 8-3).



Fig. 8-1

NOTE: Mixer will not start if bowl is in lowered position.

NOTE: Time display must be illuminated. If it is not illuminated press stop button.

5. Press up arrow to set timer to appropriate mixing time.
6. Lift for lower speed control to select appropriate speed setting.



Fig. 8-2

Three fixed speeds are available for use: first (1), second (2) and third (3).

Recommended speeds while mixing:

<u>Gear Speed</u>	<u>Product Type/Ingredient</u>
1 (low)	Heavy: mixing pizza, bread, pasta and donut doughs, waffle/cake batter, mashing potatoes
2 (medium)	Medium: 2nd stage of mixing for donut dough, etc.
3 (high)	Light: whipping cream, egg whites, meringue

IMPORTANT: When mixing product always follow the recommended agitator and speed setting according to the capacity chart located on page 12 of this manual.

7. Press green start button located on middle of control panel.



Fig. 8-3



Always STOP mixer BEFORE changing speeds! Failure to do so can damage gears or other parts and WILL void the warranty!

8. To change speed while mixing.
 - a. Press red stop button twice
 - b. Change speed by raising or lowering speed control lever
 - c. Press green start button to restart mixer.

NOTE: If the mixer shuts off during operation, reduce the batch size.

NOTE: Mixer is equipped with motor overload protection. If mixer shuts off during operation press stop button and reduce the batch size; then press overload reset button located on the back of mixer base.

NOTE: Reduce batch size by 10% if using chilled flour, water below 70°F, or ice in the mix.

Operating Instructions

IMPORTANT: For heavier loads, mixer must not run longer than fifteen minutes without pausing for a cool down period of at least fifteen minutes or more before resuming mixing. For lighter loads, mixer must not run longer than thirty minutes without pausing for a cool down period of at least thirty minutes or more before resuming mixing.

9. When the ingredients have been thoroughly mixed, press red stop button to stop mixer.

NOTE: The mixer will automatically stop when the time on the timer has expired.

10. Lower bowl by pushing bowl lift lever backwards and down to its resting position.

11. Remove splash cover by pressing splash cover clips and raising it off of bowl.

12. Remove agitator from planetary shaft by lifting it upwards, then rotate it counterclockwise until it is unlocked. Lower the agitator and remove from the planetary shaft.

13. Push each bowl clamp backwards to unlock bowl from bowl cradle.

14. Lift up slightly on bowl so it clears pins on bowl cradle.

Cleaning Instructions

CAUTION

- Dilute detergent per supplier's instruction.
- DO NOT hose down or pressure wash any part of mixer.
- **NEVER** use a scrubber pad, steel wool, or abrasive material to clean mixer.
- **NEVER** use bleach (sodium hypochlorite) or bleach-based cleaner.
- **ALWAYS** remove agitator after each batch. If not, agitator can become stuck on shaft and can be difficult to remove.



The entire mixer, including removable parts, must be thoroughly cleaned and sanitized using the procedures identified by your local health department and the ServSafe Essentials published by the National Restaurant Association Educational Foundation (NRAEF). Visit www.servsafe.com for more details.



It is extremely important to sanitize the mixer and to follow the instructions on the quaternary sanitizer container to ensure proper sanitation is achieved.



ALWAYS DISCONNECT OR UNPLUG THE ELECTRICAL POWER FROM THE MIXER BEFORE CLEANING.

RECOMMENDED CLEANING

PART	REQUIRED ACTION	FREQUENCY
Agitators	Hand wash using mild soap and water; rinse, dry, and sanitize.	Clean after each use.
Bowl	Use a scrubber pad, mild soap and apply water pressure to make sure bowl is clean; rinse, dry, and sanitize. Bowl can also be placed in a dishwasher for cleaning.	Clean after each use.
Splash cover	Hand wash using mild soap and water; rinse, dry, and sanitize.	Clean after each use.
Bowl Cradle	Hand wash using mild soap and water; rinse, dry, and sanitize.	Daily
Planetary Shaft	Wipe with clean, damp cloth, dry, and sanitize.	Clean after each use.
Exterior	Hand wash using mild soap and water; rinse, dry, and sanitize. DO NOT use a water hose!	Daily

Important Points

Your new Globe mixer will provide years of uninterrupted service, but only if you do the following.

Installation

- Do not use an extension cord to connect electrical power.

Operation

- Turn off mixer before to changing speeds.
- Follow the capacity chart on page 12, especially for mixing dough.
- Use only the first (1) speed for mixing dough.
- If the unit shuts off during mixing (overload protection trips) reduce the batch size.

Capacity Chart

The following maximum capacities are intended as a guideline only. Varying factors such as the type of flour used, temperature of water used and other conditions may require the batch to be reduced.

Product	Agitator and Speed	SP05	SP08	SP10	SP20	SP25	SP30/ SP30P	SP40	SP60	SP62P	SP80PL
Waffle or Hotcake Batter	Flat Beater	2 qts.	3 qts.	5 qts.	8 qts.	10 qts.	12 qts.	16 qts.	24 qts.	----	30 qts.
Whipped Cream	Wire Whip	2 qts.	2 qts.	2 qts.	4 qts.	5 qts.	6 qts.	9 qts.	12 qts.	----	16 qts.
Mashed Potatoes	Flat Beater	4 lbs.	4 lbs.	8 lbs.	15 lbs.	18 lbs.	23 lbs.	30 lbs.	40 lbs.	----	50 lbs.
Egg Whites	Wire Whip	¾ pts.	¾ pts.	1 pt.	1 qt.	1¼ qts.	1½ qts.	1¾ qts.	2 qts.	----	2 qts.
Meringue (Qty. of Water)	Wire Whip	¼ pts.	½ pts.	¾ pts.	1½ pts.	1¾ pts.	1 qt.	1¼ qts.	1¾ qts.	----	3 qts.
Raised Donut Dough (65% AR) *◆	Dough Hook 1st and 2nd	2 lbs.	2 lbs.	4½ lbs.	9 lbs.	12 lbs.	15 lbs./ 20 lbs.	25 lbs.	60 lbs.	75 lbs.	80 lbs.
Heavy Bread Dough (55% AR) **◆	Dough Hook 1st only	4 lbs.	3 lbs.	7½ lbs.	15 lbs.	20 lbs.	30 lbs./ 35 lbs.	40 lbs.	70 lbs.	75 lbs.	80 lbs.
Bread and Roll Dough (60% AR) **◆	Dough Hook 1st only	5 lbs.	5 lbs.	12½ lbs.	25 lbs.	25 lbs.	45 lbs.	60 lbs.	80 lbs.	90 lbs.	90 lbs.
Pizza Dough, Thin (40% AR) *x◆□	Dough Hook 1st only	3 lbs.	2 lbs.	5 lbs.	9 lbs.	12 lbs.	16 lbs./ 25 lbs.	30 lbs.	40 lbs. (1st) 35 lbs. (2nd)	50 lbs. 35 lbs. (2nd)	50 lbs.
Pizza Dough, Medium (50% AR) **◆□	Dough Hook 1st only	4 lbs.	4 lbs.	5 lbs.	10 lbs.	15 lbs.	25 lbs./ 36 lbs.	40 lbs.	70 lbs. (1st) 35 lbs. (2nd)	80 lbs. (1st) 60 lbs. (2nd)	90 lbs.
Pizza Dough, Thick (60% AR) **◆	Dough Hook 1st only	5 lbs.	5 lbs.	10 lbs.	20 lbs.	25 lbs.	40 lbs./ 45 lbs.	50 lbs.	70 lbs.	90 lbs.	100 lbs.
Fondant Icing	Flat Beater	4 lbs.	3 lbs.	6 lbs.	12 lbs.	15 lbs.	18 lbs.	25 lbs.	36 lbs.	----	60 lbs.
Cake	Flat Beater	5 lbs.	6 lbs.	10 lbs.	20 lbs.	25 lbs.	30 lbs.	40 lbs.	60 lbs.	----	90 lbs.
Pie Dough	Flat Beater	5 lbs.	4 lbs.	10 lbs.	18 lbs.	22 lbs.	27 lbs.	35 lbs.	50 lbs.	60 lbs.	70 lbs.
Pasta, Basic Egg Noodle	Dough Hook	1 lb.	2 lbs.	3 lbs.	5 lbs.	6 lbs.	8 lbs./ 15 lbs.	17 lbs.	35 lbs.	40 lbs.	50 lbs.

* NOTE: The mixer capacity depends on the moisture content of the dough. When mixing doughs (pizza, bread, or bagel) check your AR%! %AR (% Absorption Ratio) = Water weight divided by flour weight. The capacities listed above are based on flour at room temperature and 70°F water temperature. (1 gallon of water weighs 8.33 lbs.)

- x Maximum Mixing Time - 7 Minutes
- If high gluten flour is used, reduce the batch size by 10%.
- ◆ If using chilled flour, water below 70°F, or ice, reduce batch size by 10%.
- 2nd speed should never be used on 50% AR or lower with the exception of the SP60. The SP60 requires a 50% reduction in batch size to mix in speed 2 with 50% AR doughs.

Do not use attachments on hub while mixing!

Troubleshooting

Problem	Possible Causes	Action Required
Mixer will not run.	Timer is not engaged.	Turn timer on by pressing up arrow to a set time.
	Bowl not raised into position.	Raise bowl and lock into position.
	Power not connected properly.	Check all power connections. Plug into a live socket. (<i>Do not use extension cord!</i>) Test socket with another item.
	Building circuit breaker is off.	Check breaker box.
	Internal overload tripped.	Press stop button, then press reset button.
	Gear not engaged.	Switch gear fully into position. (<i>Mixer will not operate if speed control lever is positioned between speeds</i>)
Mixer stops during mixing.	Internal overload tripped.	Press stop button, then press reset button.
Mixer is noisy.	Mixer is not installed on level surface.	Adjust surface or relocate mixer.
	Bowl not seated correctly or clamps not in place.	Ensure bowl is seated into bowl cradle correctly and bowl clamps are locked into place.
	Agitator not fitted properly.	Remove and reattach agitator into position properly.
	Overloading bowl.	Reduce batch size. (<i>See Capacity Chart</i>)
Mixing time is too long.	Batch size too small.	Increase batch size <u>or</u> use smaller bowl adapter kit. (<i>Contact dealer for purchase</i>)
	Incorrect recipe portions <u>or</u> temperatures.	Follow portions and temperatures per recipe instructions.
Bowl raise sticking or not operational	Lack of lubrication and/or cleaning of bowl slides	Hand wash using mild soap and water; dry, and lubricate bowl slides with mineral oil or food quality grease. If still sticking, a technician must clean bowl raise mechanism.
One or more gears not working.	Damaged or broken gear.	Technician to replace gear. <i>Always stop mixer before changing speeds!</i>

Troubleshooting

Problem	Possible Causes	Action Required
Agitators touching bottom or sides of bowl.	Defective or dented bowl.	Remove dents or replace bowl.
	Defective agitator.	Replace agitator.
Broken Whip Wires	Batch size too large for mixer. Items too firm, speed too high.	Reduce batch size. (<i>See Capacity Chart</i>) Adjust recipe. Reduce speed.
	Hand utensil dropped into bowl while mixing.	Stop mixer before working on mixture.
Broken Flat Beater	Ingredients too cold or too large (e.g. frozen butter, cream cheese cut in chunks).	Wait for ingredients to reach room temperature before mixing. Reduce chunk size.
Broken Dough Hook	Batch size too large for mixer.	Reduce batch size. (<i>See Capacity Chart</i>) Adjust recipe.
	Ingredients too cold or too large.	Wait for ingredients to reach room temperature before mixing. Reduce chunk size.
Discoloration of mixed product.	Bowl has not been thoroughly cleaned.	Clean bowl again using a scrubber pad and applying pressure (refer to page 10).
Agitators won't go onto planetary shaft easily.	Lack of lubrication and/or cleaning of planetary shaft.	Wipe planetary shaft with a clean, damp cloth and lubricate the shaft with mineral oil or food quality grease.

If problems persist and the assigned solution does not remedy the issue, please call our Service Department at 866-260-0522.

