

INSTRUCTIONS



FlashBake® Microwave

HFBMW SERIES FLASHBAKE® MICROWAVE OVENS

MODELS

*HFBMW2
HFBMW3*

ML- 126818



701 S. RIDGE AVENUE
TROY, OHIO 45374-0001

937 332-3000

www.hobartcorp.com

FORM 34550 Rev. A (Jan. 2001)

P/N. 3828W5A1817

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions must be followed, including the following:

WARNING: TO REDUCE THE RISK OF BURNS, ELECTRIC SHOCK, FIRE, INJURY TO PERSONS, OR EXPOSURE TO EXCESSIVE MICROWAVE ENERGY:

1. Do not use metal utensils in this oven.
2. Read all instructions before using oven.
3. Read and follow the “Precautions to Avoid Possible Exposure to Excessive Microwave Energy” on the next page.
4. This oven must be grounded. Connect only to a properly grounded outlet. See ELECTRICAL CONNECTIONS.
5. Locate or install this oven only in accordance with the instructions provided.
6. Some items, such as whole eggs or sealed containers, may explode and should not be heated in this oven. Example: Closed glass jars.
7. Use this oven only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this oven. This type of oven is specifically designed to heat, cook, or dry food. It is not designed for industrial or lab use.
8. As with any appliance, close supervision is necessary when used by children.
9. Do not operate this oven if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
10. This oven should be serviced only by qualified service personnel. Contact your local Hobart Service Office for examination, repair or adjustment.
11. Do not cover or block any openings on the oven.
12. Do not use this oven outdoors. Do not use this oven near water.
13. Do not immerse cord or plug in water.
14. Keep cord away from heated surfaces.
15. Do not let cord hang over edge of table or counter.
16. When cleaning, use only mild, nonabrasive soap or detergent applied with a sponge or soft cloth. Refer to the CLEANING section in this manual.
17. To reduce the risk of fire in the oven cavity:
 - a. Do not overcook food.
 - b. If materials inside the oven should ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
 - c. Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils, or food in the cavity when not in use.
 - d. Remove wire twist-ties from paper or plastic bags before placing in oven.

PLEASE KEEP THIS MANUAL FOR FUTURE REFERENCE

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

1. **Do not attempt to operate this oven with the door open** since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
2. **Do not place any object** between the oven front face and the door.
3. **Do not operate the oven** if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
 - a. Door (bent).
 - b. Hinges and latches (broken or loosened).
 - c. Door seals and sealing surfaces.
4. **The oven should not be adjusted or repaired** by anyone except properly qualified service personnel.

CAUTION

1. **Do not attempt to tamper with** or make any adjustments or repairs to the door, control panel housing, safety interlock switches or any other part of the oven. Do NOT remove outer panel from oven. Repairs should only be done by a qualified service person.
2. **Do not operate the oven when it is empty.** The microwave energy will reflect continuously throughout the oven if no food or water is present to absorb energy.
3. **If a fire occurs in the oven,** press the ON/OFF key to shut the oven off. LEAVE THE DOOR CLOSED. Disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
4. **Do not attempt to dry clothes,** newspapers or other materials in the oven. They may catch fire.
5. **Do not use recycled paper products,** as they may contain impurities which may cause sparks and/or fires.
6. **Do not use newspapers or paper bags** for cooking.
7. **Do not hit or strike control panel.** Damage to controls may occur.
8. **Cooking trays and containers can become hot,** oven mitts or pot holders should be used.
9. **Do not store flammable materials** next to, on top of, or in the oven. It could be a fire hazard.
10. **Do not use the inside surfaces** of the oven for direct food contact. Always use approved utensils and cookware.
11. **Before removing a tray or container from the oven,** prepare a place to put it. Do not place the hot tray on wood, plastic, formica, or other burnable surfaces.

TABLE OF CONTENTS

GENERAL.....	5
INSTALLATION	5
Unpacking.....	5
Location	5
Tip Bracket	6
Installation Codes and Standards	6
Electrical Connections	7
OPERATION	8
Controls	8
Setting the Clock	9
Start Cooking	9
Cooking Features	11
Repeat Last	11
Resume	11
Power Levels	11
Recipe Options	13
Combi Cook	14
Microwave Cooking	15
Microwave Cooking Features	15
Timed Cooking	15
Micro Express	15
Power Level	16
Recipe Options	16
Defrosting	18
Cleaning	20
MAINTENANCE	22
TROUBLESHOOTING	23
FLASHBAKE OVEN FOOD PRODUCT GUIDELINES	24

INSTALLATION, OPERATION AND CARE OF MODEL HFBMW FLASHBAKE® MICROWAVE OVEN

GENERAL

Your Hobart FlashBake® Microwave oven is a versatile oven that employs a revolutionary high quality, high-speed cooking technology. This new technology cooks the outside of foods, while also penetrating the surface so the inside cooks simultaneously. Foods cook evenly and fast, retaining their natural moisture. Bread products brown and become crisp while vegetables retain their color and texture.

While halogen light is the primary source of power, a "microwave boost" is automatically added with certain foods. The oven can also be used solely as a 950 watt microwave oven.

It is suggested that you thoroughly read this manual and carefully follow all of the instructions provided.

INSTALLATION

UNPACKING

Immediately after unpacking the oven, check for possible shipping damage. If this oven is found to be damaged, save the packaging material and contact the carrier within 15 days of delivery.

Prior to installation, verify that the electrical supply agrees with the specifications on the data plate located on the back of the oven. If the supply and specifications do not agree contact your local Hobart Service Office immediately.

Peel the protective shipping film from the exterior of the oven before installation or use.

LOCATION

Locate the oven on a smooth, flat and stable surface. Do not place the oven in a hot or damp area, i.e., near a gas or electric range. The oven must not be located above or next to sources of excessive heat or greasy air. There must be a 3" (76 mm) clearance on the sides and back of the oven for free air flow.

It is recommended that the oven be located so the housing can be removed for service. The housing should NOT be removed by anyone except qualified service personnel.

Locate oven on a level counter surface. The counter must be 36 1/2" (916 mm) or higher and capable of supporting the 80 lb. (36 kg) ovenload.

Radio Interference

There is possibility of a small amount of interference with weak broadcast signals if the oven is too close to a radio or TV or similar equipment. If interference is present, it may be reduced by:

1. Cleaning the door and sealing surface of the oven.
2. Increasing the separation of the oven from the receiving device.
3. Using an antenna to obtain stronger signal reception for the receiving device.

Tip Bracket

The tip bracket is a safety feature designed to help keep the oven stable when the door is open. Proper installation is important!

- Position the oven in its final location.
- As you are looking at the back of the oven, position the tip bracket on the bottom back right side of the oven (Fig. 1).
- Use the existing hole on the back of the oven to secure the tip bracket to the oven back.
- Anchor the bracket to the counter surface.




Fig. 1

INSTALLATION CODES AND STANDARDS

The oven must be installed in accordance with:

In the United States of America:

1. State and local codes.
2. National Electrical Code, ANSI/NFPA-70 (latest edition). Copies may be obtained from The National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

In Canada:

1. Local codes.
2. Canadian Electric Code, CSA C22.2 (latest edition). Copies may be obtained from The Canadian Standard Association, 178 Rexdale Blvd., Etobicoke, Ontario, Canada M9W 1R3.

ELECTRICAL CONNECTIONS

WARNING: ELECTRICAL AND GROUNDING CONNECTIONS MUST COMPLY WITH THE APPLICABLE PORTIONS OF THE NATIONAL ELECTRICAL CODE AND/OR OTHER LOCAL ELECTRICAL CODES.

WARNING: DISCONNECT ELECTRICAL POWER SUPPLY AND PLACE A TAG AT THE DISCONNECT SWITCH TO INDICATE YOU ARE WORKING ON THE CIRCUIT.

WARNING: APPLIANCES EQUIPPED WITH A FLEXIBLE ELECTRIC SUPPLY CORD ARE PROVIDED WITH A FOUR-PRONG GROUNDING PLUG. IT IS IMPERATIVE THAT THIS PLUG BE CONNECTED INTO A PROPERLY GROUNDED FOUR-PRONG RECEPTACLE. IF THE RECEPTACLE IS NOT THE PROPER GROUNDING TYPE, CONTACT AN ELECTRICIAN. DO NOT REMOVE THE GROUNDING PRONG FROM THIS PLUG.

The electrical diagram is located in an envelope behind the control panel.

For Hard-Wired Ovens

Have a qualified electrician wire the oven into a properly rated dedicated circuit, connecting to the wires and conduit provided. Use appropriate conduit, strain relief, wire and connectors. Care should be taken not to damage the wire when applying setscrew type connectors. If connecting to aluminum wiring, properly installed connections listed for use with aluminum and copper wiring must be used.


For Cord-Connected Ovens

A short power supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord. Do not use an extension cord.

Plug the oven into a dedicated circuit outlet of the appropriate NEMA style and rating. The wall outlet receptacle recommended for this appliance is NEMA 14 - 30R.

NOTE: Both hot legs must measure 120V to neutral. Do not connect this oven to a source using a *stinger* or *wild leg*.

Single Phase 4 Wire Ground with Neutral



NEMA 14 - 30R Wall receptacle
30 Amp

ELECTRICAL DATA

Voltage	Amp	KW	Cycles	Phase
120/208-240	30	6.5	60	1

OPERATION

WARNING: THE OVEN AND ITS PARTS ARE HOT. USE CARE WHEN OPERATING, CLEANING, OR SERVICING THE OVEN.

CONTROLS (Fig. 2)



Press to turn the oven control pad on and off.



Press to operate the microwave cooking mode.



Press to set your own cooking program.



Press to access the preset cooking menu.



Press to enter food selections and start cooking.



Press to scroll through menu categories. Press to increase or decrease cooking times and power levels.



Press to change cooking power levels.



Press repeatedly for 30 second increments of microwave cooking time. The oven starts immediately.



Press to store custom recipes from the COMBI COOK feature to the key pad for one touch cooking.



Press during cooking to immediately shut off all cooking power. Press to clear out of cooking programs and go back to the clock screen.



Press to quickly access custom recipes for one touch cooking. Keys 1 through 12.




Fig. 2

PL-53574

SETTING THE CLOCK

When the oven is plugged in, the display will prompt you to set the clock. The clock must be set before using the oven for the first time.

1. Press to set the hour. Press to enter selection.
2. Press to set the minutes. Press to enter selection.
3. Press to set AM or PM. Press to enter selection.
4. The clock is set.
5. To change to clock setting, the oven must be unplugged then plugged back in.

START COOKING

Step 1: Press on the control pad.

Step 2: Press to select the type of food category you want. Press to enter selection.

Step 3: Press to select the specific food. Press to enter selection.

Step 4: Press to select amount, size, and/or doneness. Press after each selection.

Step 5: When the display reads ADJUST TIME or START, press to start cooking.

- If the door is opened during cooking, the oven will stop and PAUSE will appear in the display. Close the door and press to resume cooking.
- To adjust cook time during cooking, press to increase or decrease the time.
- To clear out of any function or program and go back to the clock screen, press .
- To review settings during cooking, press during cooking process.
- To stop the oven anytime during the cooking process press .
- At the end of the cooking cycle, YOUR FOOD IS READY appears on the display.
- At the end of the cooking cycle, the automatic fan will continue to run for a short time to cool internal components.


Preset Food Selections

For a detailed review of food selections and recipes, see the HFBMW FLASHBAKE® OVEN FOOD PRODUCT GUIDELINES section starting on page 24.


- Appetizers and Snacks
- Baked Goods
- Breakfast
- Chicken
- Fish & Seafood
- Meats
- Pasta
- Pizza
- Recipe
- Sandwiches
- Side Dishes

Cooking Trays (Fig. 3)


The HFBMW FlashBake® Microwave Oven is supplied with three cooking trays which are specifically designed for use in this oven.




Oven Rack Turntable



Black Metal Tray



Black Metal Grill Tray



White Ceramic Tray

PL-53578-E



Fig. 3

- The oven rack turntable must be in place for all cooking. Be sure it seats securely over the square spindle in the center of the oven.
- Place the selected tray or cookware directly on the oven rack turntable.
- Cooking trays and containers can become hot. Oven mitts or pot holders should be used.
- Food should be placed directly on the trays when cooking.
- Use the black metal flat tray in the same way you would use a shallow baking pan or baking tray.
- Use the black grill tray for foods that you would normally cook on the grill, such as steaks, fish and poultry.
- Place the white ceramic tray on the oven rack turntable when using the microwave features. Place food or microwave safe cookware directly on the tray.
- In addition to the cooking trays provided, you can use non-metal casserole dishes, pie plates and other heat safe cookware. Make sure to select a size that will rotate easily.
- Do not use cookware or coverings made of paper, plastic, or foil.

COOKING FEATURES



Repeat Last

Use this feature for cooking repetitive items like cookies or appetizers. The last program is stored for two hours.

1. Press and hold  for about 3 seconds.
2. The last preset food will be displayed.
3. Press  to start cooking.

Resume

For cooking foods longer than the programmed time.








1. After a cooking program has timed out, press  or open and close the oven door.
2. Press . RESUME COOKING will be displayed.
3. The oven will restart and resume the cooking program at 10% of the original time.
4. The program stays in memory for 10 minutes. After that you will need to start the program again.

Power Levels





The HFBMW FlashBake® oven uses upper and lower halogen lamps with microwaves to cook food from the top, bottom and interior simultaneously. Power levels on the lamps and microwave can be adjusted separately.

When using the preset menu foods, the power levels are already selected for you. However, power levels can be adjusted on both preset menu foods and custom recipes.

To adjust power levels before cooking:

1. Press  and select food category, specific food and amount (see Quick Start).
2. When display reads ADJUST TIME or START, press .
3. The oven will prompt you to adjust power levels.
4. Press   to increase or decrease the upper, lower and micro power levels. Press  after each selection.
5. If you do not wish to change a setting, press  to move to the next selection.
6. When display reads ADJUST TIME or START, press  to start cooking.

To adjust power levels during cooking:

1. Press  at any time during the cooking process.
2. The oven will prompt you to adjust power levels.
3. Press   to increase or decrease the upper, lower and micro power levels. Press  after each selection.
4. The power levels are adjusted.

Power Level Guidelines

Each power level gives you halogen lamp power and microwave energy for a certain percentage of the time.

For example:

- U=07 Upper halogen lamp on 70% of the time.
- L=07 Lower halogen lamp on 70% of the time.
- M=05 Microwave on 50% of the time.

Follow these general standards when selecting the best upper, lower and micro power settings. Be careful when adjusting power levels so that you do not over or undercook your food.

(U=) UPPER HALOGEN LAMP

- Select a higher setting for foods requiring a golden brown top (example: fish fillets, toast, boneless chicken breasts).
- Select a lower setting for thicker foods and foods with high sugar or fat content (examples: cakes, roasts).

(L=) LOWER HALOGEN LAMP

- Select a higher setting for thick or dense foods that may not cook quickly in the center (example: casseroles).
- Select a lower setting for thin foods (example: cookies) and foods containing high fat or sugar content (example: pastry, cakes).

















(M=) MICROWAVE

- Select a higher setting to shorten cooking time for dense or heavy foods (example: casseroles, whole chicken).
- Select a lower setting for delicate foods (examples: cakes, breads, souffles) or foods requiring longer cook times for tender results (example: stew, pot roast).









RECIPE OPTIONS

Create and store up to 30 custom recipes, or customize an existing recipe.


















Entering and Saving a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display. Press   to select a blank entry to store recipe. Press  to enter selection.
4. The oven will ask you to select COOKING TIME, UPPER, LOWER and MICRO power levels. Press   to select values. Press  after each selection to enter.
5. SPELL THE FOOD NAME appears on the display. Press   to spell out food name. Press  after each letter selected. Press  to end.
6. PRESS START TO RUN appears on the display. Press  to cook recipe. To store the recipe without cooking, press  .










Finding and Using a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display.
4. Press   until the recipe you want is displayed. Press  to enter selection.
5. When the display reads ADJUST TIME or START, Press  to start cooking.

Adjusting or Changing a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display.
4. Press   until the recipe you want to change is displayed. Press  to enter selection.
5. When the display reads ADJUST TIME or START, press  .
6. The oven will ask you to select COOKING TIME, UPPER, LOWER and MICRO power levels. Press   to select values. Press  after each selection to enter.
7. SPELL THE FOOD NAME appears on the display. Press   to spell out food name. Press  after each letter selected. Press  to end.
8. RECIPE #_ MODIFIED appears on the display. Press  to cook recipe. To store the recipe without cooking, press  .






Deleting a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display.
4. Press   until the recipe you want to change is displayed. Press  to enter selection.
5. When the display reads ADJUST TIME or START, press and hold  for 3 seconds. This deletes the recipe. SELECT COOK TIME appears on the display. You may now enter and save a new recipe or press  to go back to the clock screen.


COMBI COOK

Use this feature to quickly cook items not found in the preset food selections. You can also customize your own cooking recipes and store them to the key pad for a one-touch control to quickly cook food.

Creating a Recipe in Combi Cook

1. Press  on the control pad.
2. The oven will ask you to select COOKING TIME, UPPER, LOWER and MICRO power levels. Press   to select values. Press  after each selection to enter.
3. When the display reads ADJUST TIME or START, press  to start cooking.

Saving Recipes to the Keypad




1. After you have selected the cooking time and power levels in the COMBI COOK mode, press  .
2. SELECT LOCATION will appear on the display.
3. Press a number on the key pad where you want the recipe stored (1 - 12) . The oven will store two recipes at each number. Press the number once to store the recipe at the first location (A), and twice to store it at the second location (B).
4. If another recipe is stored at that location, the display will read CELLFULL OVERRIDE? Press (1) to override the previous saved recipe or (2) to decline and choose another location.
5. To use the key pad for quick cooking, press the number corresponding to the desired recipe. To cook from the second saved recipe, press the number twice. The oven immediately starts cooking.




Note: You can also save recipes to the key pad from the preset programs found under MENU COOK. Simply copy the information from the desired recipe and manually enter it in the COMBI COOK mode.

MICROWAVE COOKING







- Be sure to follow all precautions on page 2 and 3 of this manual.
- Make sure the oven rack turntable and white ceramic tray are in place.

Step 1: Press  on the control pad.

Step 2: Press   to select the type of food you want. Press  to enter selection.

Step 3: Press   to select amount and weight. Press  to enter each selection.

Step 4: When the display reads ADJUST TIME or START, press  to start cooking.

- If the door is opened during cooking, the oven will stop and PAUSE will appear in the display. Close the door and press  to resume cooking.
- To adjust cook time during cooking, press   to increase or decrease time.
- To clear out of any function or program and go back to the clock screen, press  .
- To review settings during cooking, press  during cooking process.
- To stop the oven anytime during the cooking process, press  .









Microwave Preset Food Selections

- Bacon
- Defrost (Auto and Time)
- Vegetables (Fresh, Frozen, Canned)
- Recipe
- Time cook

MICROWAVE COOKING FEATURES



Timed Cooking

Use this to microwave food that is not in the recipe section.

1. Press  on the control pad.
2. Press   until TIME COOK appears on the display. Press  to enter selection.
3. Press   to set the time. Press  to enter selection.
4. When the display reads ADJUST TIME or START, press  to start cooking.

Micro Express








Use this one touch feature to quickly microwave food.

1. Place food in oven.
2. Press  . Oven starts immediately for 30 seconds of microwave cooking time.
3. To increase time, press  repeatedly. Time increases in 30 second increments.





Power Level

The power level is automatically set on high or 10. You can change the power level before or during a cooking program (except when using MICRO EXPRESS).

To adjust power level before cooking:

1. Press  and select food category, amount and weight. Press  after each selection.
2. When the display reads ADJUST TIME or START, press .
3. SELECT MICRO POWER appears on the display.
4. Press   to increase or decrease power level. Press  to enter selection.
5. When the display reads ADJUST TIME or START, press  to start cooking.

To adjust power levels during cooking:

1. Press  any time during the cooking process.
2. SELECT MICRO POWER appears on the display. Press   to increase or decrease power level. Press  to enter selection.
3. The power level is adjusted.

















Power Level Guide Lines

- High 10: Fish, bacon, vegetables, boiling liquids.
- Med-High 7: Gentle cooking of meat and poultry: baking casseroles and reheating.
- Medium 5: Slow cooking and tenderizing for stews and less tender cuts of meats.
- Low 2 or 3: Defrosting; simmering; delicate sauces.
- Warm 1: Keeping food warm; softening butter.









RECIPE OPTIONS

Use this feature to create up to 10 custom recipes, or customize an existing recipe.


















Enter and Saving a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display. Press   to select blank line to store recipe. Press  to enter selection.
4. The oven will ask you to select COOKING TIME and MICRO power level. Press   to select values. Press  after each selection to enter.
5. SPELL THE FOOD NAME appears on the display. Press   to spell out food name. Press  after each letter selected. Press  to end.
6. PRESS START TO RUN appears on the display. Press  to cook recipe. To store the recipe without cooking, press .










Finding and Using a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display.
4. Press   until the recipe you want is displayed. Press  to enter selection.
5. When the display reads ADJUST TIME or START, press  to start cooking.

Adjusting or Changing a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display.
4. Press   until the recipe you want to change is displayed. Press  to enter selection.
5. When the display reads ADJUST TIME or START, press  .
6. The oven will ask you to select COOKING TIME and MICRO power level. Press   to select values. Press  after each selection to enter.
7. SPELL THE FOOD NAME appears on the display. Press   to spell out food name. Press  after each letter selected. Press  to end.
8. RECIPE #_ MODIFIED appears on the display. Press  to cook recipe. To store the recipe without cooking, press  .









Deleting a Recipe

1. Press  on the control pad.
2. Press   until RECIPE appears on the display. Press  to enter selection.
3. SELECT CUSTOM RECIPE appears on the display.
4. Press   until the recipe you want to change is displayed. Press  to enter selection.
5. When the display reads ADJUST TIME or START. Press and hold  for 3 seconds. This deletes the recipe. SELECT COOK TIME appears on the display. You may now enter and save a new recipe or press  to go back to the clock screen.

DEFROSTING

Auto Defrost

Automatically sets the defrosting times and power levels to give even defrosting results for meats, poultry and fish weighing up to six pounds.

1. Remove food from the package and place it on a microwave safe dish.
2. Press  on the control pad.
3. Press   until DEFROST (AUTO) appears on the display. Press  to enter selection.
4. SELECT FOOD WEIGHT appears on the display. Press   to increase or decrease food weight (see Conversion Guide). Press  to enter selection.
5. When the display reads ADJUST TIME or START, press  to start defrosting.
6. Turn the food over when the oven signals TURN FOOD OVER.









CONVERSION GUIDE

If the weight of the food is stated in pounds and ounces, the ounces must be converted to tenths (.1) of a pound.

Weight of Food in Ounces	Enter Food Weight (tenths of a pound)
1 - 2	.1
3	.2
4 - 5	.3
6 - 7	.4
8	.5
9 - 10	.6
11	.7
12 - 13	.8
14 - 15	.9

Time Defrost

Use this feature to defrost for a selected length of time.

1. Remove food from the package and place it on a microwave safe dish.
2. Press  on the control pad.
3. Press   until DEFROST (TIME) appears on the display. Press  to enter selection.
4. SELECT DEFROST TIME appears on the display. Press   to increase or decrease defrost time. Press  to enter selection.
5. When the display reads ADJUST TIME or START, press  to start defrosting.
6. Turn the food over when the oven display reads TURN FOOD OVER.

Defrosting Tips

During DEFROST (TIME), the power level is automatically set at 3, but can be changed. To change power levels, see the Microwave Power Level section.

You can defrost small items quickly by raising the power level after entering the time. Power level 7 cuts the total defrosting time in half; power level 10 cuts the time to about a third. When defrosting at higher power levels, food will need more frequent attention.

Foods that spoil easily should not be allowed to sit out for more than one hour after defrosting.

For more even defrosting of larger foods, such as roasts, use DEFROST (AUTO). Be sure large meats are completely defrosted before cooking.

DEFROST (TIME) can be used for foods frozen in paper or plastic packages, but foods should be taken out of the package when using DEFROST (AUTO). Closed packages should be slit AFTER food has partially defrosted. Plastic containers should be partially uncovered.

CLEANING

WARNING: DISCONNECT (UNPLUG) ELECTRICAL POWER SUPPLY BEFORE CLEANING.

WARNING: THE OVEN AND ITS PARTS ARE HOT. USE CARE WHEN OPERATING, CLEANING AND SERVICING THE OVEN.

The interior cleanliness of the HFBMW oven is essential to ensure maximum cooking efficiency. Keeping the oven clean and free of food debris will minimize the possibility of smoke and odors from food stuck on the lamp shields and interior walls.

The interior of the oven cavity **SHOULD NOT**, under any circumstances, be cleaned with abrasive materials or chemicals other than those recommended below. Certain cleaners can etch and scratch the cavity, causing a loss in cooking efficiency.

CAUTION: Do not use oven cleaners to clean the oven. Do not use abrasives or sharp objects on the oven walls or window.

Cleaners

- Mild dish soap - Use any mild food service type dish soap for the interior cleaning. Be sure that the soap is non-caustic.
- FDA food quality sanitizer for cooking surfaces.
- Vinegar and water solution.
- Baking soda and water solution.

Cleaning Tools

- Terry cloth towel - Food service quality.
- Nonabrasive pad - Institutional quality - certified nonabrasive.

Note: Always rinse cleaned surfaces to ensure all the soap and chemicals have been removed, then wipe dry with a soft clean cloth.

Cleaning Procedures

It is recommended that you clean the oven after each shift. If your operation is extremely busy, it may be necessary to wipe out the oven *during* a shift until you are able to perform the detailed cleaning.

1. Allow the oven to cool before starting the cleaning process.
2. Open the door.
3. Remove the oven rack turntable and wash carefully in warm, sudsy water.
4. Use a cloth dampened with one of the recommended cleaners. Be sure that the soap is non-caustic. Wipe the food debris out of the oven, working from the back forward.
5. Do not pour cleaning liquids into the oven. Always use a cloth dampened with the cleaning fluids.
6. You can use a rubber or plastic scraper or a nonabrasive pad to loosen any residual food remaining on the upper and lower halogen lamp glass covers. Do not remove the lamp covers or touch the cooking lamps. Skin oils on the lamps could lead to premature lamp failure.
7. Both halogen lamp glass covers must be kept free of grease and food splattering in order to operate effectively.
8. Clean the interior surface of the front door with a terry cloth towel and recommended cleaner.
9. Clean the inside of the oven door window with a cloth dampened with window cleaner.
10. With a clean cloth dampened with a food quality sanitizer, wipe the entire interior cavity of the oven, working from the back forward.
11. Clean the exterior of the oven with a soft cloth dampened sparingly with a commercial stainless steel cleaner. Do not use steel wool. The outside of the oven door window may be cleaned with a cloth dampened with window cleaner.

MAINTENANCE

WARNING: THE OVEN AND ITS PARTS ARE HOT. USE CARE WHEN OPERATING, CLEANING AND SERVICING THE OVEN.

WARNING: DISCONNECT (UNPLUG) THE ELECTRICAL SUPPLY BEFORE PERFORMING ANY MAINTENANCE ON THE OVEN.

Do not remove the oven covers or attempt to open the control cabinet. Doing so will void the warranty. There are no user serviceable parts inside.

INSPECTING THE OVEN

At least once each day, when the oven is cool, visually inspect the inside of the oven. Make sure there are no obvious signs of damaged, worn or broken parts.

Do not operate the oven if the upper or lower halogen lamp covers are cracked or broken. Contact your local Hobart Service Office.

LAMP REPLACEMENT

All lamps MUST be replaced by your local Hobart Service Technician.

SERVICE AND PARTS INFORMATION

Contact your local Hobart Service Office.

TROUBLESHOOTING

Problem	Possible Causes	What to Do
The display is blank.	The control pad has been turned off.	Press ON/OFF to turn the control pad on.
Control display is lighted yet oven will not start.	Clock is not set.	Set the clock.
	Door is not securely closed.	Open the door and close securely.
	ENTER/START not pressed after entering cooking selection.	Press ENTER/START.
	Another selection is already entered on control pad and CLEAR was not pressed.	Press CLEAR.
	Size, quantity, or cooking time not entered after selecting VEGETABLES (FRESH, FROZEN, CANNED), BACON, DEFROST (TIME) or (TIME COOK).	Make sure you have entered cooking time after selecting.
	Clear was pressed accidentally.	Reset cooking program and press ENTER/START.
	Food weight not entered after selecting DEFROST (AUTO).	Make sure you have entered food weight after selecting DEFROST (AUTO).
The door and inside of the oven feel hot.	The heat lamps produce intense heat in a small space.	This is normal. Use oven mitts to remove food when ready.
Oven will not start.	The circuit breaker may be tripped.	Reset circuit breaker.
	Power surge.	Unplug the oven, then plug it back in.
	Plug not fully inserted into wall outlet.	Make sure the plug on the oven is fully inserted into wall outlet.


If these actions do not reset the oven and allow the cooking cycle to begin, contact your local Hobart Service Office.

HFBMW FLASHBAKE® OVEN FOOD PRODUCT GUIDELINES


Preset Food Selections

The HFBMW FlashBake® oven is already preset to cook over 100 popular dishes. Use this guide as a quick reference.


- Appetizers and Snacks
- Baked Goods
- Breakfast
- Chicken
- Fish & Seafood
- Meats
- Pasta
- Pizza
- Recipe
- Sandwiches
- Side Dishes



Circular pattern
(Example: biscuits, cookies)




Circular pattern
(Example: biscuits, cookies, meats)



Spoke pattern
(Example: crescent rolls, breadsticks)

PL-53602-E



Single layer
(Example: appetizers)

Fig. 4

Cooking Tips

- To ensure consistent and even browning when cooking foods directly on the black metal tray, arrange food as shown (Fig. 4). Foods can touch but should not overlap.
- Fresh meat, chicken, fish or seafood that has been frozen should be thawed before cooking (the microwave defrost feature can be used). For other frozen prepackaged foods, follow package directions.
- Always check food for doneness at minimum time. Check doneness of meat and poultry with a meat thermometer. Check cakes by inserting a toothpick near the center.
- Select appropriate thickness for steaks.
- To determine the weight of each piece of chicken, divide the package weight by the number of pieces.
- Add toppings, such as cheese or crumbs, and sauces, such as barbecue, during the last 2 to 3 minutes of cooking time.
- Remember that the quantity of food affects cooking time. Larger quantities or sizes will increase cooking time; smaller amounts will cook in less time.

APPETIZERS & SNACKS

Food	Settings	Time	Pieces	Temperature	Pan
Cheese Sticks	U= 10, L=03, M= 03	4:30	8	Frozen, Precooked	Black Pan
	U= 10, L=03, M= 03	6:30	24	Frozen, Precooked	Black Pan
Chicken Fingers	U= 10, L=03, M= 03	4:00	8	Frozen, Precooked	Black Pan
	U= 10, L=03, M= 03	6:00	24	Frozen, Precooked	Black Pan
Chicken Tenders	U= 10, L=03, M= 05	6:00	3 - 4	Thawed, Raw	Black Pan
	U= 10, L=03, M= 05	8:00	5 - 6	Thawed, Raw	Black Pan
Wings	U= 05, L=04, M= 10	4:00	8	Frozen, Precooked	Black Pan
	U= 05, L=04, M= 10	8:00	24	Frozen, Precooked	Black Pan
Egg Rolls	U= 10, L=01, M= 08	3:30	1 - 2	Frozen, Precooked	Black Pan
	U= 10, L=01, M= 08	5:00	6	Frozen, Precooked	Black Pan
Jalapeno Poppers	U= 10, L=03, M= 03	4:30	8	Frozen, Precooked	Black Pan
	U= 10, L=03, M= 03	6:30	24	Frozen, Precooked	Black Pan
Nachos	U= 10, L=03, M= 03	2:00		Standard, Thawed	Black Pan
Onion Rings	U= 10, L=06, M= 05	5:00		Frozen, Precooked	Black Pan
Potato Skins	U= 07, L=03, M= 04	5:00		Frozen, Precooked	Black Pan
Soft Pretzels	U= 10, L=10, M= 10	1:00	1 - 2	Frozen, Precooked	Black Pan
	U= 10, L=10, M= 10	1:30	3 - 4	Frozen, Precooked	Black Pan
Stuffed Mushrooms	U= 10, L=03, M= 03	4:30	8	Frozen, Precooked	Black Pan
	U= 10, L=03, M= 03	6:30	24	Frozen, Precooked	Black Pan

BAKED GOODS

Bagel Reheat	U= 10, L=10, M= 00	2:00		Thawed	Black Pan
Biscuits	U= 08, L=04, M= 02	5:45	8 Small	Thawed	Black Pan
	U= 07, L=04, M= 02	6:45	8 Large	Thawed	Black Pan
Cinnamon Rolls	U= 08, L=03, M= 02	4:45	Small	Thawed	Black Pan
	U= 07, L=03, M= 02	7:00	Large	Thawed	Black Pan
Cookie Dough	U= 07, L=01, M= 01	7:30		Frozen	Black Pan
Pastry Reheat	U= 10, L=10, M= 05	:30	1 - 3	Thawed	Black Pan
	U= 10, L=10, M= 05	1:00	4 - 5	Thawed	Black Pan
Turnovers	U= 06, L=01, M= 02	10:00	2	Frozen	Black Pan
	U= 06, L=01, M= 02	12:00	4	Frozen	Black Pan

BREAKFAST

Food	Settings	Time	Pieces	Temperature	Pan
Breakfast Burrito	U= 10, L=08, M= 09	2:00	1	Frozen	Black Pan
	U= 10, L=08, M= 09	3:00	3	Frozen	Black Pan
Breakfast Pizza	U= 10, L=04, M= 05	3:30	1	Frozen	Black Pan
	U= 10, L=04, M= 05	6:00	4	Frozen	Black Pan
Breakfast Sandwich	U= 08, L=06, M= 10	2:30	1	Frozen	Black Pan
	U= 08, L=06, M= 10	3:30	3	Frozen	Black Pan
French Toast	U= 10, L=05, M= 08	2:30	1 - 2	Frozen	Black Pan
	U= 10, L=05, M= 08	3:30	3 - 4	Frozen	Black Pan
Pancakes	U= 10, L=05, M= 08	1:00	2	Frozen	Black Pan
	U= 10, L=05, M= 08	1:30	3 - 5	Frozen	Black Pan
Sausage Links	U= 10, L=10, M= 03	3:00	4 - 6	Frozen	Black Pan
	U= 10, L=05, M= 05	6:00	40	Frozen	Black Pan

CHICKEN

Chicken (Bone in)	U= 10, L=05, M= 10	6:00	2 - 3	Thawed, Raw	Black Pan
	U= 10, L=05, M= 10	8:00	4 - 5	Thawed, Raw	Black Pan
	U= 10, L=05, M= 10	14:00	8	Thawed, Raw	Black Pan
Boneless Breasts (5+ oz)	U= 10, L=10, M= 02	8:00	1 - 2	Thawed, Raw	Black Pan
	U= 10, L=10, M= 02	9:00	3 - 4	Thawed, Raw	Black Pan
Breaded	U= 10, L=03, M= 05	5:00	1 - 2	Frozen, Precooked	Black Pan
	U= 10, L=03, M= 05	6:00	3 - 4	Frozen, Precooked	Black Pan
Fried Chicken	U= 10, L=05, M= 10	3:00	2	Frozen, Precooked	Black Pan
	U= 10, L=05, M= 10	4:00	3	Frozen, Precooked	Black Pan
	U= 10, L=05, M= 10	4:30	4 - 5	Frozen, Precooked	Black Pan
	U= 10, L=05, M= 10	7:30	6 - 8	Frozen, Precooked	Black Pan
Stuffed Breast (5+ oz)	U= 08, L=02, M= 07	10:00		Frozen, Raw	Black Pan
Whole Chicken 2 to 3 lbs. 4 to 5 lbs.	U= 05, L=05, M= 10	20:00		Thawed, Raw	Glass Dish
	U= 05, L=05, M= 10	25:00		Thawed, Raw	Glass Dish

FISH & SEAFOOD

Food	Settings	Time	Pieces	Temperature	Pan
Breaded Fish	U= 10, L=05, M= 03	3:30	1	Frozen	Black Pan
	U= 10, L=05, M= 03	6:00	4	Frozen	Black Pan
Salmon Steaks	U= 10, L=10, M= 05	5:00	1	Thawed	Black Pan
	U= 10, L=10, M= 05	9:00	4	Thawed	Black Pan
Shell Fish					
Bay Scallops	U= 10, L=10, M= 00	6:00	1 Cup	Thawed	Black Pan
Sea Scallops	U= 10, L=10, M= 00	7:00	10 Ct.	Thawed	Black Pan
Shrimp	U= 10, L=10, M= 10	1:30	1/2 lb.	Thawed	Black Pan
	U= 10, L=10, M= 10	2:00	1 lb.	Thawed	Black Pan
Tuna Steaks					
1/2" thick	U= 10, L=10, M= 00	4:00	1	Thawed, Raw	Black Pan
	U= 10, L=10, M= 00	5:00	2	Thawed, Raw	Black Pan
1" thick	U= 10, L=10, M= 00	6:00	1	Thawed, Raw	Black Pan
	U= 10, L=10, M= 00	9:00	3	Thawed, Raw	Black Pan
Whitefish Fillets					
Medium Fillet	U= 10, L=10, M= 00	5:00	1	Thawed, Raw	Black Pan
	U= 10, L=10, M= 00	6:00	2	Thawed, Raw	Black Pan
Large Fillet	U= 10, L=10, M= 00	7:00	1	Thawed, Raw	Black Pan
	U= 10, L=10, M= 00	8:00	2	Thawed, Raw	Black Pan

MEATS

Food	Settings	Time	Pieces	Temperature	Pan
Filet Mignon					
1" Medium	U= 10, L=10, M= 03	5:00	1 - 2	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	4:30	1 - 2		
1" Medium	U= 10, L=10, M= 03	5:15	3	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	6:00	3		
1" Medium	U= 10, L=10, M= 03	6:30	4	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	7:00	4		
1 1/2" Medium	U= 10, L=10, M= 05	7:00	1	Thawed, Raw	Black Pan
1 1/2" Well Done	U= 10, L=10, M= 05	8:00	1		
1 1/2" Medium	U= 10, L=10, M= 05	8:00	2	Thawed, Raw	Black Pan
1 1/2" Well Done	U= 10, L=10, M= 05	8:30	2		
1 1/2" Medium	U= 10, L=10, M= 05	9:00	3	Thawed, Raw	Black Pan
1 1/2" Well Done	U= 10, L=10, M= 05	10:00	3		
1 1/2" Medium	U= 10, L=10, M= 05	10:00	4	Thawed, Raw	Black Pan
1 1/2" Well Done	U= 10, L=10, M= 05	12:00	4		
Hamburger	U= 10, L=10, M= 10	2:30	1	Frozen, Precooked	Black Pan
	U= 10, L=10, M= 10	3:30	2 - 3		
Steaks - Ribeye					
1/2" Medium	U= 10, L=10, M= 05	4:00	1	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 05	5:00	1		
1/2" Medium	U= 10, L=10, M= 05	5:00	2	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 05	6:00	2		
3/4" Medium	U= 10, L=10, M= 05	5:00	1	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 05	6:00	1		
3/4" Medium	U= 10, L=10, M= 05	6:00	2	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 05	7:00	2		
1" Medium	U= 10, L=10, M= 05	6:00	1	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	7:00	1		
1" Medium	U= 10, L=10, M= 05	7:00	2	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	9:00	2		

MEATS

Food	Settings	Time	Pieces	Temperature	Pan
Sirloin					
1/2" Medium	U= 10, L=10, M= 00	4:00	1	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 00	5:00	1		
1/2" Medium	U= 10, L=10, M= 00	5:00	2	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 00	6:00	2		
3/4" Medium	U= 10, L=10, M= 00	6:00	1	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 00	7:00	1		
3/4" Medium	U= 10, L=10, M= 00	8:00	2	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 00	9:00	2		
1" Medium	U= 10, L=10, M= 03	8:00	1	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 03	9:00	1		
1" Medium	U= 10, L=10, M= 03	9:00	2	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 03	10:00	2		
Strip					
1/2" Medium	U= 10, L=10, M= 00	5:00	1	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 00	6:00	1		
1/2" Medium	U= 10, L=10, M= 00	5:00	2	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 00	6:00	2		
3/4" Medium	U= 10, L=10, M= 05	5:00	1	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 05	6:00	1		
3/4" Medium	U= 10, L=10, M= 05	6:00	2	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 05	7:00	2		
1" Medium	U= 10, L=10, M= 05	7:00	1	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	8:00	1		
1" Medium	U= 10, L=10, M= 05	8:00	2	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	9:00	2		

MEATS

Food	Settings	Time	Pieces	Temperature	Pan
T-Bone					
1/2" Medium	U= 10, L=10, M= 05	6:00	1	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 05	7:00	1	Thawed, Raw	Black Pan
1/2" Medium	U= 10, L=10, M= 05	7:00	2	Thawed, Raw	Black Pan
1/2" Well Done	U= 10, L=10, M= 05	8:00	2	Thawed, Raw	Black Pan
3/4" Medium	U= 10, L=10, M= 05	9:00	1	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 05	10:00	1	Thawed, Raw	Black Pan
3/4" Medium	U= 10, L=10, M= 05	10:00	2	Thawed, Raw	Black Pan
3/4" Well Done	U= 10, L=10, M= 05	11:00	2	Thawed, Raw	Black Pan
1" Medium	U= 10, L=10, M= 05	9:00	1	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	10:00	1	Thawed, Raw	Black Pan
1" Medium	U= 10, L=10, M= 05	11:00	2	Thawed, Raw	Black Pan
1" Well Done	U= 10, L=10, M= 05	12:00	2	Thawed, Raw	Black Pan

PASTA

Lasagna	U= 05, L= 03, M= 10	2:00	21 oz.	Frozen	Ceramic Dish
	U= 10, L=03, M= 10	6:30		Thawed	Ceramic Dish

PIZZA

Deep Dish 5"	U= 10, L= 04, M= 05	5:00	1 - 2	Frozen	Black Pan
	U= 10, L= 04, M= 05	6:00	3 - 4	Frozen	Black Pan
Par-baked 6" Crust	U= 08, L= 03, M= 02	5:30	1	Thawed	Black Pan
	U= 08, L= 03, M= 02	6:30	2	Thawed	Black Pan
Par-baked 12" Crust	U= 08, L= 04, M= 02	8:00	Regular	Thawed	Black Pan
	U= 08, L= 04, M= 02	10:30	Heavy	Thawed	Black Pan
Rising Crust	U= 08, L= 07, M= 02	8:00	Small 8"	Thawed	Black Pan
	U= 08, L= 07, M= 02	11:00	Large 12"	Thawed	Black Pan

SANDWICHES

Food	Settings	Time	Pieces	Temperature	Pan
Burritos	U= 10, L=00, M= 10	3:30	1	Frozen	Black Pan
	U= 10, L=00, M= 10	8:00	4	Frozen	Black Pan
Burger & Bun	U= 08, L=06, M= 10	2:30	1	Frozen	Black Pan
	U= 08, L=06, M= 10	3:30	3	Frozen	Black Pan
Corn Dogs	U= 10, L=01, M= 03	4:00	1	Frozen	Black Pan
	U= 10, L=01, M= 03	6:00	4	Frozen	Black Pan
Grilled Meat Cheese	U= 08, L=08, M= 00	4:15	1	Thawed	Black Pan
	U= 08, L=08, M= 00	5:15	4	Thawed	Black Pan
Hot Sub	U= 10, L=06, M= 03	1:15	1	Thawed	Black Pan
	U= 10, L=06, M= 03	2:00	4	Thawed	Black Pan
Pocket Sandwiches	U= 07, L=03, M= 08	2:15	1	Frozen	Black Pan
	U= 07, L=03, M= 08	4:45	4	Frozen	Black Pan

SIDE DISHES

Baked Potatoes	7 - 9 oz. Med.	U= 10, L=05, M= 10	6:00	1 - 2	Thawed	Black Pan
	7 - 9 oz. Med.	U= 10, L=05, M= 10	10:00	4 - 5	Thawed	Black Pan
	10 + oz. Lg.	U= 10, L=05, M= 10	8:00	1 - 2	Thawed	Black Pan
	10 + oz. Lg.	U= 10, L=05, M= 10	11:00	4 - 5	Thawed	Black Pan
Breadsticks	U= 08, L=03, M= 02	6:30	4 - 6	Thawed	Black Pan	
French Fries (Regular)	U= 09, L=01, M= 07	4:30	1 - Serving	Frozen	Black Pan	
	U= 09, L=01, M= 07	7:30	4 - Serving	Frozen	Black Pan	
Steak Fries	U= 10, L=04, M= 03	7:00	1 - Serving	Frozen	Black Pan	
	U=10, L= 04, M= 03	9:00	4 - Serving	Frozen	Black Pan	
Texas Toast	U= 08, L=08, M= 03	3:00	1	Frozen	Black Pan	
	U=08, L= 08, M= 03	5:30	3 - 4	Frozen	Black Pan	

NOTES