

Water-cooled Medium Temperature

Increased charge R-290 (Propane) Refrigerant

microDS™

Installation, Operation, and Service Manual

ID5SL4WE | ID5SL6WE | ID5SL8WE | ID5SL12WE
ID6SU4WE | ID6SU6WE | ID6SU8WE | ID6SU12WE
IDD6SU4WE | IDD6SU6WE | IDD6SU8WE | IDD6SU12WE



IDD6SUWE

WARNINGS:

- » If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage, personal injury or death.
- » Installation and service must be performed by a qualified installer or service agency only as recommended by the manufacturer.
- » **READ THE ENTIRE MANUAL BEFORE INSTALLING OR USING THIS EQUIPMENT.**
- » The unit uses R-290 gas as the refrigerant. R-290 is flammable and heavier than air. It collects first in low areas but can be circulated by the fans. If propane gas is present or even suspected, do not allow untrained personnel to attempt to find the cause. The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas. If a leak is detected, immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred. Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store. No open flames, cigarettes, or other possible sources of ignition should be used inside or in the vicinity of the units.
- » **FAILURE TO ABIDE BY THIS WARNING COULD RESULT IN AN EXPLOSION, DEATH, INJURY AND PROPERTY DAMAGE.**

INSIGHT® Multideck Self-Contained

February 2026
P/N 3228555_C
Spanish P/N 3228556
French P/N 3228509

TABLE OF CONTENTS

BEFORE YOU BEGIN	IV
Legal Disclaimer	iv
ANSI Z535.5 Definitions	iv
Proposition 65	iv
User Safety and Product Information	v
Installation Tool List	ix

INSTALLATION	1-1
UL Listing	1-1
Federal / State Regulation	1-1
Location	1-1
Product Temperatures	1-1
Shipping Damage	1-2
Unloading	1-2
Exterior Loading	1-2
Unloading using a pallet jack	1-2
Optional Casters and Dollies	1-2
Serial Label Location	1-3
QR Code	1-3
Merchandisers Shipped with End Installed	1-3
End Shipping Braces	1-4
Shipping Rider	1-4
Case Leveling	1-5
Case Lineup Leveling	1-5
Joining Open Case in a Lineup	1-6
Apply Gaskets - Multideck	1-7
Case Joining - Multideck	1-8
Joining Doored Cases - Applying Gaskets	1-11
Doored Case Joining	1-12
Doors - Installing, Removing, Adjusting	1-14
Adjusting EcoVision Doors	1-14
Adjusting Door Closing Speed	1-15
Replacing LED Mullion Light Bars	1-15
Sealing Lineup Joints (all cases)	1-16
Installing End Assemblies	1-17
Case Solid End Installation	1-18
Case View End Installation	1-19
Partition Hardware	1-20
Same Case Partitions	1-21
Different Case Partitions	1-23

Acrylic Partition Hardware	1-26
Acrylic Partitions - Multideck	1-27
Installing Bumpers	1-28
Installing Night Blinds	1-29
Loading Blind Spring	1-31
Troubleshooting Night Blinds	1-32

ELECTRICAL / CONTROLLER / WATER/ REFRIGERATION.. 2-1

Refrigerant	2-1
Electrical	2-2
Field Wiring	2-2
Plug and Outlet	2-2
Case Electronic Controller	2-3
Control Operation	2-4
Before Beginning Any Service or Repair:	2-12
Leak Detection	2-13
Replacing Refrigeration System Components	2-14
Charging	2-14
Water - (For Condensers)	2-15
Inhibited Propylene Glycol System Requirements	2-16
Piping Requirements	2-16
Pre-Installation System Cleaning	2-17
Top Mounted Water & Electrical Connections	2-18
Refrigeration	2-20
Condensing Unit Access	2-20
Identification of Wiring	2-21
Sensor Location	2-21
Electrical access for sign-ready & flat-front fascias	2-22

DRIP PIPING / FIT & FINISH / SPLASHGUARDS..... 3-1

Waste Outlet and Water Seal	3-1
Installing Drip Piping	3-2
Flush Floor Drip Piping Example for Ultra Low Front Cases	3-3
Optional Waste Outlet Drip Piping Example for Ultra Low Front Cases ..	3-4
Final Alignment / Fit & Finish	3-7
Installing End Splashguards	3-10
Installing Splashguard Brackets	3-12
Installing Splashguards	3-13

TABLE OF CONTENTS (CONTINUED)

STARTUP / OPERATION..... 4-1

Start Up.....	4-1
Load Limits	4-7
Stocking	4-7
Shelf Maximum Weight Limits.....	4-8
Multideck Shelf Configuration.....	4-8
Installing CaseShieldPTM(s) (Optional)	4-9
LED Fixtures	4-10
Procedure for Installing Lighted Shelves.....	4-10
Installing FDA/NSF Required Thermometer	4-13

MAINTENANCE AND SERVICE 5-1

General Safety Instructions	5-1
Identification of Case Parts	5-2
Care and Cleaning	5-3
Exterior Surfaces	5-4
Interior Surfaces	5-4
Recommended Cleaning Instructions.....	5-5
Cleaning Honeycomb Assemblies	5-6
Cleaning Mirrors	5-6
Removing Interior Back Panels.....	5-7
Cleaning Under Merchandisers.....	5-7
Cleaning Coils	5-7
Cleaning Stainless Steel Front Rails	5-7
Removing Scratches from Bumper	5-7
Before Beginning Any Service or Repair:	5-8
Service and Repair.....	5-9
Checks to Electrical Devices.....	5-10
Repairs to Sealed Components	5-10
Repair to Intrinsically Safe Components.....	5-11
Cabling.....	5-11
Detection of flammable refrigerants	5-11
Refrigerant Removal and Evacuation	5-12
Refrigerant Recovery.....	5-12
Steps to Recover Refrigerant	5-13
Cleaning and Flushing	5-13

Replacing Filter Drier and Capillary Tube	5-13
Refrigerant Charging Procedure	5-14
Bottom Liner Repair	5-15
Troubleshooting.....	5-16
Troubleshooting Continued	5-17
Replacing Fan Motors	5-18
Replacing Door Handles	5-20

DECOMMISSIONING 6-1

Decommissioning	6-1
Warranty	7-1
Revision History.....	7-1

BEFORE YOU BEGIN

READ THESE INSTRUCTIONS COMPLETELY AND CAREFULLY.

LEGAL DISCLAIMER

Review all safety warnings on the case and in this manual before attempting start-up. Hussmann shall not be liable for any repair or replacement made without the written consent of Hussmann, or when the product is installed or operated in a manner contrary to the printed instructions covering installation and service which accompanied such product. Please note that failure to follow the instructions in this document may void your factory warranty.

ANSI Z535.5 DEFINITIONS

The definitions below are used to clarify the magnitude and urgency of harm and damage, considering problems arising from misuse. Relative to their potential danger, the definitions are divided into five parts according to ANSI Z535 Series.

 **DANGER**

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

 **WARNING**

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

 **CAUTION**

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to personal injury.

**SAFETY
INSTRUCTIONS**

Safety instructions (or equivalent) signs indicate specific safety-related instructions or procedures.

PROPOSITION 65



This warning does not mean that Hussmann products will cause cancer or reproductive harm, or is in violation of any product-safety standards or requirements. As clarified by the California State Government, Proposition 65 can be considered more of a 'right to know' law than a pure product safety law. When used as designed, Hussmann believes that our products are not harmful. We provide the Proposition 65 warning to stay in compliance with California State law.

It is your responsibility to provide accurate Proposition 65 warning labels to your customers when necessary. For more information on Proposition 65, please visit the California State Government Website.

USER SAFETY AND PRODUCT INFORMATION

General Safety Instructions

SAFETY INSTRUCTIONS

This manual was written in accordance with originally prescribed equipment that is subject to change. Hussmann reserves the right to change or revise specifications and product design in connection with any feature of our products.

Personal Protection Equipment (PPE) is required. Wear safety glasses, gloves, protective boots or shoes, long pants, and a long-sleeve shirt when working with this equipment and while handling glass.



The safety of our customers and employees is paramount. The precautions and procedures described in this manual are intended as general methods for safe use of this equipment. Please be sure to comply with the precautions described in this manual to protect you and others from possible harm. Always follow OSHA standards for safety.

Only qualified personnel should install and service this equipment. Personal Protection Equipment (PPE) is required. Wear safety glasses, gloves, protective boots or shoes, long pants, and a long-sleeve shirt when working with this equipment and while handling glass.

Observe all precautions on tags, stickers, labels and literature provided and referenced for this equipment. Use only Hussmann approved parts approved through the Hussmann Performance Parts Website. Verify that all repair parts are identical models to the ones they are replacing. Do not substitute parts such as motors, switches, relays, heaters, compressors, power supplies, or solenoids.

Read all safety information regarding the safe handling of refrigerant and refrigerant oil, including the Material Safety Data Sheet. MSDS sheets can be obtained from your refrigerant supplier. Service is to be performed by factory-authorized service personnel, so as to minimize the risk of possible injury due to incorrect parts or improper service. Contact your Hussmann representative to arrange servicing.

1. If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage, personal injury or death. Observe all precautions on tags, stickers, labels and literature attached to this equipment.
2. Installation and service must be performed by a qualified installer or service agency.
3. This unit is designed only for use with R-290 gas as the designated refrigerant.

DANGER



- DANGER—Risk of fire or explosion. Flammable refrigerant used. To be repaired only by trained service personnel. Do not puncture refrigerant tubing.
- DANGER – Risk of fire or explosion due to flammable refrigerant used. Follow handling instructions carefully in compliance with national regulations.
- Failure to follow instructions can result in an explosion, death, injury and property damage.
- A3 flammable refrigerant is used in this unit.

READ THE ENTIRE MANUAL BEFORE INSTALLING OR USING THIS EQUIPMENT

- Installation and service must be performed by a qualified installer or service agency only as recommended by the manufacturer.
- The refrigerant loop is sealed. Only a qualified and authorized technician should attempt to service.
- Propane is flammable and heavier than air. It collects first in the low areas but can be circulated by fans.
- The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas. If R-290 is present or even suspected, do not allow untrained personnel to attempt to find the cause.
- If a leak is detected, immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred. Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store.
- A hand-held propane leak detector (“sniffer”) will be used before any repair and/or maintenance.
- No open flames, cigarettes, or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all propane has been cleared from the area and from the refrigeration systems.
- Excessive ambient conditions may cause condensation and sweating on doors. Facility operators are responsible for monitoring doors and floor conditions and ensuring the safety of all persons present.
- WARNING—Keep clear of obstruction, all ventilation openings in the appliance enclosure or in the structure for build-in.
- WARNING—Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- WARNING—Do not damage the refrigerating circuit.
- WARNING—Do not use electrical appliances inside the food storage compartments unless they are the type recommended by the manufacturer.
- WARNING—In order to reduce flammability hazards the installation of this appliance must only be carried out by a suitably qualified person.
- Do not use any means to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.

WARNING

- **WARNING—Risk Of Fire** – Auxiliary devices which may be ignition sources shall not be installed in the ductwork, other than auxiliary devices listed for use with the specific appliance.
- Do not store items or flammable materials atop the unit. Do not walk on case.
- Do not store explosive substances, such as aerosol cans with flammable propellant, in this appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the (optional) supply cord is damaged, it must be replaced by the manufacturer, its service agents or similarly qualified persons in order to avoid hazard.
- Component parts are designed for propane and are non-incendive and non-sparking. Component parts shall be replaced with like components, and servicing shall be done by factory authorized service personnel only, so as to minimize the risk of possible ignition due to incorrect parts or improper service.
- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer. Other parts can result in the ignition of refrigerant in the atmosphere from a leak.
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- Precautions shall be taken to avoid excessive vibration or pulsation.
- Any insulation shall be suitable for use with the material being insulated.
- Protection devices, piping, and fittings shall be protected as far as possible against adverse environmental effects, for example, the danger of water collecting and freezing in relief pipes or the accumulation of dirt and debris.

CAUTION

- Do NOT block air vents. Obstructing air vents will affect case performance, which could potentially lead to case failure.
- Do NOT use HOT water on cold glass surfaces. This can cause the glass to shatter and could result in personal injury. Allow glass fronts, to warm before applying hot water.
- Do NOT allow cleaning agent or cloth to contact food product.
- Product will be degraded and may spoil if allowed to sit in a non-refrigerated area.

WARNING



- **WARNING**—Risk of fire or explosion. Flammable refrigerant used. To be repaired only by trained service personnel. Do not puncture refrigerant tubing.
- **WARNING**—Risk Of Fire. Dispose Of Properly In Accordance With Federal Or Local Regulations. Flammable Refrigerant Used.
- **WARNING**—Risk Of Fire. Flammable Refrigerant Used. Consult Repair Manual/Owner's Guide Before Attempting To Service This Product. All Safety Precautions Must Be Followed.
- **WARNING**—Risk of Fire due to Flammable Refrigerant Used. Follow Handling Instructions Carefully in Compliance with National Regulations.
- **WARNING**—Risk Of Fire or Explosion – Store in a well ventilated room without continuously operating flames or other potential ignition.
- **WARNING**—Risk Of Fire Or Explosion – Auxiliary devices which may be ignition sources shall not be installed in the ductwork, other than auxiliary devices listed for use with the specific appliance. See instructions.
- Installation and service must be performed by a qualified installer or service agency only as recommended by the manufacturer.
- Only a qualified and authorized technician should attempt to service.
- A hand-held leak detector (“sniffer”) will be used before any repair and/or maintenance.
- No open flames, cigarettes, or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all propane has been cleared from the area and from the refrigeration systems.
- Excessive ambient conditions may cause condensation and sweating on doors. Facility operators are responsible for monitoring doors and floor conditions and ensuring the safety of all persons present.
- **WARNING**—Keep clear of obstruction, all ventilation openings in the appliance enclosure or in the structure for build-in.
- **WARNING**—Do not use electrical appliances inside the food storage compartments of the case(s).

INSTALLATION TOOL LIST

Unloading refrigerated merchandiser from trailer:

- Lever Bar (also known as a Mule,
- Johnson Bar (J-bar)/
- Moving Dolly(s)/Pallet Jack

Setting Case Line-Up:

- Level, 4 ft (suggested)
- Ratchet
- ¼" Socket Drill Bit
- ⅝" Socket Drill Bit
- ½" Socket - Deep Drill Bit
- ½" Open End Wrench
- Cordless Impact Drill
- Caulking Gun
- 10" Adjustable Crescent Wrench

INSTALLATION

UL LISTING

These merchandisers are manufactured to meet UL 60335-2-89 standard requirements for safety. Proper installation is required to maintain this listing. This appliance is to be installed in accordance with the Safety Standard for Refrigeration Systems, ANSI/ASHRAE 15.

FEDERAL / STATE REGULATION

These merchandisers at the time they are manufactured, meet all federal and state/provincial regulations. Proper installation is required to ensure these standards are maintained. Near the serial label, each case carries a label identifying the environment (temperature and relative humidity) for which the case was designed for use.

LOCATION

These merchandisers are designed for displaying products in air conditioned stores where temperature is maintained at or below the ANSI/NSF-7 specified level and relative humidity is maintained at or below 55%. Placing refrigerated merchandisers in direct sunlight, near hot tables or near other heat sources could impair their efficiency.

Like other display cases, these are sensitive to air disturbances. Air currents passing around cases will seriously impair their operation. Do not allow air conditioning, electric fans, open doors or windows, etc. to create air currents around the cases.



≥A m²

Minimum floor room area

To prevent a hazardous refrigerant concentration in the event of a leak, merchandisers must be installed in a room with adequate floor space. Note that these required areas are not cumulative.

Refrigerant Charge			Minimum Floor Area	
Case	grams	ounces	meters ²	feet ²
ID5SL4WE	200	7.1	236	255
ID5SL6WE	300	10.6	236	255
ID5SL8WE	400	14.1	236	255
ID5SL12WE	494	17.4	236	255
ID6SU4WE	200	7.1	236	255
ID6SU6WE	300	10.6	236	255
ID6SU8WE	400	14.1	236	255
ID6SU12WE	494	17.4	236	255
IDD6SU4WE	100	3.5	236	255
IDD6SU6WE	150	5.3	236	255
IDD6SU8WE	200	7.1	236	255
IDD6SU12WE	250	8.8	236	255

Do not install merchandisers in public corridors or lobbies, regardless of room area. Merchandisers are not intended to be used at altitudes exceeding 6,562 ft (2,000 m).

PRODUCT TEMPERATURES

Product should always be maintained at proper temperature. This means that from the time the product is received, through storage, preparation and display, the temperature of the product must be controlled to maximize product life.

A 1 1/2-in (38 mm) space between the rear of the merchandiser and wall must be maintained for air circulation. However, in high ambient conditions, sweating may still occur. If this happens install a method of forced ventilation such as a fan ventilation kit.

SHIPPING DAMAGE

All equipment should be thoroughly examined for shipping damage before and during unloading. This equipment has been carefully inspected at our factory. Any claim for loss or damage must be made to the carrier. The carrier will provide any necessary inspection reports and/or claim forms.

Apparent Loss or Damage

If there is an obvious loss or damage, it must be noted on the freight bill or express receipt and signed by the carrier's agent; otherwise, carrier may refuse claim. The carrier will supply necessary forms.

Concealed Loss or Damage

When loss or damage is not apparent until after equipment is uncrated, a claim for concealed damage is made. Upon discovering damage, make request in writing to carrier for inspection within 15 days and retain all packing. The carrier will supply inspection report and required claim forms.


UNLOADING

Improper handling may cause damage to the merchandiser when unloading. Use the shipping brace and arched pod locations to lift when unloading cases.

1. Do not drag the merchandiser out of the trailer. Use a Johnson bar (mule).
2. Do not lift the case by the liner. Lift with the metal case base, arched plastic pods or the shipping brace.
3. Do not lift from the bottom edge of the end panel.

⚠ WARNING

- » If the case is to be moved using a fork lift, position the forks of the lift directly under the arched pods or shipping rails. Use extreme caution when transporting cases. Personal injury or death could result if a case falls on personnel.



LIFT HERE

EXTERIOR LOADING

Do not walk on top of case(s) or damage to the case(s) and serious personal injury could occur. They are not structurally designed to support excessive external loading such as the weight of a person. Use caution when working around refrigeration lines or water lines, damage to equipment and personal injury could occur.

⚠ WARNING

- » Do not walk on case. Do not store items or flammable materials atop the case.

UNLOADING USING A PALLET JACK

A pallet jack is also very helpful in moving a merchandiser to its permanent location. It can also be used to remove optional casters or to shim the case.




⚠ WARNING

- » Use caution when moving cases with casters or dollies. Damage to equipment and personal injury could occur from improper handling.

OPTIONAL CASTERS AND DOLLIES

Cases may be equipped with factory installed casters or dollies. Instructions for removing the casters or dollies are included in a separate document, shipped with the case. Use caution when transporting cases from the truck to the store location.



Case Caster

⚠ WARNING


- » Use caution when working around refrigeration lines or water lines. Damage to equipment and/or personal injury could occur.

SERIAL LABEL LOCATION


Serial labels are located on the left side, facing the case. The serial label contains all pertinent information such as model, serial number, amperage rating, refrigerant type, and charge.

NOTE:

A second serial label for multi-deck cases is also located behind the return air grille in the same location as single-deck cases (shown below).



Serial Label inside
Canopy (multideck)



Serial Label behind
return air grille
(single-deck)

ATTENTION

Merchandiser must operate for 24 hours before loading product!

Regularly check merchandiser temperatures. Do not break the cold chain. Keep products in cooler or freezer before loading into merchandiser.


Medium temperature merchandisers are designed for loading ONLY pre-chilled products.

Low temperature merchandisers are designed for loading ONLY frozen products.



QR CODE

Insight cases have a QR code located on the serial label(s). Once you scan the QR code with a smart phone, all of the information about that case will be at your fingertips. Links to installation videos, data sheets with case specifications, the installation and operation manual, as well as a link to replacement parts from Hussmann's Performance Parts Website.



MERCHANDISERS SHIPPED WITH END INSTALLED

If the merchandiser was shipped with the end installed, two long bolts were used to hold the shipping brace to the end. If the shipping bolts are reinserted after removing the brace, they will extend into the product area. Therefore, be sure to replace these bolts with the shorter bolts provided. NSF requires any bolt or screw in the product area be capped or cut off if it has more than three exposed threads.

Be careful not to damage the factory installed end while moving the merchandiser.



Be careful not to damage the factory installed end while moving the merchandiser.


END SHIPPING BRACES

Move the merchandiser as close as possible to its permanent location, then remove all packaging. Check for damage before discarding packaging. Remove all separately packed accessories such as kits and shelves.


Do not remove end braces until joining begins. Recycle wooden braces and hardware.

⚠ CAUTION

- » Do not remove shipping braces until the merchandisers are positioned for installation.



Remove 6 Screws and Wooden Supports Prior to Moving Case into Position (rear rail will remain attached to merchandiser)



⚠ CAUTION

- » Tipping Hazard! Case tipping may occur if cases are not properly leveled and secured, or if cases are not properly loaded.

CASE LEVELING



Merchandisers must be installed level to ensure proper operation of the refrigeration system and to ensure proper drainage of defrost water. Pay close attention to case position during all steps of setting, joining and leveling.

NOTE:

Begin lineup leveling from the highest point of the store floor.

Preparation:

1. Using store blueprints, measure off and mark on floor the exact dimensions/locations of the merchandiser footprint. A 2-inch space is required behind each merchandiser to prevent condensation.
2. Snap a chalk line for the front and rear positions of the base pods.
3. Mark the location of each joint from front to back lines.
4. Use supplied shims to level case. Shims are to be inserted under the black, plastic base pods.



CASE LINEUP LEVELING

1. FLOORS ARE NOT LEVEL! The whole lineup must be leveled on the same plane, left to right and front to back. This means that the entire lineup must be brought up to the level of the highest case in the lineup.

Along the lines previously marked, find the highest point of the floor by:

- Walking the floor and noticing any dips or mounds;
 - Using a string level; and
 - Using a transit.
2. Position the first merchandiser at the highest point on the floor. Work outward from that point to create the merchandiser lineup.
 3. Use a 48 inch (1220 mm) or longer level for end-to-end leveling. The rear edge of the top foam panel of the merchandiser is a good location for the level at the rear of the case.
 4. For leveling the merchandiser front-to-rear, a 24 inch (610 mm) level should be placed on the lower flange of the merchandiser end frame. If the merchandiser has a factory installed end, the level should be placed on the canopy support brackets on top of the merchandiser. Suggested level locations are shown in the illustration.

JOINING OPEN CASE IN A LINEUP

JOINING AND SEALING HARDWARE	Multi Deck Qty/Each	Convertible Qty/Each	Single Deck Qty/Each	Door Multi Deck Qty/Each
SEALER SILICONE ADHESIVE	1	1	1	1
GASKET 1/2 X 1/2 X 180	2	1	1	2
SCREW-SHEET METAL #8 X 5/8 PHIL HX HD	N/A	1	N/A	N/A
SCREW-CAP 1/4 x 3/4 HEX	N/A	N/A	N/A	2
BOLT HEX CAP 5/16 x 3/4	1	1	1	1
BOLT 5/16 x 2 3/4 GRADE 5 ZINC PLATED TAP	2	N/A	N/A	2
BOLT- TAP, 5/16 x 4 1/2, STEEL, ZINC FINISH, GR5 (Qty Varies)	5	2	1	5
BOLT- TAP, 5/16 x 7, STEEL, ZINC FINISH, GR5	1	1	1	1
WASHER-FLAT 5/16" ZINC (Qty Varies)	13	5	3	13
LOCKWSHR 1/4 SPLT STL	N/A	N/A	N/A	2
LOCKWSHR 5/16 SPLT STL	1	1	1	1
NUT-HEX 1/4	N/A	N/A	N/A	2
NUT-HEX 5/16 STEEL ZINC FINISH GRADE 8 (Qty Varies)	9	4	3	9
NUT-HEX 3/8-24 SERRATED FLANGE	4	N/A	N/A	4
PIN-ALIGNMENT	1	1	1	N/A
CONE-CASE ALIGNMENT (Qty Varies)	4	2	2	4
PLATE-BOTT DOOR RAIL ALIGNMENT	N/A	N/A	N/A	1
BRACKET-CASE JOINING	4	N/A	N/A	4
BRACKET-FASCIA ALIGNMENT IC2 & IC3	N/A	1	N/A	N/A
COVER-HAND RAIL JOINT	1	1	1	N/A
TAPE-BUTYL 1/16 x 2" X 49"	1	1	1	1

IMPORTANT:

Do not pull cases together with bolts. Cases must be moved together as close as possible. Follow sequence balloons to tighten bolts.


- Apply gasket to only one side of case joint.
- Remove end shipping braces as described on Page 1-4.
- Cases must be leveled as described on Page 1-5.
- Removed any casters - if installed.
- Install case lineup from left to right.
- Remove shelves, display racks, pans & interior back panels at the joining area.
- Insert gasket into case channels the entire length with no gaps.
- Do not stretch gasket, especially around corners.
- Do not butt gaskets, always overlap them.
- Remove paper backing after gasket has been applied.
- Perimeter gasket is required by NSF.
- Apply a continuous bead of neutral curing silicone sealant.
- Joints must be air tight to prevent formation of ice of condensation.

NOTICE

It is the installing contractor's responsibility to consult local agencies for local code requirements.

NOTE:

See PAGE 1-12 for joining doored cases.



APPLY GASKETS - MULTIDECK

Multideck case bolting details begin on the next page.

LEGEND:

A = 1/2 x 1/2 INCH GASKET

B = NEUTRAL CURING SILICONE SEALANT


C = PIN-ALIGNMENT

D = COVER-HAND RAIL JOINT

IMPORTANT:

Do not pull cases together with bolts. Cases must be moved together as close as possible. Follow sequence balloons to tighten bolts.

- Apply gasket to only one side of case joint.
- Remove end shipping braces as described on Page 1-4.
- Cases must be leveled as described on Page 1-5.
- Removed any casters - if installed.
- Install case lineup from left to right.
- Remove shelves, display racks, pans & interior back panels at the joining area.
- Insert gasket into case channels the entire length with no gaps.
- Do not stretch gasket, especially around corners.
- Do not butt gaskets, always overlap them.
- Remove paper backing after gasket has been applied.
- Perimeter gasket is required by NSF.
- Apply a continuous bead of neutral curing silicone sealant.
- Joints must be air tight to prevent formation of ice condensation.





CASE JOINING - MULTIDECK

Refer to detail views

LEGEND:



C = PIN-ALIGNMENT

Do not pull cases together with bolts. Cases must be moved together as close as possible. Follow sequence balloons 1, 2, 3 to tighten bolts.



CASE JOINING - MULTIDECK

Refer to detail views





CASE JOINING MULTIDECK

Refer to detail views


LEGEND:

D = COVER-HAND RAIL JOINT

Push Cover
in this direction
to snap fit



D



JOINING DOORED CASES - APPLYING GASKETS

Case bolting details begin on the next page. Refer to Page 1-6 for hardware list.

Do not pull cases together with bolts. Cases must be moved together as close as possible. Follow sequence balloons to tighten bolts.

LEGEND:

A = 1/2 x 1/2 INCH GASKET

B = NEUTRAL CURING SILICONE SEALANT


C = PIN-ALIGNMENT

F = PLATE BOTTOM DOOR RAIL ALIGNMENT

IMPORTANT:

Do not pull cases together with bolts. Cases must be moved together as close as possible. Follow sequence balloons to tighten bolts.

- Apply gasket to only one side of case joint.
- Remove end shipping braces as described on Page 1-4.
- Cases must be leveled as described on Page 1-5.
- Removed any casters - if installed.
- Install case lineup from left to right.
- Remove shelves, display racks, pans & interior back panels at the joining area.
- Insert gasket into case channels the entire length with no gaps.
- Do not stretch gasket, especially around corners.
- Do not butt gaskets, always overlap them.
- Remove paper backing after gasket has been applied.
- Perimeter gasket is required by NSF.
- Apply a continuous bead of neutral curing silicone sealant.
- Joints must be air tight to prevent formation of ice or condensation.




DOORED CASE JOINING

LEGEND:

C=PIN-ALIGNMENT

F=PLATE-BOTT DOOR RAIL ALIGNMENT



1/4 X 3/4 CAP SCREW 11

5/16 X 4 1/2 BOLT & ALIGNMENT CONE 2


1/4 X 3/4 CAP SCREW 10

5/16 X 4 1/2 BOLT & ALIGNMENT CONE 1

F



C

5/16 X 7 BOLT & ALIGNMENT CONE 3





DOORED CASE JOINING

(Continued)



This Bolt location is optional for some installed kits.



DOORS - INSTALLING, REMOVING, ADJUSTING

- A. To install a door: Lean door back, and push pin into mullion. Ensure push pins are fully seated in canopy support bracket.
- B. To remove a door: Raise door up and lift rod bottom out of bottom hinge plate hole

ADJUSTING ECOVISION DOORS


Check that all doors open and close properly.

- A. Leveling — Merchandisers must be installed level to ensure proper operation of the refrigeration system, and to ensure proper drainage of defrost water.

Glass alignment is also affected with improper leveling of the merchandisers. All steps of setting joining and case leveling attention to the glass position is critical. Do not attempt to make glass adjustments prior to case leveling.


- B. Door Adjustment — Loosen the screws A, B and C as shown below (Do not remove the screws completely).

Slide the bottom plate left and right until proper alignment is achieved. Re-tighten the screws A, B and C. Install fasteners in locations 1 and 2 as shown below.



Excessive ambient conditions may cause condensation and therefore sweating of doors. Facility operators should monitor doors and floor conditions to ensure safety of persons.

EcoVision Door Alignment - Modular Bottom Hinge Plate




ADJUSTING DOOR CLOSING SPEED

The door's closing speed is factory adjusted, but the door may also be field adjusted.

Do the following to adjust the doors:

1. To release door tension, open the door to 90° and lift up the door from the bottom. Lift the torsion rod out of the star pattern in the bottom hinge plate. (The door should be lifted out of the star pattern in the hinge plate to prevent any damage to the star pattern.)
2. Use a ½ in. open end wrench to tighten the torsion of the door. Adjust tension with each audible click. Doors should be adjusted to 4 clicks, more if needed. Door must be properly resealed in star pattern of hinge plate after torsion tension is applied.




REPLACING LED MULLION LIGHT BARS

LED vertical mullion lights are an available lighting option for EcoVision doors. Center fixtures illuminate the middle of the case, and the end fixtures illuminate the ends, or sides of the case.

These LEDs have different shaped lenses. They are not to be interchanged. Contact your Hussmann representative to order replacements.

The light bars are attached to the door mullions with mounting clips, and can be replaced similar to the canopy lights — just remove them from the mounting clips, and connect new wires at quick connect.



SEALING LINEUP JOINTS (ALL CASES)

The joint between the two joined case must be sealed for sanitation. Apply Butyl tape across the case joint. Apply a long, continuous bead of silicone to fill any gaps between the cases.


Be sure to start from the back and go all the way to the air return as shown in the illustration below.

⚠ WARNING


» Use caution when working around refrigeration lines or water lines, damage to equipment and personal injury could occur.



IMPORTANT Fill any gaps between cases with silicone.



Apply Butyl Tape




**Apply Neutral Curing
Silicone Sealant**

**Apply Neutral Curing Silicone Sealant
in any gaps between the Case Joints.**

INSTALLING END ASSEMBLIES

Remove shipping brace. Brace screws will be replaced with shorter screws found in pack-out kit. Ensure nut retainers are in place. Apply Gaskets and Silicone to End Frame.

Apply ½ x ½ in. (12.7 mm) x (12.7 mm) gaskets into the case channels. Check that the gasket is properly inserted into the entire length of the channels with no gaps. Apply silicone between case end cap and end.



FIELD INSTALLED HARDWARE	Multi Deck Qty/Each	Convertible Qty/Each	Single Deck Qty/Each	View End Multi Deck Qty/Each
Description				
SEALER SILICONE ADHESIVE	1	1	1	1
GASKET 1/2 X 1/2 X 180	1	1	1	1
SCREW SM 10-16X3/4 HX WASHER	1	1	1	N/A
BOLT 5/16 x 2 3/4 GRADE 5 ZINC PLATED TAP*	4	2	1	5
BOLT- TAP, 5/16 x 4 1/2, STEEL, ZINC FINISH, GR5	1	1	1	1
WASHER-FLAT 5/16" ZINC*	7	4	2	8
NUT-HEX 5/16 STEEL ZINC FINISH GRADE 8*	3	2	2	4
NUT-PUSH 5/16" RETAINER STEEL ZINC*	2	1	1	2
NUT-J RETAINER 5/16"	2	1	N/A	2
BUTTON-PLUG 7/8 DIA*	5	3	2	6

*Quantities may vary depending on which type of end is to be placed on case.

IMPORTANT:

Do not pull cases together with bolts. Cases must be moved together as close as possible. Follow sequence balloons to tighten bolts.

- Apply gasket to only one side of case joint.
- Remove end shipping braces as described on Page 1-5.
- Cases must be leveled as described on Page 1-6.
- Removed any casters - if installed.
- Install case lineup from left to right.
- Remove shelves, display racks, pans & interior back panels at the joining area.
- Insert gasket into case channels the entire length with no gaps.
- Do not stretch gasket, especially around corners.
- Do not butt gaskets, always overlap them.
- Remove paper backing after gasket has been applied.
- Perimeter gasket is required by NSF.
- Apply a continuous bead of neutral curing silicone sealant.
- Joints must be air tight to prevent formation of ice of condensation.

CASE SOLID END INSTALLATION





MULTIDECK DOORED

Refer to detail views

LEGEND:

A = 1/2 x 1/2 INCH GASKET

B = NEUTRAL CURING SILICONE SEALANT



CASE VIEW END INSTALLATION





MULTIDECK DOORED

Refer to detail views

LEGEND:

A = 1/2 x 1/2 INCH GASKET






















B = NEUTRAL CURING SILICONE SEALANT



PARTITION HARDWARE

Remove shipping brace. Brace screws will be replaced with shorter screws found in packout kit. Ensure Nut Retainers are in place. Apply Gaskets and Silicone to End Frame.

Apply ½ x ½ in. (12.7 mm) x (12.7 mm) gaskets into the case channels. Check that the gasket is properly inserted into the entire length of the channels with no gaps. Apply silicone between case end cap and end.

- Screw-Sheet Metal #8 x 5/8 
- Screw-sm #10 x 3/4 Hex Washer 
- Bolt-1/4 x 1 1/2 
- Bolt-1/4 x 2 1/4 
- Bolt-1/4 x 4 
- Bolt-5/16 x 2 3/4 
- Bolt-5/16 x 4 1/2 
- Bolt-5/16 x 7 
- Bolt-5/16 x 8 
- Washer Flat-1/4 
- Washer Flat-5/16 
- Nut Hex-5/16 
- Nut Hex-3/8 Serr Flange 
- Nut-Push 5/16 
- Nut-J Retainer 
- Bracket-Case Joining 
- Bracket-Canopy (Alt Applications) 
- Bracket-Unibody (Alt Applications) 
- Button-Plug 
- Bracket-Closeoff Splashguard 
- Closeoff-Splashguard 

Description	Alt Canopy Applications	Multi Deck/Door Same Case Qty/ Each	Multi Deck/Door Different Case Qty/ Each	Convertible Different Case Qty/ Each
SEALER SILICONE ADHESIVE	Refer to Multi Deck Different Case	2	2	2
GASKET 1/2 X 1/2 X 180	Refer to Multi Deck Different Case	2	2	2
SCREW-SHEET METAL #8 X 5/8 PHIL HX HD	3 or 4	1	1	1
SCREWSM10-16X3/4 HX WASHER	1	2	2	2
BOLT HEX 1/4 x 1 1/2	Refer to Multi Deck Different Case	N/A	2	N/A
BOLT HEX 1/4 x 2 1/4*	1	N/A	2	2
BOLT HEX 1/4 x 4.0	Refer to Multi Deck Different Case	N/A	1	N/A
BOLT HEX 5/16 x 2 3/4*	Refer to Multi Deck Different Case	1	4	2
BOLT-HEX 5/16 x 4 1/2	Refer to Multi Deck Different Case	2	1	N/A
BOLT-HEX 5/16 x 7.0*	Refer to Multi Deck Different Case	2	N/A	N/A
BOLT-HEX 5/16 x 8.0	Refer to Multi Deck Different Case	1	N/A	1
WASHER-FLAT 1/4*	1	N/A	5	2
WASHER-FLAT 5/16*	Refer to Multi Deck Different Case	8	5	4
NUT-HEX 5/16*	Refer to Multi Deck Different Case	7	3	4
NUT-HEX 3/8-24 SERRATED FLANGE	1	4	2	N/A
NUT-PUSH5/16* RETAINERSTEEL ZINC*	Refer to Multi Deck Different Case	2	N/A	N/A
NUT-J RETAINERS5/16*	Refer to Multi Deck Different Case	1	2	1
BRACKET-CASE JOINING	N/A	4	2	N/A
BRACKET-CANOPY (ALT APPLICATIONS)	1	N/A	N/A	N/A
BRACKET-UNIBODY (ALT APPLICATIONS)	1	N/A	N/A	N/A
BUTTON-PLUG7/8 DIA*	Refer to Multi Deck Different Case	N/A	2	1
BRACKET-CLOSEOFF SPLASHGUARD	Refer to Multi Deck Different Case	1	1	1
CLOSEOFF-SPLASHGUARD	Refer to Multi Deck Different Case	1	1	1

*Quantities may vary depending on which type of end is to be placed on case.

IMPORTANT:

Do not pull cases together with bolts. Cases must be moved together as close as possible. Follow sequence balloons to tighten bolts.

- Apply gasket to only one side of case joint.
- Remove end shipping braces as described on Page 1-5.
- Cases must be leveled as described on Page 1-6.
- Removed any casters - if installed.
- Install case lineup from left to right.
- Remove shelves, display racks, pans & interior back panels at the joining area.
- Insert gasket into case channels the entire length with no gaps.
- Do not stretch gasket, especially around corners.
- Do not butt gaskets, always overlap them.
- Remove paper backing after gasket has been applied.
- Perimeter gasket is required by NSF.
- Apply a continuous bead of neutral curing silicone sealant.
- Joints must be air tight to prevent formation of ice condensation.

SAME CASE PARTITIONS




MULTIDECK DOORED CASES

Refer to detail views

LEGEND:

A = 1/2 x 1/2 INCH GASKET




B = NEUTRAL CURING SILICONE SEALANT



SAME CASE PARTITIONS CONTINUED

MULTIDECK DOORED CASES





Refer to detail views



DIFFERENT CASE PARTITIONS

MULTIDECK DOORED CASES






Refer to detail views



DIFFERENT CASE PARTITIONS

MULTIDECK DOORED CASES


Refer to detail views



DIFFERENT CASE PARTITIONS

MULTI DECK DOORED CASES ALTERNATIVE CANOPY APPLICATIONS CONTINUED



Refer to detail views



ACRYLIC PARTITION HARDWARE


Description	Multi Deck Qty/Each	Convertible Qty/Each
PARTITION-ACRYLIC	1	1
BRACKET-CANOPY	1	1
BRACKET-RETURNAIRGRILL	N/A	1
SCREWSM#8 x 5/8 HEX	3	4
SCREWMACHINE#8 x 1/2 PHILL	3	4
LOCKWASHER-#8 EXT TOOTH	3	4
NUT-#8 MACHINEHEX	3	4

Screw-Sheet Metal #8 x 5/8  

Screw-Machine #8 x 1/2 Phill  


Lockwasher-Ext Tooth #8  

Nut Machine Hex-#8  

Bracket-Canopy Multideck 


Bracket-Canopy Convertible 

Bracket-Return Air Grill 


Partition-Acrylic 

ACRYLIC PARTITIONS - MULTIDECK

Refer to detail views






ACRYLIC PARTITION
TO BE MOUNTED
BETWEEN TWO
CASES ATTACH
BRACKET TO ONLY
ONE CASE



INSTALLING BUMPERS

1. Bumpers are packed out with the case and snap onto the bumper retainer. Gaskets are factory installed in the bumper retainers to provide support for the bumpers. Do not remove the gaskets.
2. Bumper joint inserts are provided with the case to disguise joints for a lineup of cases.
3. Start at the left end of the lineup. Install 3ft starter bumper first. Refer to bumper side view illustration to ensure the bumper is orientated correctly. Place top of bumper over bumper retainer, then snap bottom of bumper into place at bottom of retainer. Position internal joint trim between the starter bumper and full-length bumper.
4. Continue installing bumper(s) until the lineup is complete. The last piece of bumper will need to be cut so that it is flush with the right end cap. Use a fine tooth saw to cut the bumper vertically at a 90° angle.
5. Ensure joint trim is positioned behind bumper at all joints to close any gaps in the lineup. Remove protective film from bumper once installation is complete.

NOTE Bumpers come in two styles —
Ellipse and Faceted.



INSTALLING NIGHT BLINDS

STEP 1

Slide the lefthand night blind into bracket cutout.

NOTE Left section of case always uses the front cutout. Alternate front to back for remaining sections.

STEP 2

Swing righthand side of night blind into slot on side of canopy support arm.


NOTE Left section of case always uses the bottom slot. Alternate bottom to top for remaining sections.


STEP 3

Push/pull down on night blind slightly to slide pin past detent.

STEP 4

Check pin engagement to ensure at least 3/16" of pin is firmly in the slot.





LOADING BLIND SPRING

Night blinds are delivered preloaded. However, if it is necessary to load night blind spring, use a wrench (part number [0477098](#)) to twist rectangular pin on right side of night blind. Twist clockwise 14 to 15 full revolutions.


NOTE  **Keep arrow / dot / up pointed up while winding. Keep pointed down when installed.**




Image showing wrench tightening night blind

Reference Mark (triangle or circle) must be oriented upward when winding and downward during installation.

Night Blind Handle


Twist wrench clockwise for 14 to 15 revolutions



Rectangular Pin

Night Blind

Wrench 0477098



TROUBLESHOOTING NIGHT BLINDS


If night blind is not installed:

STEP 1

Only install brackets on the lefthand support arm and each center support arm.

STEP 2

On the righthand side of each arm, insert front tab of bracket into the front slot, then snap into the rear slot.



If pin is too short or rounding out canopy arm:

STEP 1


Remove night curtain from case


STEP 2

Use pliers to pull metal pin out to desired length

STEP 3

Replace night curtain into canopy

NOTE  **Keep pointed down when installed.**



ELECTRICAL / CONTROLLER / WATER / REFRIGERATION

REFRIGERANT

This equipment uses a flammable refrigerant. Installation, service and repair should be done only by qualified and trained technicians in accordance with this manual.

If a leak is detected, follow store safety procedures. It is the store's responsibility to have a written safety procedure in place. The safety procedure must comply with all applicable codes such as local fire department's codes.

At minimum, the following actions are required:

- Immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred.
- Call Hussmann and/or a qualified service agent and inform them that a propane sensor has detected the presence of propane.
- Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store.
- The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas.
- A hand-held propane leak detector ("sniffer") should be used before any repair and/or maintenance is attempted. All repair parts must be identical models to the ones they are replacing.
- No open flames, cigarettes or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all propane has been cleared from the area and from the refrigeration systems.

DANGER

- » Due to risk of ignition resulting from incorrect parts or improper service, only Hussmann authorized personnel may service this equipment. Component parts shall be replaced only with like components. FAILURE TO USE AUTHORIZED TECHNICIANS COULD RESULT IN EXPLOSION, DEATH, INJURY AND PROPERTY DAMAGE.

WARNING

— LOCK OUT / TAG OUT —

- » To avoid serious injury or death from electrical shock, always disconnect the electrical power at the breaker when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

ATTENTION

Merchandiser must operate for 24 hours before loading product!

Regularly check merchandiser temperatures. Do not break the cold chain. Keep products in freezer before loading into merchandiser.

Medium temperature merchandisers are designed for loading ONLY pre-chilled products.

Low temperature merchandisers are designed for loading ONLY frozen products.



ELECTRICAL

These self-contained merchandisers have water-cooled condensers. Each case has a single condensing unit located on top of the case. The merchandisers are controlled by the CoreLink electronic control with power relays located inside the sealed box. Hussmann recommends a gateway for defrost coordination or setting the controller with the correct time on the clock, cases with open ends must have the same defrost times. Refer to merchandiser serial label or case data sheets for electrical information.

FIELD WIRING

Field wiring must be sized for component amperes stamped on the serial label. Actual ampere draw may be less than specified. Merchandisers require a dedicated electrical circuit with ground.

PLUG AND OUTLET





The power cord extends 96 in. (2.4 m) from the case and exits on the right hand rear of the merchandiser. When shipped, the plug end will be strapped to the front of the case. Disconnect power before servicing. These merchandisers require a dedicated electrical circuit with ground. 12AWG is the minimum sized acceptable wire.

Each **ID6SU-WE**, **ID5SL-WE**, and **IDD6SU12WE** case requires a dedicated 20 AMP, 208 VAC / 3-phase circuit / 60 Hz grounded wall receptacle (NEMA L21-20P).

Each 4, 6, and 8-foot **IDD6SU-WE** case requires a dedicated 15 AMP, 120 VAC / 1-phase circuit / 60 Hz grounded wall receptacle (NEMA 5-15P). Each 12-foot **IDD6SU-WE** cases requires a dedicated 20 AMP 208 VAC / 3-phase / 60 Hz grounded wall receptacle (NEMA L21-20P). If case was shipped with optional hardwire configuration, refer to the serial label or technical data sheet for electrical requirements.

- Always use a dedicated circuit with the amperage stated on the unit.
- Plug into an outlet designed for the plug.
- Do not overload the circuit.
- Do not use extension cords. Never use adapters.
- If in doubt, call an electrician.

Electrical Connection

Model	ID5SL4WE, ID5SL6WE, ID6SU8WE, ID5SL12WE	
NEMA Plug	L21-20P 	
Model	ID6SU4WE, ID6SU6WE, ID6SU8WE, ID6SU12WE	
NEMA Plug	L21-20P 	
Model	IDD6SU4WE, IDD6SU6WE, IDD6SU8WE, IDD6SU12WE	
NEMA Plug	5-15P 	L21-20P 

⚠ WARNING

- » If the supply cord is damaged, it must be replaced by the manufacturer, its service agents or similarly qualified persons in order to avoid hazard.
- » Do not remove the power supply cord ground.
- » To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.
- » Merchandiser must be grounded. All wiring must be in compliance with NEC and local codes.

CASE ELECTRONIC CONTROLLER

WARNING

IMPORTANT:

Disconnect electrical power before beginning any service on electrical or electronic equipment. DO NOT work around live electrical circuits. Make sure the machine is switched off before working on electrical connections. All operations must be carried out by qualified personnel.

Check that the supply voltage is correct before connecting devices. Never use power that differs from that indicated in the manual. Power supplies other than those specified can seriously damage the refrigeration system or other components and parts.

Separate the cables of the analogue inputs from those of the digital inputs and the serial line cables from the power cables (resistive as well as inductive), in order to prevent malfunction due to electromagnetic interference.

All system components should be obtained from Hussmann to ensure system compatibility and reliability. Make connections as short as possible, and do not wind them around electrically connected parts. When connecting loads, follow connection diagrams carefully.

Never connect the secondary of the supply transformer to the earth.

The low voltage connections must have reinforced insulation.

When using the digital inputs of the Corelink Case Controller use another transformer in order to prevent the digital inputs from malfunctioning or being damaged.

To avoid causing static discharge, do not touch the electronic components on the boards.

DO NOT use the same secondary of the controllers power. Doing so can result in damage to case controller.

DO NOT exceed the maximum current capacity of the onboard controller relays. Always verify the capacity of the output used.

DO NOT plug in accessory devices that are not approved by Hussmann.

DO NOT exceed the maximum current capacity of the onboard controller relays.

Always verify the capacity of the output used.

DO NOT plug in accessory devices that are not approved by Hussmann.

GND is Common(-), not earth ground. Do not earth ground this device.

Permitted Use

- Food Display Merchandisers
- Coolers
- Self-Contained
- Remote Cases

Improper Use

- HVAC
- Unspecified Installation
- Deviation from established Legislation and
- Standards

Hussmann is not responsible for misuse of device. Hussmann is not held responsible for deviation from this manual and its intended use. If you have any questions, contact your Hussmann representative for details.

In case of failure or faulty operation, send the controller back to the distributor with a detailed description of the fault.

The controller should not be used for purposes different from those described in this manual. It cannot be used as a safety device.

Case Electronic Controller

Insight self-contained R-290 cases are controlled by a CoreLink Electronic Controller for refrigeration and defrost control and control of lights and fans. The controller is factory programmed with the required parameters to safely operate the merchandiser and maintain required product temperature. There is no need to make adjustments to the controller, however, it is recommended that the program be checked at startup. Refer to the display case data sheet for discharge air temperature, setpoint, defrost cycle and other information.



CONTROL OPERATION

The case temperature is controlled by cycling the compressor ON and OFF based on the discharge air temperature for models with fixed speed compressors. Cases with variable speed compressors are controlled based on discharge air temperature and suction pressure. The case is divided into modular control sections: 4 ft cases have 1 control section, 6 ft and 8 ft cases have 2 control sections, 12 ft cases have 3 control sections.

The discharge air temperature sensor is located above the honeycomb at the center of each control section. The compressor is cycled based on an average of the discharge air sensors. The discharge air temperature varies by case model and application. Refer to the technical data sheets for more information on specific case settings. The discharge air temperature may be modified for specific product temperatures. There are two methods for accessing CoreLink:

The wireless connection kit enables connection to the CoreLink Web UI on a connected smart device, or users can use Building Automated System (BAS) to change parameters from a single, central location. For an explanation of wireless connection at the case, consult the CoreLink user manual under Web User Interface Section.

NOTE: Individual cases may be designed to run at a specific temperature setting and may not perform well at lower or higher settings, depending on such things as condenser water temperature, ambient conditions, etc.

Defrost is time-initiated, and is programmed with the correct number of defrosts per day and the correct termination. Cases are time terminated. The start time for defrost must be programmed using BAS.

Additional Safeties

CoreLink incorporates additional safeties to protect the case from critical failures in an MicroDS installation. These safeties may, or may not be installed, depending on case model. The following safeties (see next page) protect the compressors in the event of refrigerant loss, water system failure, or any other blockages of the heat exchanger. These safeties will be displayed as an alarm on the CoreLink WebUI, and the compressor will shut off. Depending on the severity and length of time of the alarm condition, the CoreLink alarm may cause the compressor to lock out and not re-start, and the alarm will need to be cleared after the cause of failure is diagnosed and repaired.

Instructions to clear the alarm and re-start the compressors will be given in the Diagnosis > Fault Sequence > Fault Code (Click on link for Fault Details popup). Generally, a reboot of the controller once the failure mode is discovered and repaired will clear the lockout.

Compressor Internal Suction Pressure Protection

The controller will alarm and disable the compressor output when a refrigerant loss occurs. In the event of a refrigerant loss, the compressor will shut off and lock out. After the condition is repaired, the alarm will be cleared when the controller is rebooted.

Compressor Discharge Temperature Safety

The controller will alarm and disable the compressor output until the temperature falls below threshold.

Compressor Pressure Safety Switch

The controller will disable compressor output when the pressure safety switch is activated. Compressor will resume operation when the safety switch is deactivated.

Compressor Run-time Safeties

Additional run-time safeties are incorporated to protect the compressor and MicroDS products.

HACCP

This value can be configured to be reported as the value of a choice between a few different sensor values. This can be configured under Config > Refrigeration > Temperature Sensors > HACCP Sensor.

Application

The application will have the option to support up to three separate zones. To maintain case temperature, the application will use discharge air temperatures and safeties to manage cold operations.

Internal Web Server

The CoreLink case controller features a user interface that can be accessed by web browser. This Web UI can be accessed by in store network via windows computer or with a wireless link device that can be viewed by technician through smart devices.

Data Logging

The case control application has internal logging for each sensor along with critical operation data.

Data is available for local download.

- 2-minute intervals
- 14-day capacity
- Advanced analytics; web user interface
- CSV format with 15 critical data points

Onboard data logging allows user to review performance data from the past week. User can see Min/Max/Average data along with saving data sets and importing data sets for view.

Factory Restore

The CoreLink application has a configuration file with the complete and optimized default case settings.

Anytime a user wants to default to factory settings they can simply access the user interface and force a factory reset.

Save / Load Feature

The CoreLink Case Controller is setup from the factory with a specific product configuration when a customer purchases a display case.

This specific configuration is hard-coded into the controller and is the factory default file. Also included are three user presets that a user can save or load custom configuration settings. These settings allow customers to make small tweaks in the field that can improve performance or target temperatures.

Standalone Operation


Controller is configured from the factory to run as a standalone controller. Field network integrations are done to provide additional capabilities to the controller. In case of network failure of BAS managing additional control functions, controller will default to its standalone settings and regulate display case until network connection is restored.

In case of network failure to building automation system managing case setpoints, the controller will default to program settings in internal memory and continue to regulate display case until network connection is restored.

Bios Version: 2020052000
 Web UI Version: 2.3.0
 Application Version: 3.4.0




4 DIN Devices



Corelink Case Controller IO

Output Relays



LED Indicators

Programming Sequence USB Flash Drive	
Yellow Status LED	Time
Flashing	10 secs
Illuminated Solid ON	2 min 10 secs
Flashing	25 secs
Dim	10 secs
Illuminated Solid ON	30 secs
Reboot	See Boot Sequence

Boot Sequence	
Yellow Status LED	Time
Off	5 secs
Dim	10 secs
Illuminated Solid ON	30 secs
Blinking / Normal Operation	Indefinitely



Status Yellow LED
 Power Indicator Green LED

Digital Inputs

Connector	Description
	Connector for 24Vac/dc power supply Analogue inputs (Pb1 - Pb6), Pbc Additional Power (+5Vdc, +12Vdc, GND) Analogue outputs (Out1 - Out4, GND)
	24Vac/dc digital inputs (DI1 - DI11, GND) Note: Not a dry contact switch, power supply 24Vac or 24Vdc required to activate switch If using 24Vdc, pin 31 is GND
	Network Connector Hussmann Controller Display, maximum 1 terminal per Corelink RS485 Slave connector Serial port (LAN or RS485)
	USB port for downloads (BIOS, application, configuration files, remote display applications network configurations, website) and uploads (log files) Connection with the computer via a USB-ETHERNET converter Connection with wireless connection kit
	Digital relay outputs 4 NO relays, 2 common Note: Pin 40,41 common to pins 42,43,44,45
	Digital relay outputs 4 NO relays, 2 common Note: Pin 47,48 common to pins 46,49,50,51

		Connector for 24Vac/dc power supply Analogue inputs (Pb1 - Pb6), Pbc) Additional Power (+5Vdc, +12Vdc, GND) Analogue outputs (Out1 - Out4, GND)
Input No.	Type of Input	Description
1	Supply	Reference "-" /GND (24Vac or 24Vdc)
2	Pb1	Config analog input (NTC, PTC, 0 - 20mA, 4 - 20mA, 0 - 10V, 0 - 1V, 0 - 5V, DI, CPC, CPC High)
3	Pb2	Config analog input (NTC, PTC, 0 - 20mA, 4 - 20mA, 0 - 10V, 0 - 1V, 0 - 5V, DI, CPC, CPC High)
4	Pb3	Config analog input (NTC, PTC, 0 - 20mA, 4 - 20mA, 0 - 10V, 0 - 1V, 0 - 5V, DI, CPC, CPC High)
5	(+12V)	Additional power +12Vdc
6	(+5V)	Additional power +5Vdc
7	Out1	Analogue output (0 - 10V, 4 - 20mA, Relay)
8	Out2	Analogue output (0 - 10V, 4 - 20mA, Relay)
9	Supply	Reference "+" power supply (24Vac or 24Vdc)
10	Pb4	Config analog input (NTC, PTC, 0 - 20mA, 4 - 20mA, 0 - 10V, 0 - 1V, 0 - 5V, DI, CPC, CPC High)
11	Pb5	Config analog input (NTC, PTC, 0 - 20mA, 4 - 20mA, 0 - 10V, 0 - 1V, 0 - 5V, DI, CPC, CPC High)
12	Pb6	Config analog input (NTC, PTC, 0 - 20mA, 4 - 20mA, 0 - 10V, 0 - 1V, 0 - 5V, DI, CPC, CPC High)
13	Pbc	Common analogue inputs (NTC, PTC, DI, CPC, CPC High)
14	GND(-)	Additional power reference 5Vdc and 12Vdc, analogue inputs (0 - 20mA, 4 - 20mA, 0 - 10V, 0 - 1V, 0 - 5V), analogue outputs. Note: Pressure sensors GND reference terminate
15	Out3	Analogue output (0 - 10V, 4 - 20mA, Relay)
16	Out4	Analogue output (0 - 10V, 4 - 20mA, Relay)
		24Vac/dc digital inputs (DI1 - DI11, GND) Note: Not a dry contact switch, power supply 24Vac or 24Vdc required to activate switch If using 24Vdc, pin 31 is GND
20	DI1	Digital input 24Vac/dc
21	DI2	Digital input 24Vac/dc
22	DI3	Digital input 24Vac/dc
23	DI4	Digital input 24Vac/dc
24	DI5	Digital input 24Vac/dc
25	DI6	Digital input 24Vac/dc
26	DI7	Digital input 24Vac/dc
27	DI8	Digital input 24Vac/dc
28	DI9	Digital input 24Vac/dc
29	DI10	Digital input 24Vac/dc
30	DI11	Digital input 24Vac/dc
31	GND(-)	Reference "-" for digital inputs from 1 to 11 (Note: Dry Contacts N/A, Source Required)
		Digital relay outputs 4 NO relays, 2 common Note: Pin 40,41 common to pins 42,43,44,45
40	C	Common relays 1,2,3 and 4 (MAX 10A)
41	C	Common relays 1,2,3 and 4 (MAX 10A)
42	RL1	Relay normally open contact
43	RL2	Relay normally open contact
44	RL3	Relay normally open contact
45	RL4	Relay normally open contact
		Digital relay outputs 4 NO relays, 2 common Note: Pin 47,48 common to pins 46,49,50,51
46	RL5	Relay normally open contact
47	C	Common relays 1,2,3 and 4 (MAX 10A)
48	C	Common relays 1,2,3 and 4 (MAX 10A)
49	RL6	Relay normally open contact
50	RL7	Relay normally open contact
51	RL8	Relay normally open contact

		Network Connector Hussmann Controller Display, maximum 1 terminal per CoreLink RS485 Slave connector Serial port (LAN or RS485)
60	Remote Display	Connection for Hussmann Case Display remote terminal (Vnr)
61	Remote Display	Connection for Hussmann Case Display remote terminal (+)
62	Remote Display	Connection for Hussmann Case Display remote terminal (-)
63	RS485 Slave	RS485 Slave connection (-)
64	RS485 Slave	RS485 Slave connection (+)
65	LAN	LAN Connection (-)
66	LAN	LAN Connection (+)

First Power

The CoreLink case controller requires roughly 45 seconds to boot before any regulation will begin. At the end of the boot cycle you will probably notice the case lights will illuminate and cases equipped with night curtains will open to the default position.

Micro-Distributed Operation

The zones are controlled by a combination of Air Discharge sensors. These sensors are used to regulate refrigeration around Setpoint + Deadband. The average of those sensors will call compressors ON/OFF together. Additional time delays are incorporate to stage compressors.

Application

All parameters are accessible from the controllers website or BAS system. To review settings or make adjustments please refer to the connection methods listed in this manual. No display is provided at the case unless optional

Refrigeration

Users can find typical settings in the refrigeration menu of website. Case temp can be adjusted from here.

Defrost

CoreLink will manage defrost per its own defrost schedule or from external source such as BAS system for defrost coordination. Users can find typical settings in the defrost menu of website.

How to connect to CoreLink Case Controller


Wireless Connection

Components Required

The following items are required for first time connection:

Wireless Access Point

- One Wireless Connection Kit - PN 3053767
- One Computing Device
 - Smartphone / Mobile
 - Tablet
 - Laptop



ATTENTION CONTRACTOR!
This device must not leave the store.

Connect the CoreLink with Wireless Access Point

Step 1

Connect your wireless router connection kit to the CoreLink USB port.

Step 2


Wait until the router boots up (about 30 seconds). Next, open your laptop/tablet/phone wireless network connection panel and use the default Wi-Fi Network/SSID Name and Network Key/Password noted below. These are also printed on the wireless connection kit.

Wireless Network Name/SSID:

HSM_CORELINK_AP

Network Key / Password:

HussmannCL1234



Step 3

Launch a web browser

- Safari
- Google Chrome
- Mozilla Firefox
- Microsoft Edge
- Opera
- Internet Explorer (Not Recommended)


Note: Clear cache to see latest Web UI Version. If your browser is still not working, please try the other browsers before reporting an issue.

Step 4

Enter controllers IP into the Address/Search Bar of your browser.


Default – 192.168.0.250

Other – Review Store Network Chart



Step 5

The controller login page will appear. Enter log in information as noted below.



SW version >= 2.4.0	All Previous Versions
Level 1 User Name: user Password: Hussmann	Level 1 User Name: Hussmann1 Password: Hussmann
Level 2 User Name: service Password: Hussmann1234	Level 2 User Name: Hussmann2 Password: Corelink1234
Level 3 User Name: commission Password: Corelink4321	Level 3 User Name: Hussmann3 Password: Corelink4321
Admin Not Available	Admin User Name: admin Password: Hussmann

See page 9 for dashboard screen that is displayed after proper login

Direct Wired Connection

- One RJ-45 Ethernet to USB adaptor (Details Below)
- One RJ-45 Ethernet Cable
- A laptop with an RJ-45 Ethernet port

USB to Ethernet Adaptors

Approved RJ-45 Ethernet to USB adaptor

Best Option (Amazon Prime)

AmazonBasics USB 2.0 to 10/100 Ethernet LAN Network Adapter
 Model: AE2233X2



Model: AE2233x2

Found Locally (Best Buy)

Insignia - USB 2.0-to-Ethernet Adapter - White
 Model: NS-PU98505 | NS-PU98505-C



Model: NS-PU98505 | NS-PU98505-C

Others

Plugable USB 2.0 to 10/100 Ethernet LAN Network Adapter
 Model: USB2-E100


Belkin USB 2.0 Ethernet Adapter LAN Network Adaptor
 Model: F4U047bt

Note: Adaptors in the list above have been approved for use with CoreLink. Some adapter versions may not work with this equipment. The use of other adaptors is at the user's own risk.


Connecting to CoreLink - Direct Wired Connection

Step 1 - Connect laptop with RJ-45 ethernet cable/USB adaptor to CoreLink Case Controller

Step 2 - Change laptop network settings – open laptop network settings, right click **Ethernet**, select **Properties**.



Step 3 - Select **Internet Protocol Version 4 (TCP/IPv4)**




Step 4 - Enter IP address and subnet mask
Internet Protocol Version 4 (TCP/IPv4) Properties

IP Address: 192.168.0.249
Subnet mask: 255.255.255.0

The laptop computer now has a static IP assigned that is compatible with the CoreLink Network.
Click > OK

Note: Changes to your ethernet port settings might affect normal connection to the internet with your personal laptop.

To revert ethernet settings, repeat Steps 1-4.
Select > **Obtain IP address automatically** button on the general tab of the dialog box shown in the illustration at right.
Click > OK




Successful Connection to CoreLink

Step 5


If connection is established to the CoreLink Case Controller a Hussmann launch screen should appear. Username and password case sensitive.

See page 5 for username/password combinations

Congratulations, you are now connected to Corelink



After logging in, the CoreLink Dashboard is displayed.



How to connect to CoreLink Case Controller in Store Network

Custom Store Network

When visiting a store site, the technician might notice the USB to Ethernet adaptors installed and connected to RJ-45 ethernet cable at the CoreLink Case Controllers. The store likely has a custom CoreLink Case Controller network with all cases connected directly to an ethernet switch or multiple ethernet switches. To access these controllers, please consult the refrigeration service contractor, or Hussmann Representative.

Technicians will need to obtain details of the network setup. Some networks may only be accessed through direct wire connection and others may have Wi-Fi available onsite. Username and password will be needed to make connection to this network much like the access point instructions above.

Technicians will also need to know the IP address assigned to each case circuit. In this scenario each CoreLink Case Controller will have a unique IP address assigned. Technicians will only be able to gain access to the internal Web UI with the correct provided IP address.

Once connected to the network the technician will be able to access any of the controllers connected to the network.

COMMON PROBLEMS

Clearing Cache

Try clearing your browser's cache. If the Web UI has been revised you may need to clear your browser's cache in order for the Web UI to work correctly and see new updates.

If the CoreLink login screen does not appear after typing in the web address, first check that hardwire connections or wireless connection are correct.

If connections are good and devices power up, please check mini router settings by logging into the routers Web UI.

For cable setups, please review your computer's network settings.

If ongoing problems continue, please contact your local IT Department or Hussmann Help Center.

Web browsers are updated on a continuous basis. Information presented below is subject to change. When in doubt, search the internet for up-to-date instructions for how to clear history for the web browser you are using.

Web Browser	Clearing Web History Cache
Google Chrome (Android)	<ol style="list-style-type: none"> 1. Open Chrome. 2. On your browser toolbar, tap "More". 3. Tap History, and then tap Clear browsing data. 4. Under "Clear browsing data," select the checkboxes for Cookies and site data and Cached images and files. 5. Use the menu at the top to select the amount of data that you want to delete.
Fire Fox Mozilla	<ol style="list-style-type: none"> 1. Click the menu button, choose History, and then Clear Recent History'.... 2. Select how much history' you want to clear: Click the dropdown menu next to Time range to clear to choose how much of your history Firefox will clear.... 3. Finally, click the Clear Now button.
Safari (Apple/Mac)	<ol style="list-style-type: none"> 1. Click Safari in the upper lefthand side of your screen. In the menu that appears, click Preferences. 2. In the window that appears, click the Privacy Tab. Click the button Remove All Website Data.... 3. Click Remove Now in the pop up window that appears.
Microsoft Edge	<ol style="list-style-type: none"> 1. Open the Settings Menu. In the top righthand corner you'll see three dots in a horizontal line.... 2. Locate Clearing Browsing Data.... 3. Choosing What to Clear.... 4. Restart the Browser.
Internet Explorer (Not Recommended)	<ol style="list-style-type: none"> 1. Select Tools > Internet Options. 2. Click on the General tab and then the Delete... button. 3. Make sure to uncheck Preserve Favorites website data and check both Temporary Internet Files and Cookies then click Delete.
Safari (Apple iPhone)	<ol style="list-style-type: none"> 1. Launch the Settings app from the Home screen of your iPhone or iPad. 2. Scroll down and tap on Safari. 3. Now scroll all the way to the bottom and tap on Advanced. 4. Tap on Website Data.... 5. Scroll to the bottom again and tap on Remove All Website Data. 6. Confirm one more time you'd like to delete all data.
Chrome (Android Phone)	<ol style="list-style-type: none"> 1. Open the Chrome browser and tap the Menu button (☰).... 2. Tap "Settings" in the menu that appears.... 3. Tap "Privacy" in the Advanced section.... 4. Scroll down and tap "Clear Browsing Data." ... 5. Ensure that "Cache" and "Cookies, site data" are checked and then tap "Clear."

BEFORE BEGINNING ANY SERVICE OR REPAIR:

Use a hand-held propane leak detector (“sniffer”) to ensure no propane is present in the immediate area, the inside of the display case and the inside of the refrigeration system. R-290 is an odorless refrigerant. Keep the area clear of all customers and non-essential or unauthorized personnel.

Verify that all repair parts are identical models to the ones they are replacing. Do not substitute parts such as motors, switches, relays, heaters, compressors, power supplies or solenoids. Failure to do so can result in an explosion, death, injury and property damage. Parts used on hydrocarbon cases must meet specific UL certification for non-incendive or non-sparking components. Use only Hussmann approved parts approved through the Hussmann Performance Parts Website. <https://parts.hussmann.com/>

Brazing must not begin before all propane has been cleared from the immediate area — the inside of the displays case and the inside of the refrigeration system.

If a leak is detected, follow store safety procedures. It is the store’s responsibility to have a written safety procedure in place. The safety procedure must comply with all applicable codes such as local fire department’s codes.

At minimum, the following actions are required:

- Immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred.
- Call Hussmann and/or a qualified service agent and inform them that a propane sensor has detected the presence of propane.
- Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store.
- The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas.
- A hand-held propane leak detector (“sniffer”) should be used before any repair and/or maintenance is attempted. All repair parts must be identical models to the ones they are replacing.
- No open flames, cigarettes or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all propane has been cleared from the area and from the refrigeration systems.

WARNING

- » Only Hussmann or factory trained technicians should service or repair this R-290 (propane) equipment.
- » Failure to follow instructions can result in an explosion, death, injury and property damage.

LEAK DETECTION

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used. The following leak detection methods are deemed acceptable for all refrigerant systems: Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity might not be adequate, or might need recalibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25% maximum) is confirmed.

Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine can react with the refrigerant and corrode the copper pipe-work.

NOTE:

Examples of leak detection fluids are bubble method and fluorescent method agents.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Removal of refrigerant shall be according to the Refrigerant Recovery section provided.

WARNINGS:

- » If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage, personal injury or death.
- » Installation and service must be performed by a qualified installer or service agency only as recommended by the manufacturer.
- » **READ THE ENTIRE MANUAL BEFORE INSTALLING OR USING THIS EQUIPMENT.**
- » The unit uses R-290 gas as the refrigerant. R-290 is flammable and heavier than air. It collects first in low areas but can be circulated by the fans. If propane gas is present or even suspected, do not allow untrained personnel to attempt to find the cause. The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas. If a leak is detected, immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred. Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store. No open flames, cigarettes, or other possible sources of ignition should be used inside or in the vicinity of the units.
- » **FAILURE TO ABIDE BY THIS WARNING COULD RESULT IN AN EXPLOSION, DEATH, INJURY AND PROPERTY DAMAGE.**

REPLACING REFRIGERATION SYSTEM COMPONENTS

⚠ DANGER

- » Only Hussmann service technicians or technicians qualified to handle R-290 (propane) refrigerant should service or repair this R-290 (propane) equipment. Failure to follow instructions can result in an explosion, death, injury and property damage.

⚠ WARNING

- » Component parts shall be replaced with like components, and servicing shall be done by factory authorized service personnel only, so as to minimize the risk of possible ignition due to incorrect parts or improper service.

CHARGING

A calibrated scale with +/-2 gram accuracy must be used to charge the system. The charge amount is shown on the serial plate. Only R-290 grade refrigerant can be used. Standard propane does not meet the purity/moisture content of R-290, and therefore cannot be used to charge cases.


No gas charge adjustments are allowed. When connecting hoses between the refrigeration system, manifold gauges, and refrigerant cylinder, ensure that the connections are secure and there are no potential sources of ignition nearby. Ensure that contamination of different refrigerants does not occur when using charging equipment.

Use dedicated hoses to service R-290 (propane) refrigeration systems. Hoses or lines should be as short as possible to minimize the amount of refrigerant contained in them.

Ensure that the refrigeration system is properly grounded prior to charging the system with refrigerant, to avoid the potential for static build-up.

Extreme care must be taken not to overfill the refrigeration system. After charging, carefully disconnect the hoses, attempting to minimize the quantity of refrigerant released. Further leak check the service ports, hoses, refrigerant tanks. The service ports shall be checked for leaks using a hydrocarbon leak detector with a sensitivity of 3 grams/year (0.106 Oz/year) leak rate.

Thoroughly leak check the service ports. If no leak is present, use a pinch-off tool to close the ends of the service tubes before brazing them shut. If a Schrader valve is used on the compressor service tube, it must be removed and the previous steps followed in order to braze the service tube shut.



WATER - (FOR CONDENSERS)

Water-cooled condensers are designed to operate with a water/propylene glycol solution, supplied at a temperature of 50°F to 115°F (10°C to 46°C). A minimum of 10 percent propylene glycol by weight is recommended. If water piping is run outdoors, 35 percent propylene glycol by weight will give burst protection, (not freeze protection), to approximately -40°F (-40°C). Regardless of the amount of propylene glycol, it must be ensured that the water loop has adequate corrosion inhibitors.


The water flow requirements vary by case model and length. Refer to the technical data sheet for more information on specific case settings.

The inlet and outlet water connections are attached using a ¾ inch. NPT male hose adapter.

Trapped air must be removed at high points of the water piping. Automatic air vent valves or manual valves may be used and should be located at high points in the piping by installing contractor.

Maximum working pressure of water side components:
100 psig (6.89 bar)

Any fluid circuits connected to the merchandiser shall safely release abnormal pressure. It shall not allow the release of flammable refrigerant into areas served by the other circuits if these do not comply with minimum room area limits.



INHIBITED PROPYLENE GLYCOL SYSTEM REQUIREMENTS

Hussmann's laboratories have tested the concept, function, and reliability of inhibited propylene glycols for use as a secondary fluid for refrigerated systems in accordance with ASHRAE guidelines, UL and NSF standards.

The installation of a secondary fluid system must comply with the Safety Standard for Refrigeration Systems (ANSI/ASHRAE Standard 15), Refrigeration Piping Standard (ASME B31.5) and State and municipal building codes. Failure to follow requirements outlined in this document may result in corrosion of components.

Do NOT use Ethylene Glycol. Use of any secondary fluid other than inhibited propylene glycol is prohibited and voids the Hussmann limited warranty.

PIPING REQUIREMENTS

All field-installed materials that meet pressure and temperature ratings, material compatibility requirements and state and local building codes may be used.

Plastic

Any plastic piping used must be reliably proven, before installation, to meet all pressure, temperature and material compatibility requirements.

Plastic piping must be rated for high temperature (Hot Water) applications. If the water strainer becomes clogged, the water coming out of the unit could get too hot, causing ordinary PVC piping to melt.

CAUTION

- » Plastic must be rated for hot water use! If a water strainer becomes clogged, the water outlet can be very hot, and this may cause plastic rated for only cold water to break.

Before using unproven plastic piping, check with the manufacturer to determine the suitability of the material for use with inhibited propylene glycol.

Copper

Copper pipe of M, K, or L grades can be used. Warning: Only flux materials formulated from water-soluble compounds that do not contain zinc or zinc compounds may be used for soft soldering. Copper to copper joints may be soft soldered or brazed. Soft solder must be used where the component manufacturer's installation instructions recommend.

Steel

Schedule 40 carbon steel pipe or stainless steel pipe (or tubing) is acceptable. Piping, valves and fittings can be made of ordinary steel or ductile iron but not gray steel. Do not use galvanized steel.

System Fluids

Only distilled or deionized water is approved by Hussmann. **Never mix fluids from different manufacturers. Use premixed fluid that is mixed with fully inhibited propylene glycol, not concentrated.**

However, a small amount of concentrate should be kept on hand to allow for adjustment to the solution during start-up. If the mixing is to be done on site, use only distilled or de-ionized water. A refractometer, calibrated for fluids at room temperature, is used to measure dilution. Inhibited propylene glycol used in the system must be approved for use by the FDA.

Hussmann recommends using DOWFROST™ inhibited propylene glycol. Pre-diluted solutions (35% inhibited propylene glycol) of DOWFROST™ are available from Dow. The ingredients in DOWFROST™ have been approved by the FDA and are listed as chemically acceptable by USDA.

The Dow Chemical Company
Midland, MI 48674
1-800-447-4369
www.dow.com

Requirements on system fluid:

Pre-mixed 35% inhibited propylene glycol

Typical Fluid Properties
Solution Composition is 35% inhibited propylene glycol by weight

pH of Solution 8.0 – 10.0
Specific Gravity (at 60°F) 1.033
Viscosity (at 20°F) 14.2 cP
Boiling Point of Solution 217°F
Freezing Point of Solution 2°F
Refractive Index (at 72°F) 1.3733

System Balancing

Balancing may be required to provide adequate coolant flow to each circuit in order to maintain the required waterflow. Balancing is achieved through the setting of balance valves located throughout the system piping.

The installation contractor must consult and be familiar with the manufacturer's Material Safety Data Sheets (MSDS) before handling any secondary fluid. The MSDS contains proper disposal and safety methods.

PRE-INSTALLATION SYSTEM CLEANING

Dow recommends the new piping system be cleaned using a 1-2% solution of trisodium phosphate (TSP), or equivalent cleaner and distilled or deionized water to remove grease, mill scale, or other residues from construction.



Repeat this process if necessary until the drained solution is clear and free from visible debris. The system should then be drained and flushed again using distilled or deionized water.

Hussmann only recommends distilled or deionized water for system flushing with 2% TSP. Dry nitrogen can be used for the initial pressure test, (60 to 75 psi), hold for three hours.

NOTICE

- » Use only distilled or de-ionized water for flushing with 2 percent tri-sodium phosphate (TSP). Use a pre-mixed inhibited propylene/glycol solution. If the mixing is to be done on site, use only distilled or de-ionized water. Do not use tap water.


TOP MOUNTED WATER & ELECTRICAL CONNECTIONS



Top Mounted Water & Electrical Connections


Top View

ID6SU8WE / IDD6SU8WE



Top View

ID6SU12WE / IDD6SU12WE





⚠ DANGER

- » Risk of fire or explosion. R-290 (propane) refrigerant is flammable, and the refrigeration system should be serviced or repaired only by trained service personnel. Do NOT puncture refrigerant tubing.

REFRIGERATION

Each Insight self-contained case is equipped with its own condensing unit. The refrigeration system is sealed and factory charged. Each case has one electronic controller.

Insight self-contained merchandisers use R-290 (propane) refrigerant. All models have a hermetic compressor. The system employs pre-set thermostatic expansion valves for refrigerant flow control. Do not attempt to adjust the expansion valves. Refer to the case serial label for refrigerant charge information.

⚠ WARNING

- » Attention trained service personnel: Mandatory safety service procedures must be followed when servicing the refrigeration system.

CONDENSING UNIT ACCESS

Condensing units are located on top of the case. Remove the metal cover(s) to gain access to the condensing unit. All the case's and condensing unit's electrical connections are done at the factory.

⚠ WARNING

- » Opening condensing unit electrical box exposes personnel to electrical hazard and should only be performed by a qualified service technician.



IDENTIFICATION OF WIRING

Leads for all electrical circuits are identified by colored plastic bands. These bands correspond to the color code sticker located inside the merchandiser's wireway cover. Color code is shown on next page.





**ALWAYS CHECK THE SERIAL LABEL
FOR COMPONENT AMPERES.**

SENSOR LOCATION

Discharge air sensor is located in the case canopy by the honeycomb. An electrical box is shown at right for field installation of the sensor. (Field box may not be present if a sensor was not originally factory installed.)



ELECTRICAL ACCESS FOR SIGN-READY & FLAT-FRONT FASCIAS



WIRING COLOR CODE

Leads for all electrical circuits are identified by a colored plastic band: neutral wire for each circuit has either White insulation or a White plastic sleeve in addition to the color band.

PINK.....	REFRIG. THERMOSTAT LOW TEMP.	ORANGE OR	
LIGHT BLUE...	REFRIG. THERMOSTAT NORM TEMP.	TAN.....	LIGHTS
DARK BLUE....	DEFROST TERM. THERMOSTAT	MAROON	RECEPTACLES
PURPLE.....	CONDENSATE HEATERS	YELLOW.....	DEFROST HEATERS 120V
BROWN	FAN MOTORS	RED	DEFROST HEATERS 208V
GREEN*	GROUND	*EITHER COLORED SLEEVE OR COLORED INSULATION	

**ELECTRICIAN NOTE: Use copper conductor wire only.
MERCHANTISER MUST BE GROUNDED**



THESE ARE MARKER COLORS, WIRES MAY VARY.

DRIP PIPING / FIT & FINISH / SPLASHGUARDS

WASTE OUTLET AND WATER SEAL

Insight merchandisers have one waste outlet located in the front center of the bottom or right-hand side for 8 ft cases. Water seals are field installed with waste outlet to prevent air leakage and insect entrance into the case. Tees and clean-outs are supplied for each case.

A hat-shaped strainer is also shipped with the merchandiser. Place strainer over the waste outlet as shown below.



INSTALLING DRIP PIPING

Poorly or improperly installed drip pipes can seriously interfere with the merchandiser's operation and result in costly maintenance and product losses.

Optional drip pipe arrangements are shown on the next page. It is the installing contractor's responsibility to consult local agencies for local code requirements. Assemble the components using field-supplied PVC primer and glue according to the manufacturers direction.


Please follow the recommendations listed below when installing drip pipes to ensure proper installation.

1. When connecting drip piping, the "water seal" must be used as part of the drip piping to prevent air leakage or insect entrance. Never use two water seals in series in any one drip pipe. Double water seals in series will cause an air lock and prevent draining.
2. Pitch the drip piping in the direction of flow. There should be a minimum pitch of $\frac{1}{4}$ " per ft (20 mm per 1 m).

3. Avoid long runs of drip piping. Long runs make it impossible to provide the pitch necessary for good drainage.
4. All connections must be watertight and sealed with the appropriate PVC or ABS cement.
5. Ensure that drip piping is supported to relieve any stress on drip pipe connectors and drain hub. Drip piping MUST be supported no more than 24 in. from drain hub tee.
6. Provide a suitable air break between flood rim of the floor drain and outlet of drip pipe. To meet code on low base merchandisers, it may be necessary to install a field-supplied drip pipe reducer. An alternative is to cut the last section of drip pipe at an angle.
7. Prevent drip pipes from freezing: Do not install drip pipes in contact with uninsulated suction lines. Suction lines should be insulated with a nonabsorbent insulation material. Where drip pipes are located in dead air spaces, such as between merchandisers or between a merchandiser and a store wall, provide means to prevent freezing.



Drip Piping Example for Standard Case Height
(Not for Ultra Low Front Cases)



Never use drip piping smaller than the nominal diameter of the pipe or water seal supplied with the merchandiser.






It is the installing contractor's responsibility to consult local agencies for local code requirements.

FLUSH FLOOR DRIP PIPING EXAMPLE FOR ULTRA LOW FRONT CASES






Elbow is to be oriented toward rear of case. Install elbow to tee, place elbow on hub. Push elbow until it meets the liner.



OPTIONAL WASTE OUTLET DRIP PIPING EXAMPLE FOR ULTRA LOW FRONT CASES

There is limited space underneath the case for piping ultra low front cases. If there is a waste outlet in the floor, use the ultra low front piping kit. This extends the splashguard forward. Follow the waste outlet location drawings on the following pages to install the drip piping in the correct location. This kit can also be used to pipe multiple cases to a single floor waste outlet/sink.

Item Number	Title	Quantity	Comments
1	ELBOW- AIR SEAL INSIGHT	1	FACTORY INSTALLED
2	TEE-1.25	1	FACTORY INSTALLED
3	BUSHING-PVC REDUCER 1.250 X .50 SLIP	1	FIELD INSTALLED
4	REDUCER BUSHING-1.25x1.00	1	FIELD INSTALLED
5	PLUG-1.00	1	FIELD INSTALLED
6	PIPE-PVC .500 X 3.5 LONG	4	FIELD INSTALLED
7	ELBOW-PVC 90 DEG .500 SLIP	3	FIELD INSTALLED
8	ELBOW-PVC 22.5 DEG .500 SLIP	1	FIELD INSTALLED



Elbow trap is to be oriented toward rear of case. Install elbow to tee, place elbow on waste outlet of case. Push elbow trap until it meets the liner.



Drain Location with Drain Extension Kit (Dimensions in Inches)


Standard Depths Models Ending in SU	4-foot	6-foot	8-foot	12-foot
(A) RH end of case to center of original waste outlet	24 1/8	24 1/8	24 1/8	72 1/4
(B) RH end of case to center of relocated waste outlet (with drain extension kit)*	13 3/4	13 3/4	13 3/4	61 7/8
(C) Back of case to center of original waste outlet	33 1/2	33 1/2	33 1/2	33 1/2
(D) Back of case to center of relocated waste outlet (with drain extension kit)	38 1/4	38 1/4	38 1/4	38 1/4
(E) Back of case to the back of the relocated splashguard (with drain extension)	41	41	41	41

*Drain Extension shown piped to the right but may be piped either direction

Drain Location with Drain Extension Kit (Dimensions in Inches)


Narrow Depths Models Ending in NU	4-foot	6-foot	8-foot	12-foot
(A) RH end of case to center of original waste outlet	24 1/8	24 1/8	24 1/8	72 1/4
(B) RH end of case to center of relocated waste outlet (with drain extension kit)*	13 3/4	13 3/4	13 3/4	61 7/8
(C) Back of case to center of original waste outlet	28 5/8	28 5/8	28 5/8	28 5/8
(D) Back of case to center of relocated waste outlet (with drain extension kit)	33 1/2	33 1/2	33 1/2	33 1/2
(E) Back of case to the back of the relocated splashguard (with drain extension)	35 1/8	35 1/8	35 1/8	35 1/8





INTERIOR CASE
CONDENSATE DRAIN
LOCATION

EXTERIOR FRONT
CONDENSATE
DRAIN & FLOOR
DRAIN LOCATION



INTERIOR CASE
CONDENSATE
DRAIN
LOCATION


EXTERIOR
FRONT
CONDENSATE
DRAIN &
FLOOR DRAIN
LOCATION

FINAL ALIGNMENT / FIT & FINISH

Fascia Top Cap Alignment

Fascia Top Cap can slide toward the center of (multideck) case lineups to eliminate gaps.


1. Pull fascia top cap to uncover fixing screws.





Screw Location

Side View

Screw Locations





2. Loosen the screws of fascia top cap.
3. Move fascia top cap towards the lineup center. Tighten the screws after finishing the alignment.
4. Snap fascia top cap to closed position.
5. Install fascia trim (optional) between joints and at ends. Hook at bottom first, then snap top into place.



Fascia Panel Alignment

Fascia panels can slide toward the center of (multideck) case lineups to eliminate gaps.

1. Slide fascia panels toward lineup center as shown in the illustration below.
2. Place optional fascia trim between fascia joints between end panel and fascia and between case lineup joints. Install tape to joint first, then attach bottom and top fascia trim.



Front Panel Alignment


Front Panels can slide toward the center of (multideck) case lineups to eliminate gaps.

1. Loosen the front panel screws located at the bottom of Front Panel.
2. Slide front panel towards the lineup center to eliminate gaps between front panels. Tighten the screws after finishing the alignment.
3. Place optional front panel trim at case lineup joint. Install tape to joint first, then attach front panel trim.



NOTE Remove Front Skid Brace before aligning Front Panels. Align Panels before installing the Splashguard Front and Bumpers.



Front Panel Screw



Side View



INSTALLING END SPLASHGUARDS

(Standard Case)

1. End splashguard must be slid in from the front, so that it fits behind the end panel. Attach end splashguard brackets to base at locations shown in the illustrations below.
2. Align forward edge of splashguard end panel to the inside of front splashguard. Fasten end splashguard to bracket with screws.
3. If end assembly bolt is loosened & seal broken when installing end splashguard, apply caulk to seal end assembly to inside of case.





End Splashguard Panel fits to the inside of End Assembly.



IMPORTANT

Install end splashguard before installing front splashguards.



Installing End Splashguards

(Detail below for cases with elevated case heights.)

1. End splashguard must be slid in from the front, so that it fits behind the end panel. Attach end splashguard brackets (2) to base at locations shown in the illustrations below.
2. Align forward edge of splashguard end panel to the inside of front splashguard. Fasten end splashguard to bracket with screws.



NOTE

End Splashguard Panel fits to the inside of End Assembly.



IMPORTANT

Install end splashguard before installing front splashguards.




INSTALLING SPLASHGUARD BRACKETS

Position splashguard brackets at the front base (legs) of the merchandiser near the floor. Loosely assemble Splashguard Bracket using #8 x 5/8 inch SM screws as shown in Detail A below. More detail of splashguard installation shown on next page.

⚠ WARNING


» Use caution when working around refrigeration lines or water lines. Damage to equipment and/or personal injury could occur.

Splashguard Bracket and Panel Installation (12 ft Shown)




NOTE End Splashguard Panel fits to the inside of End Assembly.

DETAIL A



IMPORTANT Install end splashguard before installing front splashguards.

Item Number	Title	Quantity
1	RETAINER SPLGRD	4
2	SCREW SM 8 18X5/8 PHIL HX HD	8
3	PANEL 5.4" SPLGRD CL/O 12FT	1
4	SPLASHGUARD FRONT 12FT	1



SIDE VIEW

INSTALLING SPLASHGUARDS

(Retainers and Panels)




Splashguards are shipped inside each merchandiser, 4 brackets for 12 ft case, 3 for 6 ft , etc. After merchandisers have been leveled and joined, and all drip piping, electrical and refrigeration work has been completed, install the splashguard.

To Install Splashguards:

1. Check to be sure that all splashguard brackets are level with the floor. Refer to previous page for additional exploded view pictures.
2. Loosely attach the lower splashguard retainer bracket using # 8 SM screws (1).
3. Install close-off panel as shown in (2 & 3). Slide splashguard close-off panel between the bracket and lower front support.
4. Raise the splashguard close-off panel to where the top fits into bend on the lower color panel, then tighten the splashguard brackets.
5. Fit the lower splashguard into the slots on the lower splashguard retainer. Lower splashguard snaps into place (4).


To install Optional cove trim to the splashguard:

1. Remove all dirt, wax and grease from the area of the splashguard where adhesion will be necessary to ensure a secure installation.
2. Apply a good contact cement to the cove trim and allow proper drying time according to the directions supplied with the cement.
3. Install the trim to the splashguard so that it is lying flush with the floor. Do not seal the trim to the floor.
4. If required by local health codes the Cove Trim may be sealed to the floor, using a silicone type sealer. Sealant must be removed and replaced when servicing.



Splashguard Alignment to eliminate gaps in cases Line-Up

- 1. Slide Splashguard towards line-up center to eliminate Splashguards gaps.



STARTUP / OPERATION

START UP

Prior to Start-up Check List:

- Is the case connected to its proper name label power supply?
- Is there power on at the breaker panel?
- Are the water hand valves open?
- Is the chiller on and circulating water through the condenser(s)?
- Are there any leaks from condenser water connections? Clamps may need to be tightened.
- Do evaporator fans rotate freely? Are they plugged in?
- Is the water strainer clear of debris?

Starting up the case:

- Ensure the chilled water flow is on, and connect the case to power.

The case(s) will start automatically within 4 minutes. The controller will be activated, and the case will begin to cool down.

Once the cases are running, listen for any unusual sounds or events. Examples include: evaporator fan blade interference. Compressors should run continuously at startup. Use an amperage meter to check the current to each compressor. Compressors are hermetic and very quiet.

WARNING

- » Possible hazardous condition. Follow safety procedures outlined by store safety management.

DANGER

- » Due to risk of ignition resulting from incorrect parts or improper service, only Hussmann authorized personnel may service this equipment.
- » Component parts shall be replaced only with exact manufacturer and model number components. Failure to use authorized technicians could result in an explosion, death, injury and property damage.

CHECK:

The water outlet temperature from each condenser. The outlet water temperature should be about 10°F (5.6°C) higher than the inlet water temperature.

CHECK:

Each fan to ensure it is running. The discharge air output at the top inside front of the case (honeycomb area) should be relatively even across the length of the case. VERIFY there are no leaks at the condenser water connections.

CHECK:

The display on the discharge air sensor, which displays the case temperature. The display will indicate room temperature upon start up and decrease with run time.

Field Startup

When starting up the case(s) case for the first time:

Verify that water system is running and maintaining the proper water flow and temperature.

Shelves need to be in place. A false front placed on the shelves to represent a product load will support the air curtain and help the compressor reach the setpoint. Empty boxes can be used for this purpose. Ambient conditions need to be 75°/55% relative humidity or less

NOTE:



At high water temperatures (between 90° and 115°F), compressors will run the full 30 minute maximum run time - discharge air temperature will get to the setpoint, but will not cut out on temperature (Setpoint – deadband, or 26° for an ID6SU-W case, for example). The case will hold proper product temperatures at these conditions.

Troubleshooting:

If compressors are running the full 30-minute maximum run time and discharge air temperatures are not getting to the setpoint, check other possible defects before cutting into the refrigeration system:

Discharge air sensor location:

The discharge air sensors should be above the honeycomb, at the center of each section, in the location shown. If the sensors are in any other location, the discharge air sensor may read high, and the compressor then will not shut off even though discharge air temperature is reaching the setpoint. An external temperature probe can be used to verify the discharge air temperature.



Plenum and air flue seals:


The fan plenum should be tight to the case bottom and there should be no gaps between the lower back panel and the back of the plenum.

Rear air flue seams should be sealed with foil tape.

Discharge air sensor seen through discharge air honeycomb

Inside of case

Outside of case



Correct – gasket is between bottom of back panel and top of fan plenum




Incorrect – evaporator coil can be seen between back panel and fan plenum

To connect to the CoreLink WebUI refer to the CoreLink Quick Connect Guide:

https://www.hussmann.com/ns/Technical-Documents/3088251_CoreLink_OC_Guide_EN.pdf

Access the Fault Sequence Tab



The Fault Sequence will show if the refrigeration system has a failure, and will help determine the cause of the failure. The failure will usually be accompanied by a discharge air temperature alarm.

Possible failures include:

- Suction Pressure Safety Switch Alarm
- High Pressure Safety Switch Alarm
- Discharge Temperature Alarm

Check the CoreLink Fault sequence

If the compressor cuts out on high discharge pressure or high compressor discharge temperature alarm, this is usually caused by lack of water flow through the system or high water temperature.

Verify that:

- The water system has adequate flow and pressure
- The water inlet strainer screen is not blocked.
- The water flow valve on the outlet tube assembly is not obstructed, and has the correct cartridge for the water flowrate required.
- Water inlet temperature is less than 115°F
- Normally a water system problem will cause an alarm on all the compressors on a case.

A CoreLink suction pressure safety switch alarm on an individual compressor is an indication that there is a problem with the refrigeration system that requires service. Possible causes of the suction pressure safety switch alarm include:

1. Blocked refrigerant system:

This can occur at the cap tube or distributor orifice. This will cause a suction pressure safety switch alarm to enable and then clear three times, then lock out. Then after a delay the alarm will clear and the compressor will start again. If the failure condition is still present, this will continue until the CoreLink controller permanently locks out the compressor. This is an indication that service is required to repair the blockage in the refrigeration system.

NOTE:

A system with a partially blocked refrigerant system may run without alarms but have poor performance. This will be indicated by high compressor discharge temperature on the CoreLink analysis or status tab (20° higher on one compressor compared to the others on the same case while the compressor is running).

2. Low refrigerant charge due to a leak:

If the compressor cuts out on the suction pressure safety switch alarm due to refrigerant loss, the suction pressure will not go back up high enough to reset. The suction pressure safety switch alarm will enable, and will not clear. This is an indication that service is required to evacuate the system, repair a leak, and then re-charge with the correct refrigerant charge.

Fault Sequence shown for suction pressure lockout due to a blocked cap tube.

3/29/2022 9:24:8	F4012	Compressor 2 Suction pressure Safety Lockout	2	Active
3/29/2022 9:23:56	F4372	Compressor 2 Permanent Suction Lockout	2	Active
3/29/2022 9:19:8	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 9:19:5	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active
3/29/2022 9:16:50	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 9:16:47	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active

Date and Time	Fault Code	Fault Name	Zone	Status
3/29/2022 8:59:16	F4012	Compressor 2 Suction pressure Safety Lockout	2	Active
3/29/2022 8:59:16	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 8:59:14	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active
3/29/2022 8:56:59	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 8:56:57	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active
3/29/2022 8:54:41	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 8:54:38	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active
3/29/2022 8:50:7	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 8:50:4	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active
3/29/2022 8:34:51	F4012	Compressor 2 Suction pressure Safety Lockout	2	Active
Date and Time	Fault Code	Fault Name	Zone	Status
3/29/2022 8:32:36	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 8:32:32	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active
3/29/2022 8:25:32	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Clear
3/29/2022 8:25:25	F4002	Compressor 2 Suction pressure Safety Switch Alarm	2	Active

Servicing

It is important that replacement parts are the same as the original equipment, and that the design of the original equipment is followed. For example, if the cap tube is replaced, the replacement cap tube must be in contact with the suction line.

If a leak is detected, follow store safety procedures.

It is the store's responsibility to have a written safety procedures in place. The safety procedure must comply with all applicable codes such as local fire department's codes.

At minimum, the following actions are required:

- Immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred.
- Call Hussmann and/or a qualified service agent and inform them that a propane sensor has detected the presence of propane.
- Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store.
- The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas.
- A hand-held propane leak detector ("sniffer") should be used before any repair and/or maintenance is attempted. All repair parts must be identical models to the ones they are replacing.
- No open flames, cigarettes or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all propane has been cleared from the area and from the refrigeration systems.

12 hours after startup checklist:

- Check case temperature.
- Check if there is any alarm on the controller display.
- Check water connections for leaks or accumulation of water.
- Verify the fans are running.
- Check compressor's amperage, and validate with the information on serial label.
- Check that all inspection plates and covers have been properly replaced.
- Inspect for any water accumulation due to incorrect or unsealed penetrations where electrical or other lines pass through insulated walls of the case.
- • Check the water outlet temperature from each condensing unit. Water outlet temperature should be approximately 10° F (5.6° C) higher than the inlet water temperature.

⚠ WARNING

» Possible hazardous condition. Follow safety procedures outlined by store safety management.

Condensing Unit Components

The condensing units are equipped with a non-adjustable high pressure controls and internal compressor motor protectors.

IMPORTANT:

The high pressure control will open in the event of excessive pressures; for example, the loss or reduction in condenser water flow. The high pressure control will open at approximately 450 psig and automatically resets when the pressure has decreased below 320 psig.


LOAD LIMITS

Each merchandiser has a load limit. Shelf life of perishables will be short if load limit is violated. At no time should merchandisers be stocked beyond the load limits indicated.

STOCKING

Do not block honeycomb or return air grille. Product should not be placed inside of merchandisers until merchandiser is at proper operating temperature. Proper rotation of product during stocking is necessary to prevent product loss. Always bring the oldest product to the front and set the newest to the back.

Air discharge and return flues must remain open and free of obstruction at all times to provide proper refrigeration and air curtain performance. Do not allow product, packages, signs, etc. to block these grilles. Do not use non-approved shelving, baskets, display racks, or any accessory that could hamper air curtain performance.



⚠ WARNING

- » Do not walk on case. Do not store items or flammable materials atop the case.

⚠ WARNING

- » Case ventilation openings must be clear of any obstructions. Do not damage the refrigerant circuit.

SHELF MAXIMUM WEIGHT LIMITS

Hussmann merchandiser shelves are designed to support the maximum weight load limits as indicated in this table.

Exceeding these maximum weight load limits may cause damage to the shelf or shelves, damage to the merchandiser, damage to store products, and potentially create a hazardous condition for customers and staff. Exceeding the indicated maximum weight load limits constitutes misuse as described in the Hussmann Limited Warranty.

Weight Limits for Merchandiser Shelving

Nominal Shelf Depth	Maximum Load Limit
12 in. (305 mm)	125 lb (56.7 kg)
14 in. (357 mm)	125 lb (56.7 kg)
16 in. (406 mm)	200 lb (90.7 kg)
18 in. (457 mm)	200 lb (90.7 kg)
20 in. (508 mm)	250 lb (113.4 kg)
22 in. (559 mm)	250 lb (113.4 kg)
24 in. (610 mm)	250 lb (113.4 kg)
Heavy Duty Beverage Shelf 16 in. (406 mm)	300 lb (136 kg)
Heavy Duty Beverage Shelf 18 in. (457 mm)	320 lb (145.1 kg)
Heavy Duty Beverage Shelf 20 in. (508 mm)	350 lb (158.8 kg)
Heavy Duty Beverage Shelf 22 in. (559 mm)	350 lb (158.8 kg)
Heavy Duty Beverage Shelf 24 in. (610 mm)	350 lb (158.8 kg)

*Shelf load limits at 0° tilt


Merchandiser Shelf Depths

	Recommended	Maximum
Narrow (37 in. Merchandiser Depths)	16 in. (406 mm)	18 in. (457 mm)
Standard (42 in. Merchandiser Depths)	22 in. (559 mm)	24 in. (610 mm)

MULTIDECK SHELF CONFIGURATION

Shelves are individually mounted in 1 in. (25 mm) increments and have two-, three-, or four-position brackets, permitting shelves to be placed in a flat or down-tilt position (see illustration). Front product stops are recommended when shelves are placed in the down-tilt position.

Case performance will be degraded if peg shelves are used without baffles. Unauthorized specialty shelving may cause poor merchandiser performance. Consult your Hussmann representative to ensure optimum performance of Hussmann equipment.





INSTALLING CASESHEILDPTM(S) (OPTIONAL)

The CaseShieldPTM is installed on the front edge of shelves as a replacement to existing price tag molding (PTM). It acts as a guide for the air from the discharge to the return air grille to reduce turbulence and save energy.

To install the CaseShieldPTM:

Slide the CaseShieldPTM onto the shelf as shown in (B) below.


NOTE: For use only with straight shelves. Do not apply CASESHIELD PTM(s) to angled shelves.



LED FIXTURES

These merchandisers are equipped with 24 volt DC power supplies that power the LEDs. The power supplies are located in the canopy raceway. Power supplies are located in the field connection box for wedges. LEDs work well for dimming or on/off operation using an occupancy sensor (optional kits). Replace lights with like fixtures. Contact your Hussmann representative for more information.

They can be turned on and off in a cold environment with no warm-up time and no negative impact on lamp life.




⚠ WARNING

— LOCK OUT / TAG OUT —

» To avoid serious injury or death from electrical shock, always disconnect the electrical power at the breaker when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.


PROCEDURE FOR INSTALLING LIGHTED SHELVES

Follow these instructions to ensure good contact between male and female connectors.




1. Remove any products from the case and place in cooler. Shut off power to the merchandiser.
2. Turn off Canopy Light Switch. Remove all packed shelves.

- Engage each power socket cap, and ensure that each cap is fully seated before cleaning. Ensure the proper seating of the cap at all times when the plug is not engaged.




- Clean the merchandiser as described in the Care and Cleaning paragraphs of Section 5 — Maintenance. Keep liquid out of sockets. (Allow merchandiser shelves to dry before turning on shelf power.)
- Verify power to the merchandiser is turned ON. Verify that the merchandiser light switch is turned OFF. The switch is located in the canopy, on the left side.
- Refer to the illustration at the top of the next page. Note that other models will have fewer rows of shelves. Starting from the left-hand (where applicable) bottom section, choose the location for the first shelf, X-1.
- Secure the shelf in the slotted upright. Make certain that the shelf is level and that ends are in the same slot on the left and right upright. Markings on the shelf uprights indicate the proper shelf notch for each shelf location. It is important that shelf brackets be properly seated in the slotted upright.
- Working from left to right (where applicable), install the next shelf, X-2, to the right of the first shelf you installed. Always work from left to right and from the bottom up in each 90° wedge case.
- After each shelf on the bottom row is in position, be sure to remove the cap and insert the shelf connector. Push firmly.
- Turn ON the wedge case light switch after the entire bottom row has been installed. The shelf lights should light.



If an LED shelf light does not operate:

- Turn off light switch.
- Remove and firmly re-insert each shelf plug.
- Turn on light switch.




Always work Left to Right,

Always work Left to Right, and Bottom to Top

If lights do not operate after checking the items listed above, contact the installation contractor.

- Using the row of shelves just installed as support, set the next shelf, X-3, in the desired location. Remove the cap and insert the shelf plug. Continue working left to right installing shelf X-4.



Note: Since the location for the remaining shelves, X-4 to X-10, may be directly over the rear wall receptacle, the shelf should be plugged in before engaging brackets in the uprights. The lower shelf will support the weight of the next shelf until it is plugged in. After installing each shelf, verify that its plug is properly connected to its rear wall receptacle. Continue working row by row, bottom up, left to right.



If a shelf is plugged in and the lamp does not work, verify the case light switch is ON.


Shelf LED clips must be first inserted into the front lip underneath the shelf as shown at left. Next the retaining clip is "snapped on" to the rear of the LED clip.

SHELF LED CLIP INSTALLATION



Use caution when installing Product Stops. Product stop legs must be inserted at an angle. When product leg goes through the shelf, it must rest BEHIND the LED shelf light as shown below.


PRODUCT STOP INSTALLATION



INSTALLING FDA/NSF REQUIRED THERMOMETER

The following pages provide the same information that ships with the thermometer. This requirement does not apply to display refrigerators intended for bulk produce (refer to Page 1-1 for definitions. Please note that the tape cannot be exposed after installation. A digital thermometer may be ordered as an optional kit. Suggested mounting locations for EGP cases is on the interior end panel in a location where the temperature can easily be seen.

This is an NSF-7 &
US FDA Food Code
Required
Thermometer



SAFETY INSTRUCTIONS

- » Merchandiser must operate for 24 hours before loading product!
- » Regularly check merchandiser temperatures. Do not break the cold chain. Keep products in freezer before loading into merchandiser.
- » Medium temperature merchandisers are designed for loading ONLY pre-chilled products. Low temperature merchandisers are designed for loading ONLY frozen products.

Important – Please read!

This thermometer is provided in response to United States
Food and Drug Administration (US FDA) Food Code [<http://www.fda.gov/>]
and
National Sanitation Foundation (NSF / ANSI) Standard 7 [<http://www.nsf.org/>]

Each installation will be different depending on how the unit is stocked, shopping patterns in the department and ambient conditions of the store. The suggested locations provided herein are possible locations. It is the responsibility of the purchaser / user to determine the location within the food storage area of the unit that best meets the code requirements above.

The thermometer may need to be moved several times to find the warmest location. Mounting options include flexible plastic for price tag molding application, magnet applied to back of flexible plastic for steel end wall, and double stick tape. Tape must not be exposed after installation.

Questions about either code should be addressed to local agencies or other appropriate officials.

Keep with merchandiser

or give to store manager.

DO NOT DESTROY.

MAINTENANCE AND SERVICE

GENERAL SAFETY INSTRUCTIONS

WARNING

If the information in these instructions are not followed exactly, a fire or explosion may result, causing property damage, personal injury or death. Installation and service must be performed by a qualified installer or service agency.

READ THE ENTIRE MANUAL BEFORE INSTALLING OR USING THIS EQUIPMENT.

The unit uses R-290 gas as the refrigerant. R-290 is flammable and heavier than air. It collects first in low areas but can be circulated by the fans. If propane gas is present or even suspected, do not allow untrained personnel to attempt to find the cause. The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas.

If a leak is detected, immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred. Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store. No open flames, cigarettes, or other possible sources of ignition should be used inside or in the vicinity of the units.

FAILURE TO ABIDE BY THIS WARNING COULD RESULT IN AN EXPLOSION, DEATH, INJURY, AND PROPERTY DAMAGE.

LOCK OUT / TAG OUT — To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

To reduce the risk of fire, electrical shock or injury when cleaning this merchandiser:

- Unplug the merchandiser before cleaning.
- Keep all liquids away from electrical and electronic components.

To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

Do not remove the power supply cord ground. Merchandiser must be grounded. All wiring must be in compliance with NEC and local codes.

IDENTIFICATION OF CASE PARTS


⚠ WARNING

» Do NOT allow cleaning agent or cloth to contact food product.

⚠ WARNING

» Hussmann does not recommend using spray hoses or misting systems due to risk of serious injury or death from electrical shock.

» Do not use spray hoses or misting systems on cases with shelf or rail lighting.



CARE AND CLEANING

Long life and satisfactory performance of any equipment is dependent upon the care it receives. To ensure long life, proper sanitation and minimum maintenance costs, these merchandisers should be thoroughly cleaned, all debris removed and the interiors washed down as part of a regular store sanitation schedule.

Fan Plenum

To facilitate cleaning, the fan plenum is hinged. After cleaning be sure the plenum is properly lowered into position or product loss will result due to improper refrigeration.

Fan motor harness plug must be securely connected. Do not disconnect fan motor harness plug for cleaning or maintenance procedures.



To lift the fan plenum:

1. Gently bend the bottom of the hinge pin arm away from the plenum to release the retainer from the coil support.
2. Rotate the hinge pin 180° so that the arm is pointed upwards.
3. Slide the hinge pin out and away from the plenum.




Lift up Fan Plenum. Use chain to hook up fan plenum to facilitate cleaning.

The plenum can also be removed, but this is not necessary for routine cleaning.




1. Flip the arm up and pull arm out to release the plenum.



Removable Return Air Grilles

The return air grilles may be removed to facilitate cleaning. Lift a four foot section up and out as shown below.



⚠ WARNING

- » All case cleaning and maintenance procedures should be performed with the power disconnected at the breaker.

Fascia Panels

The exterior of the fascia panels should be cleaned with a mild detergent and warm water. Do not use ammonia-based products to clean optional acrylic panels. Never use abrasive cleansers or scouring pads.

EXTERIOR SURFACES

The exterior surfaces must be cleaned with a mild detergent and warm water to protect and maintain their attractive finish. Never use abrasive cleaners or scouring pads.

INTERIOR SURFACES

The interior surfaces may be cleaned with most domestic detergents, ammonia based cleaners and sanitizing solutions will not harm the surface. Always read and follow the manufacturer's instructions when using any cleaning product.

Inspect all LED connections and plug/ receptacles for signs of arcing. Replace any component that shows signs of arcing. Make sure all unused receptacles have close-off covers securely attached.

Do Not:

- Abrasive cleansers and scouring pads, as these will mar the finish.
- Coarse paper towels on coated glass.
- Ammonia-based cleaners on acrylic parts.
- Do not spray water from a hose directly on the canopy lights or fans.
- Solvent, oil or acidic based cleaners on any interior surfaces.

- A pressure nozzle on canopy lights, shelf lights or any other electrical connection. Do not use water pressure beyond what is supplied from the potable water system and spray nozzle (ie Do not use a pressure washer.)

Steps:

- First turn off refrigeration, then disconnect electrical power. Turn off case power at breaker. Make sure all unused light receptacles have their close-off covers securely attached.
- Remove the product and all loose debris to avoid clogging the waste outlet.
- Store product in a refrigerated area such as a cooler. Remove only as much product as can be taken to the cooler in a timely manner.
- Thoroughly clean all surfaces with soap and warm water. Do not use steam or high water pressure hoses to wash the interior. These will destroy the merchandisers' sealing causing leaks and poor performance.
- Lift hinged fan plenum for cleaning. Hook chain in rear panel to secure plenum during cleaning. Be sure to reposition the fan plenum after cleaning merchandiser.
- Take care to minimize direct contact between fan motors and cleaning or rinse water.
- Rinse with warm water, but do not flood. Never introduce water faster than the waste outlet can remove it.
- Allow merchandisers to dry before resuming operation.
- Wipe down lighted shelves with a damp sponge or cloth so that water does not enter the light channel.
- After cleaning is completed, turn on power to the merchandiser.

WARNING

- » Do not use mechanical devices or other means to accelerate the defrosting process.
- » Do not use electrical appliances inside the food storage compartments of the case(s).

RECOMMENDED CLEANING INSTRUCTIONS

The directions below are recommended cleaning instructions for Insight cases and should not be used as a substitute for the store's regular maintenance schedule. Follow all local and national health codes. Cleanliness of the case encourages long-lasting life of the equipment. This guide lists some of the key areas of the cases that require cleaning to help maintain the overall appearance and performance of the equipment and keep it free of debris. The cases may need additional cleaning, especially in high traffic areas, dusty areas and during unusually extended periods of use of the equipment.

Cleaning Instructions Weekly or Monthly

1. Remove product; store it in another case or suitable walk-in cooler.
2. Remove wire racks and bottom pans. Cleaning them in the case with warm water and a soap solution, then rinse and set aside.
3. Turn off case power at breaker.
4. Flip up the fan plenum assembly to provide more room for cleaning in the case if necessary.
5. Remove all loose debris and food particles that may clog drain. Check drain to make sure it is not clogged. Do not force items down drain, use the drain catch to remove debris and dispose.
6. Remove honeycomb and price display molding.
7. Clean all surfaces including shelves and honeycomb by spraying down water (preferably warm) and mild detergent. Use a brush or cleaner pad if necessary to aid in penetrating dirt.
8. Rinse all surfaces with water, then spray with a sanitizer. Rinse off sanitizer with clean water using a hose. Allow surfaces to air dry, since wiping would defeat the purpose of sanitizing.
9. Replace all internal parts carefully so that they seat properly. This is necessary for proper case operation.
10. Turn ON power to the fans at breaker.
11. Replace product.


Cleaning Instructions Quarterly or Semiannually

1. Remove product; store it in another case or suitable walk-in cooler.
2. Remove wire racks and bottom pans. Cleaning them in the case with warm water and a soap solution, then rinse and set aside.
3. Turn off case power at breaker.
4. Flip up the fan plenum assembly to provide more room for cleaning in the case if necessary.
5. Remove all loose debris and food particles that may clog drain. Check drain to make sure it is not clogged. Do not force items down drain, use the drain catch to remove debris and dispose.
6. Remove honeycomb and price display moulding.
7. Clean all surfaces including shelves and honeycomb by spraying down water (preferably warm) and mild detergent. Use a brush or cleaner pad if necessary to aid in penetrating dirt.
8. Remove all the shelves and set aside then remove the back panels.
9. Clean the backside of the back panels in the case as you remove them.
10. Clean the newly exposed surfaces and the coil by spraying down with water (preferably warm) and a mild detergent solution.
11. Rinse the newly exposed surfaces and the coil with water then spray with a sanitizer. Allow surfaces to air-dry, since wiping would defeat the purpose of sanitizing.
12. Replace the back panels and shelves.
13. Rinse all surfaces with water, then spray with a sanitizer. Allow surfaces to air-dry since wiping would defeat the purpose of sanitizing.
13. Replace all remaining internal parts carefully so that they seat properly. This is necessary for proper case operation.
14. Turn ON power to the fans at breaker.
15. Replace product.

CLEANING HONEYCOMB ASSEMBLIES

Honeycombs should be cleaned every six months, or depending on store environment the honeycombs may need to be cleaned more often. Dirty honeycombs will cause cases to perform poorly.

The honeycombs may be cleaned with a vacuum cleaner. Soap and water may be used if all water is removed from the honeycomb cells before replacing. Be careful not to damage the honeycombs.



1. Remove honeycomb by pulling clip as shown above.
2. Clean and dry the honeycomb.
3. Honeycomb is symmetrical.
4. After cleaning, replace honeycomb. Ensure clip is centered and engaged along full-length of honeycomb.

Damaged honeycomb must be replaced.

CLEANING MIRRORS

Mirrors are sheets of clear glass that have very thin reflective and protective coatings applied to one side. These coatings are susceptible to deterioration if certain cleaning solutions and even water are allowed to come in contact with them. Every precaution should be taken to keep all liquids away from the coated side of the mirrors. If liquids are allowed to flow along the face side of the mirror to its edge, the liquid can seep up between the coating and the glass, causing serious damage.

To Help Prolong the Life of the Mirrors:

- Use only mild cleaning solutions that do not leave residue, such as a weak (10%) solution of vinegar and water.
- Do not spray liquids on the mirrors. Away from food, dampen the cleaning cloth, then use the cloth to wipe the mirror.
- Wipe water from the mirrors immediately to prevent difficult to remove water spots and also to prevent the water from reaching the mirror's edge.
- Never use dirty cloths, scrapers or any other abrasive materials for cleaning.

⚠ WARNING

- » Product will be degraded and may spoil if allowed to sit in a non-refrigerated area.
- » All products in the case should be removed and stored in a cooler at the appropriate temperature before cleaning the interior of the case.

⚠ WARNING

- » Do not use HOT water on COLD glass surfaces. This can cause the glass to shatter and could result in personal injury. Allow glass fronts, ends and service doors to warm before applying hot water.

REMOVING INTERIOR BACK PANELS

The interior back panels may be removed for cleaning and to gain access to the evaporator coils. Remove the rear interior back panels as follows:

1. Disconnect the electrical power to the merchandiser.
2. Unplug shelf lights and insert plastic protective cap. Remove shelving.
3. Remove the lower panel first: lift the panel up, then pull forward and out.
4. Remove the top panel.



5. Replace panels in reverse order, starting with the top panel.

CLEANING UNDER MERCHANDISERS

- Remove splashguards not sealed to floor.
- Use a vacuum with a long wand attachment to remove accumulated dust and debris from under the merchandiser.

CLEANING COILS

Never use sharp objects around coils!

Use a soft brush or vacuum brush to clean debris from coils. Do not puncture coils! Do not bend fins. Contact an authorized service technician if a coil is punctured, cracked or otherwise damaged.

ICE in or on the coil indicates the refrigeration and defrost cycle is not operating properly. Contact an authorized service technician to determine the cause of icing, and to make adjustments as necessary. To maintain product integrity, move all product to a cooler until the unit has returned to normal operating temperatures.

- Do not puncture coils!
- Do not bend fins. Contact an authorized service technician if a coil is punctured, cracked, or otherwise damaged.
- Do NOT use chlorine or ammonia-based cleaners to clean aluminum coils.

CLEANING STAINLESS STEEL FRONT RAILS

Use non-abrasive tools, and always polish with grain of the steel. Use alkaline chlorinated or non-chlorine containing cleaners. Do not use cleaners containing salts as this may cause pitting and rusting of the stainless steel finish.

Clean frequently to avoid build-up of hard, stubborn stains. Rinse and wipe dry immediately after cleaning. Never use hydrochloric acid (muriatic acid) on stainless steel.

REMOVING SCRATCHES FROM BUMPER

Most scratches and dings can be removed using the following procedure.

- Use steel wool to smooth out the surface area of the bumper.
- Clean area.
- Apply vinyl or car wax and polish surface for a smooth glossy finish.

BEFORE BEGINNING ANY SERVICE OR REPAIR:

Use a hand-held propane leak detector (“sniffer”) to ensure no propane is present in the immediate area, the inside of the display case and the inside of the refrigeration system.

Keep the area clear of all customers and non-essential or unauthorized personnel.

Verify that all repair parts are identical models to the ones they are replacing. Failure to do so can result in an explosion, death, injury and property damage.

Brazing must not begin before all propane has been cleared from the immediate area, the in-side of the displays case and the inside of the refrigeration system.

If a leak is detected, follow store safety procedures.

It is the store’s responsibility to have a written safety procedures in place. The safety procedure must comply with all applicable codes such as local fire department’s codes.

At minimum, the following actions are required:

- Immediately evacuate all persons from the store, and contact the local fire department to advise them that a propane leak has occurred.
- Call Hussmann and/or a qualified service agent and inform them that a propane sensor has detected the presence of propane.
- Do not let any persons back into the store until the qualified service technician has arrived and that technician advises that it is safe to return to the store.

 **DANGER**

- » Only Hussmann service technicians or technicians qualified to handle R-290 (propane) refrigerant should service or repair this R-290 (propane) equipment. Failure to follow instructions can result in an explosion, death, injury and property damage.

- The propane gas used in the unit has no odor. The lack of smell does not indicate a lack of escaped gas.
- A hand-held propane leak detector (“sniffer”) should be used before any repair and/or maintenance is attempted. All repair parts must be identical models to the ones they are replacing.
- No open flames, cigarettes or other possible sources of ignition should be used inside the building where the units are located until the qualified service technician and/or local fire department determines that all propane has been cleared from the area and from the refrigeration systems.

SERVICE AND REPAIR

- Prior to beginning work on systems containing FLAMMABLE REFRIGERANTS, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the refrigerating system, complete the following steps prior to conducting work on the system.
- Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.
- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e., nonsparking, adequately sealed, or intrinsically safe.
- If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available on hand. A dry chemical or CO₂ fire extinguisher should be adjacent to the charging area.
- No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment shall be surveyed to make sure that there are not flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times, the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.

The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:

- a) The actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed;
- b) The ventilation machinery and outlets are operating adequately and are not obstructed;
- c) If an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
- d) Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- e) Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

CHECKS TO ELECTRICAL DEVICES

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment, so all parties are advised.

Initial safety checks include:

- a) That capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- b) That no live electrical components and wiring are exposed while charging, recovering or purging the system;
- c) That there is continuity of earth bonding.

REPAIRS TO SEALED COMPONENTS

During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.

Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

Ensure that the apparatus is mounted securely. Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

REPAIR TO INTRINSICALLY SAFE COMPONENTS

Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.

Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

Replace components only with parts specified by the manufacturer. Other parts can result in the ignition of refrigerant in the atmosphere from a leak.

NOTE:

The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

CABLING

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges, or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

DETECTION OF FLAMMABLE REFRIGERANTS

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used. The following leak detection methods are deemed acceptable for all refrigerant systems: Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity might not be adequate, or might need recalibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25% maximum) is confirmed.

Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine can react with the refrigerant and corrode the copper pipe-work.

NOTE:

Examples of leak detection fluids are bubble method and fluorescent method agents.

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

REFRIGERANT REMOVAL AND EVACUATION

When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:

- a) Safely remove refrigerant following local and national regulations;
- b) Purge the circuit with inert gas;
- c) Evacuate;
- d) Purge with inert gas;
- e) Open the circuit by cutting or brazing.

DANGER

- » Only Hussmann service technicians or technicians qualified to handle R-290 (propane) refrigerant should service or repair this R-290 (propane) equipment. Failure to follow instructions can result in an explosion, death, injury and property damage.

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and that ventilation is available.

REFRIGERANT RECOVERY

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labeled for that refrigerant (i.e., special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

STEPS TO RECOVER REFRIGERANT

1. Make sure you are in a well ventilated area before making any service or repair to the refrigeration system.
2. Disconnect all power sources from the system. Some systems may have more than one plug or power supply.
3. Tap system with line tap valves, attaching gauges to the high and low sides of the system.



**refrigeration
line tapping
valve**

4. Connect hose to an evacuated recovery tank. Open refrigeration gauges and recovery tank.



5. With the suction valve in vacuum, the refrigerant will be recovered into the recovery tank.
6. Once recovered, close the tank valve and remove the gauge from the tank and connect nitrogen tank to the system to purge it with nitrogen.
7. Pull vacuum to a minimum of 200 microns or lower.

CLEANING AND FLUSHING


See Section 2, Page 2-17.

4. Connect hose to an evacuated recovery tank. Open refrigeration gauges and recovery tank.

REPLACING FILTER DRIER AND CAPILLARY TUBE

Use only Hussmann approved replacement parts. Use of unapproved parts may cause poor case performance.

Filter drier should be horizontal. If original filter drier is not in a horizontal position, an additional elbow fitting may be installed between the heat exchanger and filter drier.



REFRIGERANT CHARGING PROCEDURE

A calibrated scale with +/-2 gram accuracy must be used to charge the system. The charge amount is shown on the serial label. Only R-290 grade refrigerant can be used. Standard propane does not meet the purity/moisture content of R-290, and therefore cannot be used to charge cases.

No gas charge adjustments are allowed. When connecting hoses between the refrigeration system, manifold gauges, and refrigerant cylinder, ensure that the connections are secure and there are no potential sources of ignition nearby. Ensure that contamination of different refrigerants does not occur when using charging equipment.

Use dedicated hoses to service R-290 (propane) refrigeration systems. Hoses or lines should be as short as possible to minimize the amount of refrigerant contained in them.

Ensure that the refrigeration system is properly grounded prior to charging the system with refrigerant, to avoid the potential for static build-up.

In addition to conventional charging procedures, the following requirements shall be followed:

- a) Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- b) Cylinders shall be kept in an appropriate position according to the instructions.
- c) Ensure that the REFRIGERATING SYSTEM is earthed prior to charging the system with refrigerant.
- d) Label the system when charging is complete (if not already).
- e) Extreme care shall be taken not to overfill the REFRIGERATING SYSTEM.



Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

Extreme care must be taken not to overfill the refrigeration system. After charging, carefully disconnect the hoses, attempting to minimize the quantity of refrigerant released. Further leak check the service ports, hoses, refrigerant tanks. The service ports shall be checked for leaks using a hydrocarbon leak detector with a sensitivity of 3 grams/year (0.106 oz/year) leak rate.

Thoroughly leak check the service ports. If no leak is present, use a pinch-off tool to close the ends of the service tubes before brazing them shut. If a Schrader valve is used on the compressor service tube, it must be removed and the previous steps followed in order to braze the service tube shut.

⚠ WARNING

» Follow leak check procedures carefully in order to ensure service tubes are not leaking before brazing.

BOTTOM LINER REPAIR

Insight merchandisers have bottom liners, which are made of a high density polyethylene material (HDPE). Repairs may be made if the bottom liner becomes damaged. Follow the illustrations at right to repair the liner.

For minor repairs:

Minor repairs consist of deep scratches and tears that are no more than 1/8 inch thick.

1. Remove all product, and disconnect power to the case that is to be serviced. Locate the damaged area of the liner. Clear and clean the area, then wipe it dry.
2. Use an electric hot air gun to heat the tear. Heat to 600°F (316°C). Solder the tear with 1/8 inch filler welding rod, made from HDPE. Ensure no voids or skips in completed bead.








Forthoff Mini Electric Hot Air Gun
(120V 1300W)

3. Let the area cool, then buff the area flat. A 5-inch, 80 grit disc works well for this. The repair is now complete.

For major repairs:

1. For repairs with larger size gashes or holes, a piece of HDPE may be cut into a square as shown in (F) at right. (The square HDPE shown in the photo is white for clarity.)
2. Remove all product and disconnect power to the case that is to be serviced. Locate the damaged area of the liner. Clear and clean the area, then wipe it dry. Ensure no voids or skips in completed bead.
3. The square is then tacked at all four corners using the hot air gun.
4. Solder with 1/8 inch filler welding rod around the perimeter of the HDPE square.
5. Buff the area flat if needed. The repair is now complete.



⚠ WARNING

- » Always wear protective clothing when operating hot air gun, such as fire resistant gloves and arm guards. Hot air gun operates at extremely high temperature and could cause serious burns. Always have fire protective gear on hand in case of fire.
- » To avoid serious injury or death from electrical shock, always disconnect the electrical power at the breaker when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.

TROUBLESHOOTING

Problem	Possible Cause	Possible Solution
Case temperature is too warm.	Ambient conditions may be affecting the case operation.	Check case position in store. Is the case located near an open door, window, electric fan or air conditioning vent that may cause air currents? Case must be located minimum 15 ft away from doors or windows. Cases are designed to operate at 55% Relative humidity and a temperature of 75°F.
	Discharge air temp is out of spec.	Check evaporator fan operation. Check electrical connections and input voltage.
		Fans are installed backwards. Check airflow direction.
		Make sure fan blades have correct pitch and are per specification.
		Check to see that fan plenum is installed correctly. It should not have any gaps.
	Case is in defrost.	Check defrost settings. See Technical Data Sheet.
	Product is outside of the load limit area, blocking airflow.	Redistribute product so it does not exceed load limit. There is a sticker on the inside of the case indicating the maximum load limit.
Coil is freezing over.	Return air is blocked, make sure debris is not blocking the intake section.	
	Coil close-offs are not installed. Inspect coil to make sure these parts are on the case.	
	Clean coil.	
Case temperature is too cold.	Condensing coil or evaporator coil is clogged or dirty.	
	The t-stat temp is set too low.	Check settings. See Technical Specifications on the data sheet.
	Ambient conditions may be affecting the case operation.	Check case position in store. Is the case located near an open door, window, electric fan or air conditioning vent that may cause air currents? Case must be located minimum 15 ft away from doors or windows. Cases are designed to operate at 55% Relative humidity and a temperature of 75°F.

TROUBLESHOOTING CONTINUED

Problem	Possible Cause	Possible Solution
Water has pooled under case.	Case drain is clogged.	Clear drain.
	PVC drains under case may have a leak.	Repair as needed.
	Case tub has unsealed opening.	Seal as needed.
	If the case is in a line-up, case to case joint is missing or unsealed.	Install case to case joint and seal as needed.
	Evaporator pan is overflowing (if applicable).	Check electrical connection to evaporator pan. Check float assembly, it should move freely up and down the support stem. Clear any debris.
	Case is not level.	Level the case.
	Drain screen is plugged.	Clean drain screen and remove any debris.
Case is not draining properly.	Drain or P-trap is clogged.	Clear any debris.
Frost or ice on evaporator coil.	Evaporator fans are not functioning.	Check electrical connections.
	Defrost clock is not functioning.	Case should be serviced by a qualified service technician.
	Coil is freezing over.	Return air is blocked, make sure debris is not blocking the intake section. Coil close-offs are not installed. Inspect coil to make sure these parts are on the case.
Lights do not come on.	LED Driver / light socket wiring.	Check electrical connections. See Electrical Section and check wiring diagram.
	LED Driver needs to be replaced.	Case should be serviced by a qualified service technician. See Electrical Section.
	LED fixture socket / connection needs to be replaced.	Case should be serviced by a qualified service technician.
	LED fixture needs to be replaced.	See Maintenance Section.
	Light Switch needs to be replaced.	Case should be serviced by a qualified service technician.


REPLACING FAN MOTORS

See Appendix for separate fan motor replacement instructions if motor harness connector is different than the one shown below.


Should it ever be necessary to service or replace the fan motors or blades, be certain that the fan blades are reinstalled correctly.

To access and replace fan motor:

1. Turn off case power at breaker.
2. Remove bottom display pans.
3. Unpack new motor/harness assembly and set aside outside of case.
4. Remove screws holding existing fan motor bracket assembly to plenum, and remove assembly from plenum.
5. Disengage and unplug existing motor harness connector; remove existing motor.
 - A. Grasp the plug and receptacle, and apply slight pressure to pull apart. The connector should not separate without depressing the locking tab.



6. Taking care to avoid any existing moisture in the case, IMMEDIATELY connect and lock new motor harness as follows:
 - A. Align the plug and receptacle, and push together until the locking tab engages. (Locking tab must engage in the window of receptacle and not separate.)



⚠ WARNING

— LOCK OUT / TAG OUT —

- » To avoid serious injury or death from electrical shock, always disconnect the electrical power at the main disconnect when servicing or replacing any electrical component. This includes, but is not limited to, such items as doors, lights, fans, heaters, and thermostats.
- » Warning: Before obtaining access to terminals, all supply circuits must be disconnected.

7. Place new fan motor assembly back into plenum, and reinstall screws to secure.
8. Turn on power.
9. Verify that motor is working and blade is turning in the correct direction.
10. Close air gaps under fan plenum. Warmer air moving into refrigerated air reduces effective cooling. If the plenum does not rest against the case bottom without gaps, apply foam tape to the bottom of the fan plenum to reduce improper air movement. Use silicone sealant to close other gaps.
11. Replace display pans. Bring merchandiser to operating temperature before restocking.



⚠️ WARNING

STOP - DO NOT UNPLUG

The fan motor harness plug **MUST** be properly secured in order to perform at its IP68 rating. This connection should **ONLY** be disconnected / connected by a qualified contractor and **ONLY** in the event of a fan motor replacement. The fan motor harness plug should not be disconnected/connected in performing any other cleaning, service or repair. Refer to the installation, operation and services manual for sequence of repair. All case cleaning & maintenance procedures should be performed with the power disconnected at the breaker. Failure to adhere to these instructions can lead to damage to the unit and creates a risk of flammability.

REPLACING DOOR HANDLES

(for cases with doors)

These doors have glued on studs. If the handle is broken it should be replaced along with the stud.

1. Remove stud from door (if needed). Wear gloves to safely remove the stud using a razor blade. A hammer could be used to assist with removing the stud by gently tapping on razor blade.
2. Remove excess glue. Wearing gloves, use razor blade to remove the excess glue from the door.
3. Clean the glass surface. Apply isopropyl alcohol to the surface of the glass and wipe using a paper towel until dry.
4. Using a new stud, apply isopropyl alcohol to the surface of the stud and wipe using a paper towel until dry.

Note: Do not use original studs, they may contain residue that prevents the stud from adhering to the glass.

Replacement Parts


Kit	Description	Components in Kit	Order
ABB91	Retrofit studs only	2 studs only, 2 sets screws, instructions	Replace 1 or 2 studs only - have original handle
ABB92	Retrofit black handles and studs	2 studs, one black handle assembly, 2 set screws	Replace black handle, 2 studs, 2 set screws
ABB93	Retrofit black handles and studs	2 studs, one gray handle assy, 2 set screws	Replace gray handle, 2 studs, 2 set screws
ABB94	Glue and Template	adhesives and template	Template and adhesives for repairing 4 to 6 handles.



1.



2. & 3.



4.

Tools and Supplies Needed:

Provided Items

- EcoVision Stud: P/N 3119359
- Glue: Permatex Kit (adhesive and activator)
- Template

Not Provided Items

- Hammer, if needed
- Razor
- Isopropyl Alcohol
- Paper Towels
- Tape

5. Open Permatex package. Clean the area, then attach template.

Note: Repair one handle at a time. Complete all steps on a single handle before repairing additional handles. The temperature of the glass should be between 65 and 85 degrees, and door should be dry when applying the stud

6. Apply Permatex to the stud.

Let stud cure for 30 minutes, then reinstall handle(s), and tighten set screw(s) until they are flush with handle.



Adhesive should repair 4 to 6 handles.

5.



Open Package

5.



Open/cleaner activator towelette. Towelette is to remain in package. Read directions on towelette package.

5.



Wipe the area where the stud goes with a towelette. Allow to dry for 1 minute. Do not touch glass again.

5.



Attach template to door over existing stud location. Use tape or clamp to secure.

5.



6.

Wipe the flat surface of the stud. Allow to dry for 1 minute. Do not touch clean surface again.




6.

Remove cap from adhesive.



6.

Cut tip of adhesive.



6.

Apply two drops of adhesive to stud only, none to the glass.



6.

By hand, firmly press the stud to the glass, and hold for one minute.



6.

Wipe away any excess glue with isopropyl alcohol. Allow to set for 30 minutes. Reattach handle.

DECOMMISSIONING

DECOMMISSIONING

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- a) Become familiar with the equipment and its operation.
- b) Isolate the system electrically.
- c) Before attempting the procedure, ensure that:
 - i. Mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - ii. All personal protective equipment is available and being used correctly;
 - iii. The recovery process is supervised at all times by a competent person;
 - iv. Recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with instructions.
- h) Do not overfill cylinders (no more than 80% volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.

Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

WARRANTY

To obtain warranty information or other support, contact your Hussmann representative or visit:

<https://www.hussmann.com/services/warranty>.

Please include the model and serial number of the product.

For questions about your equipment, please contact our Technical Support Team at 1-866-785-8499

For general support or service calls, contact our Customer Support Call Center at 1-800-922-1919

For ordering aftermarket warranty parts, call 1-855-HussPrt (1-855-487-7778) or email the following address:

Hussmann_part_warranty@hussmann.com

REVISION HISTORY

REVISION A: Original Issue

REVISION B: Added 4 ft and 6 ft models; Revised wiring diagrams and NEMA plug

REVISION C: Revised refrigerant charge data; Added model ID6SL-WE; Revised minimum floor areas; Removed coil repair procedure, and rotating cleaning products statement; Revised door handle replacement procedures



Scan the QR code on your mobile device to access additional product information or order parts.

Parts may also be ordered at:

parts.hussmann.com

Call toll free: 1.855.487.7778

We reserve the right to change or revise specifications and product design in connection with any feature of our products. Such changes do not entitle the buyer to corresponding changes, improvements, additions or replacements for equipment previously sold or shipped.