



OPERATION MANUAL

042016

FOOD MIXER

Model
ERGO60
ERGO100
ERGO150

Caution -READ BEFORE OPERATING- Caution

Varimixer recommends that mixer operators be at least 18 years of age and be thoroughly trained on the use, cleaning and lubrication of the mixer.

This manual should be seen as an integral part of the mixer and should be kept by the machine throughout its working life.

Varimixer recommends that the following precautions be adopted to help make the mixer operation safer and more efficient.

- All operators should be at least 18 years of age.
- All operators should be thoroughly trained before being allowed to operate the mixer.
- NEVER reach into the bowl when the mixer is running.
- Do not wear loose clothing or rings while operating the mixer.
- Stop the mixer and lower the bowl before adding ingredients, scraping the bowl, removing the agitator, or removing the product.
- Stop the mixer before removing or installing attachments into the drive hub.
- Do not attempt to assemble or disassemble attachments while mounted into the drive hub.
- Always use the pusher plate with the slicer/meat grinder attachments.
- NEVER bypass the safety mechanisms supplied on the mixer. Doing so can cause injury and is the responsibility of the user to insure these safety mechanisms are operating properly.

Before the machine is commissioned, it is important to read these instructions thoroughly.

The manufacturer may update the product manual without updating this copy of the manual



LIMITED WARRANTY

Varimixer warrants its commercial mixers to the original purchaser against defects in material or manufacture for a period of one year from the date of original purchase, subject to the following exclusions and limitations. The warranties provided by Varimixer do not apply in the following instances:

EXCLUSIONS

1. In the event that the equipment is improperly installed. Proper installation is the responsibility of the installer, proper installation procedures are covered in the Varimixer Spare Parts and Operations Manual.
2. In the event that the equipment is improperly maintained. Proper maintenance is the responsibility of the user. Proper maintenance procedures are covered in the Varimixer Spare Parts and Operations Manual.
3. In the event that failure or malfunction of the appliance or any part thereof is caused by abnormal use or is otherwise not attributable to a defect in material or manufacture.
4. In the event that the appliance, by whatever cause, has been materially altered from the condition in which it left the factory.
5. In the event that the rating plate has been altered or removed.
6. On parts which would normally be worn or replaced under normal conditions.
7. With regard to adjustments and/or calibrations. Checking of and changes in adjustments and calibrations are the responsibility of the installer, Proper installation is the responsibility of the installer, proper installation procedures are covered in the Varimixer Spare Parts and Operations Manual.

If any oral statements have been made regarding the appliance, such statements do not constitute warranties and are not part of the contract of sale. This Limited Warranty constitutes the complete, final and exclusive statement with regard to warranties.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ALL OTHER WARRANTIES WHETHER WRITTEN, ORAL OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE OR WARRANTY AGAINST LATENT DEFECTS.

LIMITATIONS OF LIABILITY

In the event of warranty claim or otherwise, the sole obligation of Varimixer shall be the repair and/or replacement at the option of Varimixer, of the appliance or component or part thereof. Such repair or replacement shall be the expense of Varimixer *except* that travel over 100 miles or two hours, overtime, and holiday charges shall be, the expense of the purchaser. Any repair or replacement under this warranty does not constitute an extension of the origin, warranty for any period for the appliance or for any component part thereof. Parts to be replaced under this warranty will be repaired or replaced at the option of Varimixer with new or functionally operative parts. The liability of Varimixer on any claim of any kind, including claims based on warranty, expressed or implied, contract, negligence, strict liability or any other theories shall be solely and exclusively the repair or replacement of the product as stated herein, and such liability shall not include, and purchaser specifically renounces any rights to recover, special, incidental, consequential or other damages of any kind whatsoever, including, but not limited to, injuries to persons or damage to property, loss of profits or anticipated profits, or loss of use of the product.

TO SECURE WARRANTY SERVICE

If you claim a defect covered by this Limited Warranty, first direct your claim to the local Authorized Service Agency, giving model, serial and code numbers, voltage, a description of the problem and your sales slip. If this procedure fails to be satisfactory to you, you may write to the Varimixer National Service Manager, 14240 South Lakes Drive, Charlotte, NC 28273; you should include the information listed above.

CONTENTS:

GENERAL:	2
SAFETY:	2
INSTALLATION OF NEW MIXER:	2
CONSTRUCTION OF THE MIXER:	3
POSITIONING THE BOWL IN THE MIXER:	3
MAXIMUM CAPACITY OF THE MIXER:	4
CORRECT USE OF TOOLS:	4
MAINTENANCE AND LUBRICATION:	4
CLEANING:	4
RECOMMENDED MAXIMUM SPEEDS:	4
CONTROL PANEL VL4:	5
REMIX FUNCTION:	5
VL4 CONTROL PANEL - SURVEY OF VARIOUS OPERATING SITUATIONS:	6
OPERATION OF THE MIXER:	8
OVERLOAD:	9
PROCEDURE IN CASE OF OVERLOADING:	9
HOW TO BRING A MIXER TO STOP:	9
READING THE NUMBER OF OPERATING HOURS/DAYS/YEARS:	9
RESETTING THE CONTROL SYSTEM:	9
MECHANICAL COMPONENT ERROR:	10
ERROR CODES SHOWN IN DISPLAY:	10
CALL UP AN ERROR LOG OF THE LAST 10 DISCONNECTIONS:	11
ERROR CODES DISPLAYED IN THE ERROR LOG:	11
ADJUSTING OF BOWL CLAMPING AND CENTERING:	12
ELECTRICAL-COMPONENTS:	14
SAFETY CIRCUIT:	15
ELECTRICAL DIAGRAMS:	16
TO REPLACE A BELT:	18
TO REPLACE A LIFTING ACTUATOR:	18
REPLACING THE REED CONTACTS:	18
FINE-TUNING REED CONTACTS AND CE MICROSWITCH:	18
LUBRICATION OVERVIEW:	20

GENERAL:

In case of complaints, please contact your dealer.

The guarantee does not cover faults resulting from faulty operation, overloading and lacking observance of directions of maintenance.

It should be checked that all loose parts are delivered with the mixer such as bowl, tools, and rubber feet.

SAFETY:

The constant noise level of the workplace of the operator is lower than 70 dB (A).

In all cases where the parts of the mixer are moving and the bowl screen is not closed, it takes two hands to operate the mixer.



The mixer is designed for manufacture of products which do not during processing cause reactions or emit substances which may be detrimental to the user.



Putting your fingers in the bowl while the mixer is running may cause injuries.



The mixer must be bolted securely to the floor.

Load per leg not to exceed:

**ERGO60 - 2500 N ERGO140 - 4000 N
ERGO100 - 3200 N**

INSTALLATION OF NEW MIXER:

Installation and securing:

The mixer must be fitted with rubber feet, which neutralize shaking. Spacers can be inserted under the mixer's feet, if the floor is not completely even.

Connection to power:

Before the mixer is connected to power, it should be checked that the voltage and frequency printed on the machine label is correct in relation to the place of installation. The machine label is placed at the top right side of the mixer.

Note: to be installed by a qualified electrician.



Of functional and safety reasons, the machine must be connected to earth!

Voltage at the installation: 50/60 Hz.			The machine label				Remarks:
Power: Phases x voltage	With neutral	Earth	Voltage	Phases	Use neutral	Use earth	
3 x 380-480V +/-10%	no	Yes	400V	3	no	Yes	Of functional and safety reasons, the machine <u>must</u> be connected to earth!

CONSTRUCTION OF THE MIXER:

VL-4 control panel with Remix function

See page 7 for an explanation of the panel.

Emergency stop

Bowl lift and "JOG"-function:

The mixer is provided with a "JOG"-function.

Before the bowl reaches its top position, the tool starts rotating to dig its way into the ingredients.

The bowl lift requires two-hands operation for safety reasons.

Magnetic sensor, which is activated by the screen when the screen is closed.

Bowl screen – removable.

The screen must be closed before the tool can rotate.

The bowl can be raised with the screen open, but it will stop where the tool normally starts to rotate. The screen must be closed and two hands are required to lift the bowl the rest of the way.

Bowl clamping system with inductive sensor:

At the back of the right-hand bowl arm is an inductive sensor which is activated when the bowl is correctly positioned in the bowl clamping system (at the very back of the bowl arms). This sensor must be activated in order for the mixer to operate. If there is no contact between the bowl and the inductive sensor, the bowl cannot be lifted. **EE: 3** will appear in the display, see "Error codes shown in display" on page 12.

The bowl arms can move a little in case of maximum loading.

POSITIONING THE BOWL IN THE MIXER:


The bowl arms must be lowered to their lowest position and the bowl pressed all the way to the back of the bowl arms. If there is no contact between the bowl and the inductive sensor, the bowl cannot be lifted. **EE: 3** will appear in the display, see "Error codes shown in display" on page 10.

If you have a bowl with "ears" it is important to place it correct in the mixer.



Note: It is very important to orientate the bowl correctly so that the "third ear" is turned in towards the mixer

Left "ear"



Right "ear"

MAXIMUM CAPACITY OF THE MIXER:

Capacities per mix	ERGO60	ERGP100	ERGO150
Dough, Bread 65%AR	90 lbs.	155 lbs.	190 lbs.
Dough, Bread 50%AR	75 lbs.	135 lbs.	175 lbs.
Dough, Donut - Yeast	70 lbs.	150 lbs.	170 lbs.
Dough, Donut - Cake	60 lbs.	140 lbs.	225 lbs.
Pie Dough	58 lbs.	95 lbs.	135 lbs.
Cookie, Dough	50 lbs.	105 lbs.	160 lbs.
Muffins	60 lbs.	125 lbs.	195 lbs.
Mashed Potatoes	46 lbs.	76 lbs.	110 lbs.
Pancakes, Waffles	28 qts.	44 qts.	50 qts.
Whipped Cream	12 qts.	20 qts.	32 qts.
Cake, Layer	69 lbs.	125 lbs.	175 lbs.
Eggs & Sugar	28 lbs.	57 lbs.	80 lbs.
Icing, Fondant	40 lbs.	76 lbs.	105 lbs.
Egg Whites	2 qts.	3 qts.	4 qts.
Cake, Cup	81 dz.	178 dz.	250 dz.
Cookies, Sugar	115 dz.	171 dz.	240 dz.

AR = Absorption Ratio (%AR)
(Liquid in % of solids)

Water weights

1 Gallon	=8.33 lbs.
1 Quart	=2.08 lbs.
1 Pint (16 oz.)	=1.04 lbs.
1 Cup	= .52 lbs.

Batch size and/or speed reduction may be necessary due to one of the following conditions:

1. High Gluten Flour-Reduce batch size by 10%
2. AR % under 40%-Reduce batch size by 10%
3. Water temp under 65 Degrees F
4. USE OF ICE REQUIRES A 10% REDUCTION IN BATCH SIZE.
5. Speed should not exceed 100 RPM when mixing dough.

CORRECT USE OF TOOLS:

Recommended applications for tools:

See the section “Maximum capacity of the machine”.



Whips should not be struck against hard objects as e.g. the edge of the bowl. This will make the life of the tool shorter due to increasing deformity.

For production of mashed potatoes the special wing whip or the reinforced whip should be used, alternatively use the beater and the whip.

MAINTENANCE AND LUBRICATION:

See lubrication overview on **page 22**.

CLEANING:

The mixer should be cleaned daily or after use.

Press the emergency stop before wiping the control panel.

The mixer should be cleaned with a soft cloth and clean water. Sulphonated soaps should be used with caution as they destroy the mixer's lubricants.




Never use high pressure cleaning for the mixer.


Parts made of aluminum should not be used to strongly acidic, highly alkaline or highly salty food-stuffs, which may attack aluminum without coating

Tools of aluminium must not be washed with strong alkaline detergents - The PH value should be between 5 and 8

RECOMMENDED MAXIMUM SPEEDS:



CONTROL PANEL VL4:



REMIX FUNCTION:

The special Remix-function is a shortcut to programming of recipes. While the mixer is operated, all commands are stored, and when a recipe is finished and is pushed, it is possible to store the entire recipe under a program number.

- There are 20 program numbers: 1, 2, 3, 4 - 11, 12, 13, 14 - 21, 22, 23, 24 - 31, 32, 33, 34 - 41, 42, 43, 44
- A program cannot be deleted, but can be replaced.
- The programs are not deleted in case of no power

How to store a program:

Program number 12 in this example

- Start by pressing .
- Run the whole recipe, including pauses, changes of speed and automatic lowering of the bowl.
- Press to stop the mixer.
- Keep depressed; the display shows **P** .
- Continue pressing and press **1** and **2** as well, **P12** is shown on the display
- Release and the program will be stored as number 12


How to run a program:

Program number 12 in this example:

- First a short push on and then on **1** and **2**. Now **P12** appears in the text field and immediately thereafter the total length of the program will be shown. The program is run by pushing .
- If the speed or the time is changed, when running a program, **the program will be left** and the mixer must be run manually.
- If is pressed while a program is running, the mixer stops and **quits the program**.
- If the bowl screen is opened while a program is running, the mixer stops and **EE: 2** will be displayed. When the bowl screen is closed again, press twice; the first press eliminates the error code and the second press starts the mixer – **the program quits**.
- If the program is containing a pause, the mixer will stop and at the same time an acoustic signal is heard. It is now possible to lower the bowl and open the bowl screen. When the operator wants to restart the mixer, push and **the program will be resumed**.

VL4 CONTROL PANEL - SURVEY OF VARIOUS OPERATING SITUATIONS:

The following pictures show various operating situations and corresponding explanation:



If the field is activated while the mixer is running, the chosen operation time is reset and the speed is set to minimum. (The same when pushing emergency stop).


Activation of the field keeps the chosen values for operation time and speed.

The operation time and the speed can be changed while the mixer is running.

The operation time can be set to 90 min. as maximum.




There is no power connection to the mixer or the emergency stop has been activated - there is no light in the control panel.



There is power connection to the mixer and the bowl is not in its top position. The bowl can be raised by activating the fields and simultaneously - diodes in the fields are flashing! The mixer cannot be started until after the bowl has been raised to its top position.


The bowl can be lowered by activating the field .



The bowl is in its top position and the mixer is ready for operation by activation of the field .

Speed can be chosen. Operation time can be chosen by activating the fields or .

The bowl can be lowered by activating the field .




The mixer is ready for operation by activating the field .


The bowl can be lowered by activating the field .

One of the four fixed speeds is chosen by a short activation of the field - six diodes on the speed indicator are flashing.

5




The mixer is ready to run by activating the field .
Speed 2 is chosen.



An operation time has been chosen by activating the field .


The bowl can be lowered by pressing .


6




The mixer is running - green diode in the field  is constantly alight when the chosen speed has been reached.

The operation time can be changed by activating the fields  and .


The mixer can be stopped by activating the field .

By activating the field  the bowl is automatically lowered when the mixer stops.


7




The bowl screen has been opened while the mixer was running.
The bowl can be lowered.


When the bowl screen is closed and the operator presses  twice, the mixer starts at its lowest speed.

8





As figure 6, but automatic lowering of the bowl is selected by pressing .


9




The field  has been activated and the mixer is ready.

The time can be changed by activating the fields  or .

The bowl can be lowered by activating the field .

The mixer can be started by activating the field .

10




The mixer runs and an operation time has been indicated.

Automatic lowering of bowl at ended operation time has been chosen - see **position 6**.

When activating the field  or  automatic lowering of bowl is deactivated and can not be chosen again.

OPERATION OF THE MIXER:



Before starting the mixer:

Mount the required tool in the bayonet shaft. Place the bowl in the bowl arms and close the bowl screen.

To raise the bowl, activate the fields , and **simultaneously**, the activation to be continued until the bowl has reached its top position. When the bowl is approx. 20 cm from its top position, the tool will start to rotate in low speed. The rotation of the tool and the bowl will stop automatically when the bowl is in its top position.

The red diode in the field is now alight to show that the mixer is ready.

Start the mixer:

Activate the field to start the mixer.

Activate the field to increase the speed.

Activate the field to reduce the speed.

The speed indicator below the fields **1** to **4** shows the mixing speed of the tool.

Four fixed speeds:

For quick choice of speed, use the fields **1** to **4** .

Field **1** corresponds lowest speed.

Field **2** corresponds approx. 30% of maximum speed.

Field **3** corresponds approx. 60% of maximum speed.

Field **4** corresponds maximum speed.

Indication of operation time:

Before starting the mixer, an operation time for the mixer can be chosen by adjusting the time on and . If the field is activated for longer time, the speed is increased/reduced quicker.

Minutes and seconds are shown in the text field between and .

Automatic lowering of bowl:

Once the mixer has been started, the operator can make the mixer lower the bowl automatically when it stops by pressing . The diode in the field is flashing after the activation.

Inspection of the ingredients during operation:

If it is wished to stop the mixer without affecting the operation time, the field can be activated. The mixer will reduce speed and then stop, the operation time will also stop. If the guard is opened, the display shows **EE: 2** , but the operation time is displayed again when the guard is closed.

Close the bowl screen and press and the mixer will start at the lowest speed. The operation time continues from before.

Lowering of bowl:

When the ingredients in the bowl have been mixed, the mixer is stopped by activating the field . The bowl is lowered by activating the field . When the bowl has reached its bottom position, the bowl screen can be opened.

OVERLOAD:



Do not overload the mixer. Sticky and heavy doughs can overload the mixer. Overloading is further exacerbated if the speed of the mixing tool is increased beyond the recommended values or if a wrong mixing tool is used. Large lumps of fat or cooled ingredients must be cut into small parts before they are placed in the bowl.

*If the mixer is overloaded for an extended period, it will cut out. An error code will show on the display. Follow the instructions for **"Procedure in case of overloading"***


PROCEDURE IN CASE OF OVERLOADING:

- Push emergency stop.
- Open the bowl screen.
- Reduce the bowl contents.
- Close the bowl screen and release the emergency stop.
- If the error code is still shown on the display, see the **"Error codes"** section on **page 12**.

If the emergency stop has been activated while the mixer is running with a full bowl, it may be necessary to lower the bowl in order to empty it.

- Release the emergency stop to connect the power to the mixer.
- Lower the bowl and empty it.
- Now the mixer can be used as normal again.

HOW TO BRING A MIXER TO STOP:



If the mixer stopped after the bowl screen has been opened, it can be re-started by pressing  twice (the first press resets the mixer's safety switch).




The mixer should only be stopped using the emergency button if there is an emergency.

READING THE NUMBER OF OPERATING HOURS/DAYS/YEARS:

It is possible to read how long the mixer has been in operation (operation = tool revolving). The total time is read as a combination of hours, days and years; see below:

- Press the emergency stop
- Press  and the number of hours the mixer has been operating will be displayed, e.g.: if it shows 157, this means 1 hour and 57 minutes
- Press  and the number of years and days the mixer has been operating will be displayed, e.g.: if it shows 1120, this means 1 year and 120 days.

RESETTING THE CONTROL SYSTEM:

- Press the emergency stop
- Press  for 10 seconds.

MECHANICAL COMPONENT ERROR:

The bowl is too tight or too loose in the bowl arms.

Solution: “Adjustment of bowl clamping and centering”, **page 14**

The tool hits the sides of the bowl.



Solution: “Adjustment of bowl clamping and centering”, **page 14**

Abnormal noise from the lifting actuator:

Solution: Lubrication of actuator; see lubrication chart on **page 22**



ERROR CODES SHOWN IN DISPLAY:

The error codes shown on the display are from the motor or the frequency transformer:

Motor error codes:			
Code	Error	Solution	
EE1	The CE switch interrupted the safety circuit when the mixer started	Check that the CE switch is closed with the bowl in the top position	
EE2	The bowl screen is open	If the screen is opened while the tool is not rotating, the error code will be eliminated when the screen is closed. If the screen is opened while the tool is rotating, closing the screen and pushing  will eliminate the error code.	
EE3	The bowl is not correctly positioned, so the inductive sensor has not been activated	<p>Check that the bowl is positioned correctly – if the bowl ring has three “ears”, the middle ear must point in towards the body of the mixer, otherwise the bowl must be lowered again and turned to the correct position. (It is possible to lower the bowl even if the error code is displayed.)</p> <p>If/when the bowl is positioned correctly, push it right back into the bowl arms, the inductive sensor will then be activated and you can lift the bowl.</p> <p>If contact between the sensor and bowl is interrupted again, the error code will appear in the display.</p> <p>It is still possible to lift the bowl during the first 5 seconds when the error code is shown, after this the lifting movement will be deactivated.</p> <p>Push the bowl right back into the bowl arms again so that contact is re-established between the bowl and sensor. The error code will disappear and you can lift the bowl again.</p>	
EE4	The thermal sensor in the motor has overheated	Reduce the quantity of ingredients in the bowl.	
EE5	The overcurrent switch to the lifting motor has tripped. Once the cause of the problem is found and the problem has been fixed, reset the overcurrent switch by pressing the blue button on the switch, see ill. The overcurrent switch is in the electrical box		
	Reason: The bowl arms have reached the physical end stop but the lifting motor has not cut out.		<p>Check that the reed contacts, located on the outer tube of the lifting motor spindle, have been activated (the yellow diode on the contact illuminates) when the bowl arms are at the top or bottom.</p> <p>If the reed contacts do not activate, they must be replaced</p>
	Reason: The bowl has too great a quantity of ingredients.		Reduce the quantity of ingredients in the bowl
EE6	The panel is not connecting with the frequency transformer.	Check the connection.	
EE7	There is a fault with the frequency transformer.	Check the error log to ascertain the error code; see page 13	

CALL UP AN ERROR LOG OF THE LAST 10 DISCONNECTIONS:

The last 10 disconnections due to errors resulting in code **EE: 7** can be read on the mixer display:

- Press the emergency stop
- Press  and  to browse the log
- The diodes on the speed indicator light up. The age of the error is indicated by the diode that illuminates:
The first diode lights up – the last (most recent) error code is displayed
The second diode lights up – the second-last error code is displayed
The third diode lights up – the third-last error code is displayed, etc.

ERROR CODES DISPLAYED IN THE ERROR LOG:


Display on the mixer	Reason for error	User	Engineer	
		Fault correction	Frequency transformer display	Error description
1	Error in frequency transformer	Call the engineer	UU	DC bus undervoltage
2	Error in frequency transformer	Call the engineer	OU	DC bus overvoltage
3	Overloading of the frequency transformer	Reduce the quantity in the bowl	OI.AC	Overcurrent at drive output
4	Overloading of the frequency transformer	Reduce the quantity in the bowl	OI.br	Braking IGBT transistor overcurrent
6	1 phase of supply voltage missing	Call the engineer	ph.AC	Loss of a motor phase with brake enabled
7	??		OSP	Over speed
19	Overloading of the frequency transformer	Reduce the quantity in the bowl	it.br	Braking resistor overload I x t
20	Overloading of the motor	Reduce the quantity in the bowl	it.AC	Motor overload I x t
21	Overloading of the frequency transformer	Reduce the quantity in the bowl	Oht1	IGBT overheating detected by internal sensor
22	Overloading of the frequency transformer	Reduce the quantity in the bowl	Oht2	Internal braking resistor overheating detected by thermal sensor
24	Overloading of the motor	Reduce the quantity in the bowl	th	Motor thermal sensor has tripped
26	Error in frequency transformer	Call the engineer	O.Ld1	Overload on the +24V power supply or digital
27	Error in frequency transformer	Call the engineer	CL1	Loss of the current reference on analog input ADI1
28	Error in frequency transformer	Call the engineer	CL2	Loss of the current reference on analog input ADI2
29	Error in frequency transformer	Call the engineer	CL3	Loss of the current reference on analog input ADIO3
30	Connection broken between panel and frequency transformer	Call the engineer	SCL	Loss of serial link communication
31	Error in frequency transformer	Call the engineer	EEF	EEPROM trip or transfer problem with XPress-Key (drive and key version different)
33	Error in motor	Call the engineer	rS	Trip during measurement of the stator resistance
34	Error in frequency transformer	Call the engineer	Fbus	Disconnection of the fieldbus during operation or error detected by the bus option
35	Connection broken from safety circuit to frequency transformer	Call the engineer	Secd	Secure disable input trip
36	Error in voltage supply to the mixer	Call the engineer	Enc1	Loss of channel U
37	Error in voltage supply to the mixer	Call the engineer	Enc2	Loss of channel V
38	Error in voltage supply to the mixer	Call the engineer	Enc3	Loss of channel W

ADJUSTING OF BOWL CLAMPING AND CENTERING ERGO150:





In the rear part of the bowl arms (J) a shaft with an eccentric stud (K) has been mounted, on which the ball bearing is mounted. By turning the eccentric stud, the bowl arms can be opened and closed so that the clamping and the centering of the bowl can be adjusted. It has to be observed that the shaft is mounted in the bowl arm with a thread so that when the eccentric stud is turned, the whole shaft is turned out and in into the bowl arms. When exchanging the whole shaft, the right starting point for the adjustment must be found first. The ball bearing (L) must be in the middle of the guide plate (M) so that the width of the entire ball bearing is fitting tightly against the guide plate, and at the same time it has to be observed that the eccentric stud cannot hit the back plate when the adjustment has been finished.

In order to counteract that the eccentric shaft turns loose by itself when the mixer is working, the eccentric shaft must be self-tightening. In order to obtain this effect, the below drawings must be followed, on which the adjusting area for the left and the right bowl arm, resp. is shown.


First find the bowl centering, e.g. by mounting bowl and beater in the mixer, and turn the beater round with your hand, and measure the distance from the beater to the edge of the bowl.



- When adjusting the clamping and centering of the bowl, the bowl arms must be raised into working position. When exchanging the shaft with eccentric stud (K) the bowl arms must be lowered.
- First open the lock plate (N).
- Loosen the shaft counter nut (P), use span 46.
- Screw an M8 bolt with counter nut (R) into both the eccentric studs (K), and tighten the counter nuts. If the shaft with the eccentric stud has stuck in the bowl arm, it can be loosened with a key with the span 36.
- By turning the eccentric studs the clamping and the centering of the bowl can be adjusted.
- Remember to use the right adjusting area for right and left bowl arm. The drawings show the adjusting area for
- When the adjustment is correct, tighten the shaft counter nuts (P). Hold the bolt (R) while the shaft counter nut is tightened.
- Knock the lock plate (N) in position.
- Remove bolt and counter nut




ELECTRICAL-COMPONENTS:



SAFETY CIRCUIT:

Description of the SDI safety input on the Leroy inverter



Emergency switch



Safety relay



CE switch

Emergency switch, Safety relay contact and CE switch are fed directly through the PCB without any electronics involved!

SDI1 **SDI2**

Safety Input on FC in accordance with safety standard EN 954-1, category 1 (Secure inputs SDI1 and SDI2 will stop safely)


In normal operation, Emergency switch, Safety relay and CE switch will be closed to enable the Leroy Frequency inverter

Opening of Emergency switch, Safety relay or CE switch will safely shut down the inverter by disabling the safety inputs

Speciality is with the CE switch, as it will be overruled by the controller
 When operation the bowl to the top position, a JOG switch tells the controller that it will be OK to start the Inverter.
 A relay will be engaged to bypass the CE switch in this situation (Aux relay).
 When the bowl is in top position, the relay will be physically disconnected by the second contact in the CE switch, and also stopped by the controller, as it has reached the top.





Company	MOTRON A/S	Torsoevej 4, 8240 Risskov Denmark - +45 87388602
Project	<i>Wodschow Ergo 140</i>	Date:091115
Item	SAFETY FUNCTIONS	Rev.: 19
Page	2 / 2	Author: Sb
Comments		




AS WODSCHOW & CO Kirkebjerg Søpark 6 DK-2605 Brønby www.beavermixer.dk	Project title: Ergo 60 VL4 - Ergo 100 VL4 - Ergo 140 VL4 CE * Ergo 60 VL4 - Ergo 100 VL4 - Ergo 140 VL4 Page title: Main power	Subject name: / Drawing no.: / Const. (project/page): / Appr. (initial/date): /	Project rev.: Rev. 8 Page: 1
	File name: Ergo 60 VL4-B-CE	Last printed: 27-10-2015 Last corrected: 27-10-2015	Previous page: / Next page: / Number of pages: 5

208V AC - 380V AC
 220V AC - 400 V AC
 230V AC - 415 V AC
 250V AC - 440V AC

 3 x 400V AC + PE
 Power supply
 Max. 16A
 Customer supplied



Deep-switches must be in OFF-position, as they are not in use



A/S WODSCHOW & CO Kirkebjerg Søpark 6 DK-2865 Brønby www.beearmixer.dk	Project title: CE * Ergo 60 VL-4 - Ergo 100 VL-4 - Ergo 140 VL-4	Subject name: /	Project rev.: Rev. 8	Page: 2
	Page title: Control Voltage File name: Ergo 60 VL4.8-CE	Drawing no.: Const. (project/page): /	Last printed: 27-10-2015	Page rev.: Last connected: 27-10-2015

TO REPLACE A BELT:

The old belt can be removed by loosening the belt tightener.

Installing a new belt:

1. Place the belt in the wheel groove.
2. Tighten the belt using the belt tightener
3. Tighten the belt until the belt can be bent approximately 23/64" (dL) at a pressure of approx. 19 lb (F), see Fig. 2.
4. Run the machine with a regular production load for approximately 10 min.
5. Check the belt tension by measuring its elasticity. If the elasticity has changed, retighten as described in point 3.

The belt tension should be checked every 6 months.

If there is not enough belt tension, the belt will wear out quickly, and if there is too much tension, there is a risk that the life-span of the bearings will be considerably shortened.




Fig. 2. Belt tension.

TO REPLACE A LIFTING ACTUATOR:

Lift the bowl arms to the top position.

Lower the bowl arms to a pressure relief point set at approx. midway.



It is very important that the bowl arms are lowered to a pressure relief point before disassembling the lifting actuator.

Cut the power to the machine by removing the plug from the socket.

Remove the three plugs for the reed contacts on the actuator.

Remove the lifting actuator from the bowl arms by removing the pins and axle.

Remove the cotter pin that secures the actuator at the top.

Remove the cable to the actuator and lift the actuator out from the mixing machine.

Install the new actuator.

Connect the machine to the power supply.

If replacing the lowest actuator fittings, use Loctite 270 to tighten the fittings.

Then follow the section “**Fine-tuning the reed contacts and CE microswitch**”.

The lifting actuator has 3 proximity detectors (reed contacts) that check the position of the bowl.

REPLACING THE REED CONTACTS:

Remove the incorrectly charged contact and install the new contact according to Fig. 3. Connect the cable as shown in the illustration on page 14.

Follow the instructions below to secure the reed contact in the correct position.

FINE-TUNING REED CONTACTS AND CE MICRO-SWITCH:

Check that the location of the reed contacts matches up with the marks in Fig. 3.

Connect the reed contacts with the matching cables – see illustration on page 16.

Adjust the three contacts and the CE microswitch according to the following sequence:

1. Adjusting the top reed contact:

Contact **A** determines the top position of the bowl.

The contact must be positioned in accordance with the mark in Fig. 3.

Raise the bowl to the position corresponding to mark **X**, Fig. 5.

Adjust the top reed contact upwards until the reed LED lights up – it is important to stop adjusting once the LED lights up!

2. Adjusting CE-microswitch:

ERGO60 and **ERGO100**, se Fig. 4, page 24.

ERGO150, se Fig. 4a, page 24.

3. Adjusting the reed contact for the JOG function

Contact **B** determines where the machine’s JOG function starts, see also “Bowl lifting and JOG function” on page 3.

The contact must be positioned as shown in Fig. 3 and does not require any further adjustment.

4. Adjusting the bottom reed contact:

Contact **C** determines the bottom position of the bowl.

The contact must be positioned in accordance with the mark in Fig. 3.

Raise the bowl to the position that corresponds to mark **Y** in Fig. 5.

Adjust the bottom reed contact until the reed LED lights up – it is important to stop adjusting once the LED lights up





Fig 4 Adjusting the CE microswitch on ERGO60 and ERGO100:

The measurement **A** must be 1 1/2".





Fig 4a Adjusting the CE microswitch on ERGO150:

Loosen CE microswitch **D**.

Push the microswitch completely into the switch housing **E**.

Pull the microswitch back 3/64" so that there is 3/64" of air between the contact and the housing, see **F**.

Tighten the screws that hold the CE microswitch in place.



The distance **X** corresponds to the top position of the bowl, and the distance **Y** corresponds to the bottom position of the bowl. The distances are measured from the underside of the bayonet shaft to the surface of the bowl arms on which the bowl is resting.

LUBRICATION OVERVIEW:

Part	Location	Oil/grease	Explanation	Frequency
Bushings in the bowl arms	Item A, Fig.6	Organic oil or grease, e.g Texaco StartPlex EP	Remove the back cover. Lubricate the bowl arm axle with grease.	Per 5,000 batches or min. once yearly or in case of unusual noise.
Lifting guide	Item B, Fig.6	Organic oil or grease, e.g Texaco StartPlex EP	Remove the back cover. Lubricate the bearing and track with grease.	
Mixer head	Item C, Fig.6	Gearwheel and sprocket Molub Alloy 036SF Heavy or Castrol Grippa 355. Needle bearings should not be lubricated with this type of lubricant..	The mixer head may only be repaired by an authorised technician.	During repairs
Lifting actuator AK00131	Item D, Fig.6	Always use spindle grease: Mobilith SCH 460 from Mobil.	The gear of the actuator is lubricated for life and does not need to be serviced. The spindle and the spindle nut in the actual actuator (Fig 6a) are not lubricated for life and therefore need relubricating. The actuator is thoroughly lubricated on delivery. Relubricating (Fig 6a): <ul style="list-style-type: none"> • Run the actuator away from bottom dead centre (bottom dead centre is when the actuator's piston is not run out). • Fill max. 2 ml lubricant via the grease nipple (shown in the diagram below). • Run the actuator in the bottom position before it is used again. 	Min. every 6 month, or in case of unusual noises or vibrations. The spindle nut "screams" if there is insufficient lubrication. It is important to keep the spindle well lubricated because this is important for the lifespan of the nut. However, there should not be too much grease because this can be squeezed out of the actuator and potentially get into the gears.




Fig. 6 Lubrication overview

