CRES COR®
5925 Heisley Road • Mentor, OH 44060-1833

OPERATING and MAINTENANCE INSTRUCTIONS for H135WUA11 Hot Cabinet (Aluminum) H135WSUA11 Hot Cabinet (Stainless Steel)


Model No.	Volts	Watts	Amps	Hertz	Phase	NEMA
H135WUA11 H135WSUA11	120	2000	16	60	1	5-20P
H135WUA11208 H135WSUA11208	208	2000	9.6	60	1	6-15P
H135WUA11240 H135WSUA11240	240	2000	8.6	60	1	6-15P

All are designed for AC service. The above model numbers may be followed by "***M***", "***L***", "***D***", "***R***" and ending with "***S***" or "***Z***".

HOW TO INSTALL UNIT:

1. Place cabinet near warm ovens. Do NOT place cabinet in drafty areas or near ventilating systems.
2. Plug end into proper wall outlet.
3. Fill with 2 qts.(1.8 liters) of clean, hot water.

⚠ CAUTION **Use of treated or soft water may be required for proper operation and to maintain warranty.**



CONTROL PANEL PARTS IDENTIFICATION

1. Switch-Power
2. Yellow Light-Power
3. Thermostat-Humidity
4. Thermostat-Air
5. Yellow Light-Proof
6. Red Light-Heat
7. Switch-Mode Selection
8. Thermometer

HOW TO PROOF:

1. Fill water pan (See "How to Install")
2. Push "POWER" switch to "ON." The yellow light will come on.
3. Push "MODE SELECTION" switch to "PROOF". The yellow light will come on.
4. Turn "HUMIDITY" dial to No. 8.
5. Turn "AIR" dial to "OFF."
6. Preheat for 30 minutes. "
7. Put fresh or fully thawed dough into cabinet.

NOTE: The cabinet temperature will drop temperature inside cabinet if cold dough is added.

Do <u>NOT</u> put frozen dough into cabinet

NOTE: No. 8 setting will give you an approximate temperature of 95°F (35°C), and 90-95% humidity. Experiment with different "HUMIDITY" and "AIR" settings to get the exact temperature and humidity you need. The thermometer shows the temperature inside the cabinet.

NOTE: Check water level in water pan if you are proofing longer than 90 minutes. Fill with clean, hot water.

CRES COR®
5925 Heisley Road • Mentor, OH 44060-1833

OPERATING and MAINTENANCE INSTRUCTIONS for H135WUA11 Series Hot Cabinet

HOW TO HOLD

1. Push "POWER" switch to "ON." The yellow light will come on.
2. Push "MODE SELECTION" switch to "HEAT." The red light will come on.
3. Turn "AIR" dial to temperature needed.

NOTE: No. 8 is about 175°F (79°C).
No. 6 is about 165°F (74°C).
Proper food holding temperature is 140°F (60°C) or higher.

4. Preheat cabinet for 30 minutes.
5. Put food into cabinet.

HOW TO TURN UNIT OFF:

Push "POWER" switch to "OFF" position.

MAINTENANCE:



HOT UNIT REMOVAL INSTRUCTIONS:

1. Unplug power cord from wall outlet.
2. Pull entire unit out the front of the cabinet.

⚠ WARNING

BEFORE CLEANING THE CABINET:

1. **Allow cabinet to cool.**
2. **Remove Hot Unit from cabinet.**
3. **Do NOT use abrasives or harsh chemicals.**

Cleaning Notes:

1. Wipe up spills as soon as possible.
2. Clean cabinet regularly to avoid heavy dirt build-up.
3. Make a test spot with cleaner.
4. Follow manufacturer's directions on cleaner.
5. Do not mix cleaners.
6. Avoid drips and splashes.
7. Empty water pan at least once a week.

⚠ CAUTION DELIME OR DESCALE RESERVOIR PARTS AS REQUIRED TO PREVENT DAMAGING BUILD-UP.

WARRANTY COVERAGE MAY BE AFFECTED WITHOUT PROPER CLEANING.

CRES COR®
5925 Heisley Road • Mentor, OH 44060-1833

OPERATING and MAINTENANCE INSTRUCTIONS for H135WUA11 Hot Cabinet (Aluminum) H135WSUA11 Hot Cabinet (Stainless Steel)

HOW TO CLEAN UNIT:

	Soil	Cleaner	Method
DOORS Vinyl (Out) Aluminum (In)	Dirt, Grease and Oil	Mild Detergent* and water.	1. Wipe with soft, damp cloth. 2. Rinse well.
CABINETS (H137WUA11 is Aluminum) (H137WSUA11 is Stainless Steel)	Dirt	Mild detergent* and hot water, or mild abrasive cleaner.	1. Use soft, damp cloth. 2. Rinse with hot water. 3. Wipe dry.
		Steam (No strong alkaline additive)	1. Rinse after steam cleaning. 2. Wipe dry.
	Fingerprints, Grease and Oil	Chemical oven cleaner for cabinet material	Follow oven cleaner manufacturer's directions
		Mild abrasive cleaner; oily or waxy cleaner	Apply with clean, soft cloth. Wipe with damp cloth.
	Water Spots	Mild abrasive cleaner. Oily or waxy cleaner.	Apply with soft, clean cloth. Wipe with damp cloth.

**Mild detergents include soaps and non-abrasive cleaners.*

TROUBLE-SHOOTING CHART:

FAILURE	POSSIBLE CAUSE
1. Indicator lights do NOT light.	1a. Circuit breaker/fuse to wall outlet blown. 2a. Cord unplugged from wall outlet or cabinet. 3a. Switch is "OFF."
2. Unit does not heat	2a. Thermostats set too low or are off. 2b. Switch is "OFF."
3. Unit gets too hot or won't shut off	3a. Defective electrical parts. *3b. UNPLUG UNIT FROM WALL OUTLET*
4. Humidity is low.	4a. Water in pan may be low 4b. Thermostat set too low
5. Blower does not work or makes noise.	5a. Defective Blower

NOTE: Optional digital thermometer will flash if cabinet temperature is below 140°F or above 250°F. Call the Factory if you need different settings.

If cause is none of the above, refer to our list of Authorized Service Centers, FL-1400.

CABINET	W/BLACK FRAME	W/O BLACK FRAME
Door Assembly, Aluminum	1200-495-BL-K	1221-571-K
Door Assembly, Red	1200-499-BL-K	1221-571-RK
Door Assembly, Stainless Steel	-	1221-571-SS
Door Gasket	0861-259-K	0861-271-K
Door Hinge	0519-104-K	0519-104-K
Door Latch	1006-154-01-K	1006-154-01-K
Pan Slides	0621-281-K	0621-281-K

CRES COR®
5925 Heisley Road • Mentor, OH 44060-1833

OPERATING and MAINTENANCE INSTRUCTIONS for H135WUA11 Series Hot Cabinet

REPLACEMENT PARTS:

DESCRIPTION	120 VOLT	208 VOLT	240 VOLT
Hot Unit (135WUA11)	PHU-747-071	PHU-747-072	PHU-747-073
Hot Unit (135WSUA11)	PHU-747-080	PHU-747-081	PHU-747-082
Heater (Reservoir)	0811-285	0811-286	0811-287
Pan (Reservoir)	1017-097	1017-097	1017-097
Heater (Air)	0811-214-K	0811-250	0811-215
Thermostat Kit	0848-062-K	0848-062-K	0848-062-K
Thermometer Kit (Analog)	5238-030-K	5238-030-K	5238-030-K
Power Cord	0810-065-1	0810-039	0810-039
Proof & Heat Lights	0766-093	0766-093-1	0766-093-1
Power Light	0766-094	0766-095	0766-095
Switch (Power)	0808-116-K	0808-116-K	0808-116-K
Switch (Mode Selection)	0808-117-K	0808-117-K	0808-117-K
Blower Kit	0769-180-K	0769-182-K	0769-182-K
Drip Pan Kit	1017-058	1017-058	1017-058

