

KIT CONTENTS:

- 1) S.S. PURSE RAIL COVER (1)
- 2) #10 PHILLIPS HD SCREW (9)

TOOLS REQUIRED (NOT SUPPLIED)

PHILLIPS HEAD SCREWDRIVER
OR
POWERED SCREWDRIVER



BE SURE TO REMOVE ANY LOOSE DEBRIS FROM TOP SIDE OF EXISTING RAIL SO THAT THE STAINLESS RAIL COVER SITS FLUSH ON THE TOP.

SLIDE PURSE RAIL COVER OVER EXISTING WOODEN PURSE RAIL AND CENTER AS SHOWN.



ONCE THE STAINLESS PURSE RAIL IS LOCATED CORRECTLY USE SUPPLIED #10 SCREWS TO SECURE THE RAIL IN PLACE.