

OPERATING INSTRUCTIONS

PRINCE CASTLE INC. 
WORLDWIDE

Grill Scraper

Model No. 161, 161-MC,
161-PG & 173

Redi-Gril®



WARRANTY This product is warranted to be free from defects at time of delivery only.

1. Grip scraper handle in one hand and place other hand against the hand guard.
2. Set edge of blade on grill.
3. Push down and forward.

For maximum efficiency do the following:

- Once a day sharpen the blade on your grill scraper to keep the edge sharp and straight.
- Once a day wash entire tool in hot, soapy water.
- Once a week remove blade and clean underneath it.
- Avoid nicking the edge of the grill scraper's blade.
- Keep blade corners rounded to prevent scoring grill.

Purchase grill scraper blades through Prince Castle.

Replacement Blade Part Numbers

173-1	Disposable Blades (Pkg. of 6)
161-6DP	Disposable Blades (Pkg. of 6)
161-6EHD	Extra Heavy Duty Blades (Pkg. of 6)
161-6HD	Heavy Duty Blades (Pkg. of 6)
161-1HD	Heavy Duty Blade

PRINCE CASTLE INC. 
WORLDWIDE

355 East Kehoe Blvd. • Carol Stream, IL 60188
Tel: (630) 462-8800 • Fax: (630) 462-1460
Toll Free: 1-800-PCASTLE