



RG-05, RG-07, RG-09 Roller Grill

This manual contains important information regarding your *Admiral Craft* unit. Please read this manual thoroughly prior to equipment set-up, operation and maintenance. Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty. MUST READ!!!

WARNINGS

- Do not touch any hot surfaces
- Do not immerse unit, cord or plug in liquid at any time
- Unplug cord from outlet when not in use and before cleaning. Allow grill to cool completely before cleaning.
- Plug only into a 3-hole grounded electrical outlet
- Do not operate unattended
- Do not use this unit for anything other than intended use
- Do not use outdoors
- Keep children and animals away from unit
- Always cook on a firm, dry and level surface at least 12" from walls or any other obstruction
- Do not use unit with a damaged cord or plug, in the event the appliance malfunctions, or has been damaged in any manner
- Any incorrect installation, alterations, adjustments and/or improper maintenance can lead to property loss and injury. All repairs should be done by authorized professionals only
- Ensure that the designated power supply is adequate for continual usage and the voltage is correct

TO USE

1. Place unfrozen hot dogs on the rollers, evenly.
2. The left knob controls the front rollers and the right knob controls the back rollers. Use both rows simultaneously for high-volume usage.
3. To control the rotation of the rollers, turn the switch on the control plate to "ON".
4. Turn the knob to the desired level of heat. Once hot dogs have been heating for 40 minutes, turn the temperature control knob lower to continuously keep warm.
5. Average heating duration is 40 minutes; however this may vary depending on of quality of hot dogs.

CLEANING – NOTE: To maintain cleanliness and increase service life, the rollers should be cleaned daily. Clean every 3-4 hours for products with high fat or sugar content.

1. Do not immerse the grill in water or any other liquid.
2. Before cleaning or attempting to move grill, unplug and let the unit cool completely.
3. Wipe from the end of the rollers to the center. Make sure hot dogs have been removed before wiping.
4. To avoid damage, do not use abrasive cleaners or scouring pads.
5. If soap or chemical cleaners are used, be sure they are completely rinsed away with clear water immediately after cleaning. Chemical residue could damage or corrode the surfaces of the unit.

NOTE:



- Hot dogs *must* be completely unfrozen.
- In order to keep the juicy taste, do not keep warm for too long. The surface of the hot dogs may become thick and hard if warming for more than four hours.

Hot Dog Roller Grill

RD-07

Circuit diagram

AC/L.N/120V/50~60Hz/0.56kW/4.7A





Hot Dog Roller Grill

RD-05

Circuit diagram

0.4kW/120VAC/50~60Hz





Hot Dog Roller Grill


RD-09

Circuit diagram

AC/L.N/120V/50~60Hz/0.72kW/6A



RG-05
RG-07
RG-09



VER811

Roller Grill - RG-05, RG-07, RG-09

Reference Number	RG-05 Part Number	RG-07 Part Number	RG-09 Part Number	Description
1	RG-1	RG-1	RG-1	Power Cord and Strain Relief
2	RG-2	RG-2	RG-2	White Grease Ring and White Bearing Ring
3	RG-3	RG-3	RG-3	Roller Tube
5	RG-5	RG-5	RG-5	Heating Element
6				Guide Rail
7				Right Side Cover
8	RG5-8	RG7-8	RG9-8	Chain
9	RG-9	RG-9	RG-9	Sprocket
10	RG-10	RG-10	RG-10	Motor
11				Bottom Cover
12	RG-12	RG-12	RG-12	Heat Indicator - Yellow
13	RG-13	RG-13	RG-13	Thermostat Regulator Knob
14	RG-14	RG-14	RG-14	Thermostat Regulator
15	RG-15	RG-15	RG-15	On/Off Switch
16				Oil Tray
17				Oil Tray Rack
18	RG-18	RG-18	RG-18	Rubber Foot
19				Body
20				Left Side Cover
21				Upper and Lower Support Rails



1-YEAR LIMITED WARRANTY

Admiral Craft Equipment Corp. (the "Company") warrants this product (the "Product") will be free from failures in material and workmanship for one (1) year from the date of original purchase with proof of purchase, provided that the Product is operated and maintained in conformity with the Owner's Manual. This Limited Warranty is non-transferable. During this period, your exclusive remedy is repair or replacement without charge of the Product or any component found to be defective at the Company's discretion. If the Product or any component is no longer available, the Company will replace it with a similar one of equal or greater value. This Limited Warranty is void if the Product is used with voltage other than 120 Volts. **THIS WARRANTY IS IN LIEU OF ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, PERFORMANCE, OR OTHERWISE, WHICH ARE HEREBY EXCLUDED. IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY DAMAGES, WHETHER DIRECT, INDIRECT, INCIDENTAL, FORSEEABLE, CONSEQUENTIAL, OR SPECIAL ARISING OUT OF OR IN CONNECTION WITH THIS PRODUCT INCLUDING DAMAGES ARISING FOR FOOD OR BEVERAGE SPOILAGE CLAIMS.**

You may have other legal rights depending upon where you live. Some States or Provinces do not allow limitations on warranties so the foregoing may not apply to you.

WARRANTY EXCLUSIONS

IMPROPER ELECTRICAL CONNECTIONS:

The Company is not responsible for the repair or replacement of failed or damaged components resulting from electrical power failure, the use of extension cords, low voltage, or voltage spikes to the Product.

IMPROPER USAGE:

This Limited Warranty does not cover failure or other damages to the Product resulting from (i) improper usage or installation or failure to clean and/or maintain the Product as set forth in the Owner's Manual; or (ii) accident, misuse, abuse, negligence, or modification or alteration of the Product.

CONSUMABLES:

This Limited Warranty does not include consumables or wear-and-tear items such as legs, feet, plastic component parts, splash shields, filters, gaskets, and non-stick cooking surfaces.

ADJUSTMENTS & CALIBRATIONS:

Leveling, tightening of fasteners, or utility connections normally associated with the original installation are the responsibility of the dealer, installer, or the end user and not the responsibility of the Company and will not be considered warranty issues.

If you think the Product has failed, or requires service, within its warranty period, please contact the Company's Customer Care Department through our website at: www.admiralcraft.com "Service" --> "Technical Support Request". A receipt proving the original purchase date will be required for all warranty claims, handwritten receipts are not accepted. You may also be required to return the Product for inspection and evaluation. Return shipping costs are not refundable. The Company is not responsible for returns lost in transit.

This Limited Warranty is Valid only in the USA and Canada.