



WB-100 Water Boiler

This manual contains important information regarding your *Admiral Craft* unit. Please read this manual thoroughly prior to equipment set-up, operation and maintenance. Failure to comply with regular maintenance guidelines outlined in this manual may void the warranty. MUST READ!!!

WARNINGS

- Do not touch any hot surfaces
- Do not use machine with wet hands.
- Do not immerse unit, cord or plug in liquid at any time
- Unplug cord from outlet when not in use and before cleaning.
- Plug only into a 3-hole grounded electrical outlet
- Do not operate unattended
- Do not use this unit for anything other than intended use
- Do not use outdoors
- Keep children and animals away from unit
- Always operate on a firm, dry and level surface at least 12" from walls or any other obstruction
- Do not use unit with a damaged cord or plug, in the event the appliance malfunctions, or has been damaged in any manner
- Any incorrect installation, alterations, adjustments and/or improper maintenance can lead to property loss and injury. All repairs should be done by authorized professionals only
- Ensure that the power supply you are using is adequate for continual usage and the voltage is correct.
- The minimum volume to operate must be at least 1/3 of the maximum capacity.
- The lid must be closed when operating unit.


TO USE

1. First, confirm the switch is off and the thermostat is set at "0" position.
2. Fill the urn to at least half of total capacity with cool water.
3. Place the lid on unit.
4. Plug the power cord into the appropriately rated outlet.
5. Turn the power switch "On". The light will illuminate to indicate the power is connected.
6. Control desired temperature by turning the knob.
7. When the indicator lights up, the boil pressure is completed. Hot water is now ready to be served.
8. When the temperature cools down to about 10°C or (50°F), the unit will restart and heat up automatically and the indicator will light up again.
9. When the temperature cools down to about 100°C or (212°F), the unit will maintain a boiling temperature until setting is reduced.


CLEANING – NOTE: To maintain cleanliness and increase service life, the brewer should be cleaned every four weeks. Do not immerse the unit in water or any other liquid. If liquid enters the electrical compartment it may cause a short circuit or electrical shock.

***On areas of the heating element, hard water will cause chalk and limestone to accumulate over time. It is recommended that you de-sediment when it is determined there are scale sediments at the bottom of the unit.**

1. Before cleaning or attempting to move water boiler, unplug from outlet.
2. Pour 200ml of fresh lemon juice or concentrated lemon juice into the urn.
3. Wait 5 minutes to allow the lemon juice to penetrate.
4. A brush with soft bristles may be used to gently clean the unit.
5. Repeat steps 1-3 until all residue is removed.
6. Use a dry cloth to wipe away the lemon juice.
7. Rinse with clean water and brush the heating element lightly.
8. To avoid damage, do not use abrasive cleaners or scouring pads.
9. If soap or chemical cleaners are used, be sure they are completely rinsed away with clear water immediately after cleaning. Chemical residue could damage or corrode the surfaces of the unit.



WB-100



Water Boiler - WB-100

Reference Number	Part Number	Description
1	CP-01	Cover with knob
2	WB-2	Plastic Handle
3		Fixer of Urn's Shaft S/S
4	CP-18	Screwcap for Sleeve
5		Sealing of Graduation
6		Fixer of Water Graduation
7	CP1-11	Glass Graduation
8	CP1-12	Sleeve for Graduation
9		Screw of Glass Graduation
10	CP-13	Spigot
12	WB-12	Indicator Light - Clear
13	CP-17	Lighted Switch - Red
14		Base of Urn
15	WB-15	Foot
16		Terminal Block
17		Bottom Cover Support
18	CP-15	Power Cord and Plug
19		Base of Urn
20	WB-20	Thermos Cutoffs
21	WB-21	Thermostat
22	WB-22	Temperature Knob
23	WB-23	Adjustable Thermostat
24	WB-24	Heating Element
25		Heating Dish Gasket
26		Body of Urn



1-YEAR LIMITED WARRANTY

Admiral Craft Equipment Corp. (the "Company") warrants this product (the "Product") will be free from failures in material and workmanship for one (1) year from the date of original purchase with proof of purchase, provided that the Product is operated and maintained in conformity with the Owner's Manual. This Limited Warranty is non-transferable. During this period, your exclusive remedy is repair or replacement without charge of the Product or any component found to be defective at the Company's discretion. If the Product or any component is no longer available, the Company will replace it with a similar one of equal or greater value. This Limited Warranty is void if the Product is used with voltage other than 120 Volts. **THIS WARRANTY IS IN LIEU OF ALL IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, PERFORMANCE, OR OTHERWISE, WHICH ARE HEREBY EXCLUDED. IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY DAMAGES, WHETHER DIRECT, INDIRECT, INCIDENTAL, FORSEEABLE, CONSEQUENTIAL, OR SPECIAL ARISING OUT OF OR IN CONNECTION WITH THIS PRODUCT INCLUDING DAMAGES ARISING FOR FOOD OR BEVERAGE SPOILAGE CLAIMS.**

You may have other legal rights depending upon where you live. Some States or Provinces do not allow limitations on warranties so the foregoing may not apply to you.

WARRANTY EXCLUSIONS

IMPROPER ELECTRICAL CONNECTIONS:

The Company is not responsible for the repair or replacement of failed or damaged components resulting from electrical power failure, the use of extension cords, low voltage, or voltage spikes to the Product.

IMPROPER USAGE:

This Limited Warranty does not cover failure or other damages to the Product resulting from (i) improper usage or installation or failure to clean and/or maintain the Product as set forth in the Owner's Manual; or (ii) accident, misuse, abuse, negligence, or modification or alteration of the Product.

CONSUMABLES:

This Limited Warranty does not include consumables or wear-and-tear items such as legs, feet, plastic component parts, splash shields, filters, gaskets, and non-stick cooking surfaces.

ADJUSTMENTS & CALIBRATIONS:

Leveling, tightening of fasteners, or utility connections normally associated with the original installation are the responsibility of the dealer, installer, or the end user and not the responsibility of the Company and will not be considered warranty issues.

If you think the Product has failed, or requires service, within its warranty period, please contact the Company's Customer Care Department through our website at: www.admiralcraft.com "Service" --> "Technical Support Request". A receipt proving the original purchase date will be required for all warranty claims, handwritten receipts are not accepted. You may also be required to return the Product for inspection and evaluation. Return shipping costs are not refundable. The Company is not responsible for returns lost in transit.

This Limited Warranty is Valid only in the USA and Canada.