



# Part List and Exploded View of WCR496DS

No.	Part #	Part Name	Qty
2	YC-TY.LJ.35	Dry Filter	1
3	EYA55U6	Compressor	1
4		Earthing line	1
5	YC150A.02.01.10	Power PCB box	1
6	<a href="#">YC510.03.01.01</a>	Power PCB (Dual zones)	1
8	YC150A.02.09	Hinge hole caps	6
9	YC150A.03.18.00	Upper right hinge	1
10	YC150S-ZZ-WJ-035	Evaporator	1
11	<a href="#">YC150A.03.01.02</a>	Evaporator Fan	2
12	YC150D.03.01.20	Air -duct board	1
13	YC150B.03.02.10	Control panel bracket	1
14	YC150D.03.02.04	Control PCB	1
15	YC150D-ZZ-WJ-001	upper air-duct board	1
16	YC150E.03.02.01	middle foam	1
17	YC150D-ZZ-SL-001	Control panel fixtures	2
18	YC150D.03.02.03.03	Control panel film	1
19	YC150S-ZZ-WJ-004-1	Burgundy metal shelf	2
	YC150S-ZZ-CM-012	wooden trim	6
20	YC150A.03.22	shelf guide	5 pair
21	YC150A/14-6-10-3	Non-seamless SS Door assembly	1
	YC150A.03.10.12	SS handle	1
	YC150A.03.06.09	Door sealing	1
22	YC150A.03.26.00	Lower door hinge	1
23	YC150A.03.07	Bottom shelf	1
24	YC150S-ZZ-WJ-005-1	Metal shelf for standard bottles	4
25	YC150D-ZZ-WJ-001	lower air-duct board	1
25		Light cover	2
26	YC150A.03.02.01.05	LED light PCB	2
27	YC-TY.LJ.02	LED light box	2
28	<a href="#">YC150A.03.01.02</a>	PTC heater fan	1
29	YC150C.03.20	Bottom Grille	1
30	<a href="#">YC-TY.LJ.41.01</a>	Charcoal filter	1
31	YC150A.03.28	Sensor cover	1
32	YC150A.03.26.02	Lower hinge	1
33		Light cover	1
34	YC150A.01.12	LED light PCB	1
35	YC150A.03.20.04	Lock hook	1
36	YC150B.03.02.05	PTC heater	1
37	YC150C.02.04.00	Condensor base	
38	YC150A.02.04.02	Condensor fan	1
39	YC150A.02.15	Condensor	1
40	YC150S-ZZ-WJ-042		1
41	YC150A.02.01.01	Compressor bracket	1
42	YC-TY.LJ.37	water tank	1
43		Anti-vibration rubber	2
44	YC150A.02.20	Compressor connecting pipe	1
45	YC-TY.LJ.33	Compressor exhaust pipe	1
Left	YC150A.03.18.01	Left upper hinge	1
	YC150A.03.26.01	Left lower hinge	1