CATALOG OF REPLACEMENT PARTS



DPC1S DEHUMIDIFYING PROOFING CABINET

ML-132644 **DPC1S**


A product of BAXTER MFG. CO., INC. 19220 STATE ROUTE 162 EAST, ORTING, WA 98360

FORM 43430 Rev. A (October 2025)

 © BAXTER MFG. 2025

Table of Contents

5 CONTROL PANEL AND DOOR ASSEMBLY
7 PANELS AND FLOOR
9 VENT STACK ASSEMBLY
11 COMPONENT BOX ASSEMBLY
13 STEAMING & DEHUMIDIFYING ASSEMBLY




CONTROL PANEL AND DOOR ASSEMBLY

CONTROL PANEL AND DOOR ASSEMBLY

ILLUS. PL-62279	PART NO.	NAME OF PART	AMT.
1	01-1P1485-00002	Clamp - Wire Tube (Door)	1
2	01-1P1383-00003	Conduit - Wire	1
3	01-1P1471-00002	Magnet Assy. (Door)	1
4	01-1000V4-00412	Mach. Screw 10-32 x 1/2 Phil. Truss Hd. (SST)	AR
5	01-1P1837-00011	Bumper - Door	1
6	01-1P2833-00003	Door Assy. (Without Control - With Window) (Dunkin Donuts)	1
7	01-1P2683-00003	Door Assy. (Without Control - Without Window)	1
8	01-1P2756-00001	Handle - Door Loading (SST)	1
9	01-1M6103-0203B	Cap - End (Door Handle) (Oval)	2
10	01-100V15-00086	Cap, Handle - Door (Round)	2
11	01-1P2832-00002	Bracket - Control	1
12	01-1P2865-00004	Cover - Control	1
13	01-1P2410-00017	Kit - Control Panel Conduit (Incls. Items 2, 10, & 11)	AR
14	01-1P2830-00001	Board - Control (DPC1S Proofer) RPW Display	2
15	01-100V16-00831	Overlay	1
16	01-1P2321-00033	Gasket - Door (Top)	1
17	01-100V16-0271C	Gasket - Door (Side)	2
18	01-1P2344-00002	Sweep - Door Assy. (Incls. Items 19, 20, & 21)	1
19	01-1P2345-00002	Retainer - Outer Door Seal	1
20	01-1P2346-00002	Retainer - Inner Door Seal	1
21	01-1P2347-00002	Seal - Door Sweep	1
22	01-1P1867-00001	Hinge - Package	2
23	01-1000V4-00119	Self-Tapping Screw 3/8-16 x 1-1/4 Phil. Flat Hd	8
*24	01-100V15-00064	Plug - Push-In (Black)	8


* Used in Unused Hinge Mounting Holes



PANELS AND FLOOR

PANELS AND FLOOR


ILLUS. PL-62280	PART NO.	NAME OF PART	AMT.
1	01-1P2376-00001	Retainer - Upper Forward Trim Assy	2
2	01-1P2374-00002	Trim - Front Upper Trim - Front	1
3	01-1P2362-00002	Trim - Front Lower Trim - Front	1
4	01-100V16-0772A	Nameplate - Baxter Flat (9 In.)	1
5	01-1P2914-00001	Rack Guide Assy. (Complete) (Incls. Items 27 thru 31)	1
6	01-1P2493-00005	Corner - Front Left	1
7	01-1P2496-00003	Wall	3
8	01-1P2502-00001	Panel - Ceiling Front	1
9	01-1P2867-00002	Ceiling - Rear	1
10	01-1P2493-00006	Corner - Rear	2
11	01-1P2493-00001	Corner - Front (Right)	1
12	01-1P2366-00003	Trim - Rear Corner	2
13	01-1P2367-00001	Angle - Floor Side (40-1/2 In.)	2
14	01-1P2368-00002	Angle - Floor Rear (42 In.)	1
15	01-1P2018-00002	Angle - Retainer	2
16	01-1P2364-00001	Trim - Outer Base (40-1/2 In.)	2
17	01-1P2365-00001	Bracket - Floor Retainer Assy	3
18	01-1P2366-00001	Trim - Jamb (Front) (LH)	1
19	01-1P2366-00002	Trim - Jamb (Front) (RH)	1
20	01-1P2370-00040	Floor - Single Floor - Single	1
21	01-1000V4-0073A	Tool - Setting	1
22	01-1000V4-00073	Anchor - Drop-In 1/4-20 (Quantity of 10)	1
23	01-1000V4-00221	Mach. Screw 1/4-20 x 1/2 Phil. Flat Hd. (SST)	AR
24	01-1000V4-00222	Mach. Screw 1/4-20 x 3/4 Phil. Flat Hd. (SST)	AR
25	01-1000V4-00223	Mach. Screw 1/4-20 x 1 Phil. Flat Hd. (SST)	AR
26	01-100V21-00057	Adhesive - Floor (11 Oz. Tube)	AR
27	01-1P2914-00103	Rack Support	1
28	01-1P2914-00101	Rack Guide (LH)	1
29	01-1P2914-00102	Rack Guide (RH)	1
30	01-1000V4-00412	Mach. Screw 10-32 x 1/2 Phil. Truss Hd. (SST)	4
31	01-1000V4-00411	Acorn Nut 10-32 (SST)	4



VENT STACK ASSEMBLY

VENT STACK ASSEMBLY

ILLUS. PL-62281	PART NO.	NAME OF PART	AMT.
1	01-1P2919-00101	Harness	1
2	01-1000V8-00150	Motor - Vent Damper	1
3	01-1P2919-00104	Bracket - Vent Actuator Mounting	1
4	01-1000V4-00475	Screw - Pan HD Sht Mtl (#10-16 x 0.5)	2
5	01-1P2915-00101	Body - Exhaust Vent	2
6	01-100V16-00682	Gasket - Vent Duct	1
7	01-1P2915-00102	Baffle - Exhaust Vent	1
8	01-1P2916-00001	Lid Assy. - Exhaust Vent	1
9	01-1000V4-00409	Screw 5/16-18 x 1-1/4 Hex Socket Hd	1
10	01-1000V4-00408	Screw 5/16-18 x 1 Hex Socket Hd	1
11	01-1000V4-00426	Screw #10-16 x 3/4 Hex Hd. (Drill Tip) (SST)	10
12	01-1P2915-00103	Hinge - Exhaust Vent	1
13	01-1P2915-00001	Vent Assy	1



COMPONENT BOX ASSEMBLY


COMPONENT BOX ASSEMBLY

ILLUS. PL-62282	PART NO.	NAME OF PART	AMT.
1	01-1P2451-00302	Cover (J-Box)	1
*2	01-100V10-00235	End - Section (Flat Mount) (600 V.) (Before 10/1/21)	1
*3	01-100V10-00234	Holder -Midget Fuse (Qty. of 2 for 1 Ph., Qty. of 3 for 3 Ph.) (Before 10/1/21)	AR
4	01-100V10-00236	Fuse (30 Amp) (1 Ph.)	2
5	01-100V10-00245	Fuse (25 Amp) (3 Ph.)	3
6	01-1P2945-00001	Solenoid Assy. (Incls Items 7 thru 13)	1
7	01-1P2945-00102	Bracket - Mounting	1
8	01-100V17-00829	Valve - Solenoid	1
9	01-100V17-00821	Elbow - Push-to-Connect (1/4 x 1/4)	1
10	01-1000V5-00002	Bushing - Strain Relief	1
11	01-1P2946-00001	Harness - Water Solenoid	1
12	01-1P2945-00101	Bracket - Solenoid Mounting	1
13	01-100V15-00057	Grommet	1
14	01-1000V17-00813	Tubing (1/4" OD) Order by In	AR
15	01-1P2451-00301	Base (J-Box)	1
16	01-100V11-00139	Box - Breaker	1
17	01-1000V6-00191	Breaker - Circuit (15 Amp., 120/240 V.)	1
18	01-1000V5-00059	Bushing - Snap 7/8 In. (Plastic)	1
19	01-100V11-0024C	Box Assy. - Junction	1
20	01-1000V5-00037	Lug - Terminal	2
21	01-1P2758-00001	Terminal Block Assy	2
22	01-1000V5-00002	Bushing - Strain Relief	1
23	01-1P3045-00001	Kit - Upgrade, Power Supply Board	1
24	01-1P2383-00001	End (Component Box)	2
25	01-1000V5-00035	Bushing - Snap (1 In.)	1
26	01-1P1749-00002	Beeper Assy	1
27	01-1000V5-00166	Bushing - Snap	1
28	01-1000V5-00096	Block - Power Distribution	2
29	01-1000V6-00327	Relay (1/2 Hp.)	1
30	01-1000V8-0175C	Capacitor - Fan Motor	2
31	01-1000V5-00406	Stop - Terminal Section End	4
32	01-1000V6-00382	Contactor (40 Amp., 3-Pole, 120 VAC Coil)	2
33	01-100V18-00115	Rail - Din (7 In.)	1
34	01-100V17-00830	Adapter - Hose to Pipe 3/4 GHTF x 1/2 NPTF	1
**35	01-1P2927-00001	Harness - Main (1 Ph.) (Inside Control Box)	1
**36	01-1P2927-00002	Harness - Main (3 Ph.) (Inside Control Box)	1
37	01-1P2927-00003	Harness - Extension (Control Box to J-Box above Heating Duct)	1
38	01-1P2944-00001	Box - Control (1 Ph.) (Incls. Items 1, 2, 3, 4, 6 thru 34 & 36)	1
39	01-1P2943-00001	Box - Control (3 Ph.) (Incls. Items 1, 2, 3, 5 thru 35 & 36)	1
40	01-1P2979-00002	Fuse Holder - Block Assy. (2 pc.) (W/O Fuses) (Incls Items 31, 42 & 43)	1
41	01-1P2979-00003	Fuse Holder - Block Assy. (3 pc.) (W/O Fuses) (Incls Items 31, 42 & 43)	1
42	01-1P2980-00001	Rail - Din (4 In.)	1
43	01-100V10-00364	Holder - Fuse	AR
44	01-1P2982-00002	Kit - Fuse Holder (2 pc.) (W/O Fuses) (Single Phase Power) (incls. Item 40)	1
45	01-1P2982-00003	Kit - Fuse Holder (3 pc.) (W/O Fuses) (Triple Phase Power) (incls. Item 41)	1

* Use Item 44 for Single Phase Power, Use Item 45 for Triple Phase Power
** Order with 01-1P3045-00101, Harness Adapter

19 Kit - Drain (40-1/2 In.)

PART NOT ILLUSTRATED



STEAMING & DEHUMIDIFYING ASSEMBLY

STEAMING & DEHUMIDIFYING ASSEMBLY

ILLUS. PL-62333	PART NO.	NAME OF PART	AMT.
1	01-1000V4-00336	Nut #10-32 W/ Lockwasher (SST)	6
2	01-1000V4-00412	Mach. Screw 10-32 x 1/2 Phil. Truss Hd. (SST)	AR
3	01-1000V4-00423	Mach. Screw 10-32 x 1/2 Hex Hd. W/ Washer (SST)	4
4	01-1000V4-00426	Screw #10-16 x 3/4 Hex Hd. (Drill Tip) (SST)	5
5	01-100V16-0746B	Label (Fan Blade)	1
6	01-1P2903-00001	Base Plate Assy	1
7	01-1P2907-00001	Front Cover Assy	1
8	01-1P2917-00102	Cover Plate - Drain	1
9	01-1P3063-00002	Kit - Air Duct	1
10	01-1P2456-00001	Switch - High Limit Thermostat Assy	1
11	01-1P2462-00005	Sprayer Assy	1
12	01-1P2901-00001	Heater Plate Assy	1
13	01-1P2904-00001	Duct Body - RH Side	1
14	01-1P2905-00001	Duct Body - LH Side	1
15	01-1P2906-00001	Fan Assy	1
16	01-1P3062-00002	Drain Pan Assy	1
*17	01-1P2461-00001	Bracket - Humidity Sensor (Order W/ Item 18)	1
*18	01-1P1875-00002	Sensor Assy. - Humidity W/Filter (Order W/ Item 17)	1
19	01-1P3061-00002	Kit - Drain (40-1/2 In.)	1

* Both Bracket and Sensor Required