




PARTS LIST


PRESSURELESS COOKER 6 PAN AND 10 PAN UNITS
Boiler Base, Direct Steam, Kettle, Steam Coil, cabinet Base

MODELS: SB-6,10G SB-6,10E

SB-6,10SC SC-6,10DS



BLODGETT OVEN CO ▪ 44 lakeside Ave ▪ Burlington, VT 05446
Tel. 800-331-5842 ▪ Fax 802-860-3732 ▪ www.blodgett.com



5273-3R1

PARTS LIST, PRESSURELESS COOKER 6 PAN & 10 PAN UNIT, MODELS SB-6G, SB-10G

ITEM	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QUANTITY</u>	
			<u>SB-6</u>	<u>SB-10</u>
1	43516	Hinge Rod	1	
	41715	Hinge Rod		1
2	42137	Door Switch	2	2
	42285	Actuator Pin Complete With Clip	2	2
3	41631	Striker	2	2
	41632	Washer	2	2
	40112	Lock Washer	2	2
	40114	Nut	2	2
4	43517	Control Decal	1	
	42577	Control Decal		1
5	40945	Pilot Light, Green	2	2
6	40950	Pilot Light, Red	2	2
7	41633	Perforated Trough	1	1

PARTS LIST, PRESSURELESS COOKER 6 PAN & 10 PAN UNIT, MODELS SB-6G, SB-10G

ITEM	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QUANTITY</u>	
			<u>SB-6</u>	<u>SB-10</u>
**	8	43265 Dial 60 Minutes, 60 Hz	2	2
		43518 Dial 60 Minutes, 50 Hz	2	2
		43266 Dial 120 Minutes, 60 Hz	2	2
	9	43264 Spacer	4	4
	10	41699 Bushing	8	8
	11	41691 Door Assembly	2	
		41690 Door Assembly		2
	12	41675 Handle Assembly	2	2
*		40648 Handle	1	1
*		40647 Handle Plate	1	1
*		40191 Socket Screw, 1/4 - 20 x 1 3/4	2	2
*		40089 Socket Screw, 1/4 - 20 x 3/4	1	1
*	12	40646 Spacer	2	2

PARTS LIST, PRESSURELESS COOKER 6 PAN & 10 PAN UNIT, MODELS SB-6G, SB-10G

ITEM	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QUANTITY</u>	
			<u>SB-6</u>	<u>SB-10</u>
*	43519	Lock Washer, 1/4	2	2
*	40093	Nut, 1/4 - 20	2	2
*	42258	Decal	2	2
13	41679	Latch Assembly	2	2
14	41672	Door Panel	2	
	41671	Door Panel		2
15	41658	Door Gasket	2	
	41657	Door Gasket		2
16	41665	Door Gasket Plate	2	
	41664	Door Gasket Plate		2
	41875	Screws	12	16
17	40199	Pan Racks	4	
	40201	Pan Racks		4

PARTS LIST, PRESSURELESS COOKER 6 PAN & 10 PAN UNIT, MODELS SB-6G, SB-10G

ITEM	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QUANTITY</u>	
			<u>SB-6</u>	<u>SB-10</u>
18	41706	Enclosure Panel	1	
	41708	Enclosure Panel		1
	40076	Screws	2	2
19	40551	Steam Control Valve	1	1
20	41925	Steam Supply Tube	2	
	42600	Steam Supply Tube		2
21	40573	Elbow	1	1
22	40549	Pressure Gauge	1	1
23	42142	Steam Manifold	1	
23	42143	Steam Manifold		1
24	40585	Transducer	1	1
25	40442	Elbow 1/4C x 1/4 MPT	1	1
26	42145	Steam Tube 1/4 Copper	1	

PARTS LIST, PRESSURELESS COOKER 6 PAN & 10 PAN UNIT, MODELS SB-6G, SB-10G

ITEM	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QUANTITY</u>		
			<u>SB-6</u>	<u>SB-10</u>	
	43520	Steam Tube 1/4 Copper		1	
27	40484	Buzzer	1	1	
**	28	40972	Timer, 60 Min.	2	2
		40973	Timer, 120 Min.	2	2
*		41881	Rotary Shaft Seal	2	2
29	40447	Elbow, 1/2 C x 1/4 MPT 2	2	2	
30	43252	Pressure Switch	1	1	
31	40595	Steam Solenoid Valve	2	2	
32	40460	Tee, 3/8 c x 1/4 MPT	6	6	
33	42146	Steam Tube - Front	2	2	
34	42147	Steam Tube - Rear	2	2	
35	42215	Steam Tube - Crossover	4		
		40908	Steam Tube - Crossover	4	
36	41710	Left Hand Side and Back Panel	1		

PARTS LIST, PRESSURELESS COOKER 6 PAN & 10 PAN UNIT, MODELS SB-6G, SB-10G

ITEM	<u>PART NO.</u>	<u>DESCRIPTION</u>	<u>QUANTITY</u>	
			<u>SB-6</u>	<u>SB-10</u>
	41711	Left Hand Side and Back Panel		1
37	41702	Compartment Strainer	2	2
* —	38 42216	Compartment Drain Hose	2	2
* —	39 42148	Component Mounting Panel	1	1
* —	40 41716	Top Panel	1	1
* —	41 40614	Thermal Switch (Optional)	2	2

* NOT SHOWN.

** SELECT AS REQUIRED.

PARTS LIST, PRESSURELESS COOKER 6 PAN & 10 PAN UNIT, MODELS SB-6G, SB-10G

ALTERNATE PARTS

<u>Page</u>	<u>Item</u>	<u>Crown</u>	<u>Blodgett</u>
3	4	7582-1	42901
		7481-1	42902
	8	4104-1	42456
	11	8-5076-9	43154, Bottom
		8-5076-9	42678, Top
		8-5076-8	42681, Bottom
		8-5076-8	42682, Top
	12	8-5066-9	43151
		4090-1	42453
4	12	9-3320	42454