

CONTACTOR NO 1 (LEFT SIDE REAR VIEW)

SERVICE CONNECTIONS		
THREE PHASE	L1	1.4
	L2	2.5
	L3	3.6
SINGLE PHASE	L1	1.3.5
	L2	2.4.6

