

DYNACOUBE

Parts list	Code	List \$ Price
Mounting support (unit)	3507	4,28
Foot	3508	14,58
Suction cup (unit)	3512	10,69
Self-lubricating ring (unit)	3523	8,24
Circlips 18	3524	7,32
Handle pin 4X18	3525	2,19
Crank handle and pin	3526	52,51
Cone shape gear and pin	3527	14,58
Screw on button	3600	10,24
Smooth cone shape gear	3607	12,15
Plastic ball bearings	3608	17,05
Handle (crank) assembly kit	3609	159,44
Lower plate with screws (6) + self-lubricating ring	3610	92,58
Upper cover casing	3611	115,94
Pusher	3612	19,49
Blockage sheet + screws (4)	3613	11,47
Hollow axle	3614	55,74
Roller axle	3615	8,94
Support with screws (2)	3616	3,22
Roller	3617	4,85
Disc holder	3618	102,36
Cutter pin	3619	1,95
Axle assembly for disc holder	3620	104,31

