

Factory Parts Catalog

Product No.	E51CA60ESS	E51LB60ESS	E51LK60ESS	E51NB60ESS	E51NK60ESS
Series	51" elec/ign	51" elec/ign	51" elec/ign	51" elec/ign	51" elec/ign
Market	North America	North America	North America	North America	North America
Color	stainless	stainless	stainless	stainless	stainless
Owner's Guide	e51en	e51en	e51en	e51en	e51en



Electrolux Major Appliances
 North & Latin America
 P.O. BOX 212378
 AUGUSTA, GA 30917


Publication No.
5995435764
 05/04/28
 (EN/SERVICE/BJH)
 099

GAS GRILL

Model No.
 E51CA60E / E51LB60E /
 E51LK60E / E51NB60E /
 E51NK60E

Copyright © 2005 Electrolux Home Products, Inc.
 All rights reserved.

RECOMMENDED SPARE PARTS




E51-A

RECOMMENDED SPARE PARTS

Model Index: A E51LK60E (E51LK60ESS)
 B E51NK60E (E51NK60ESS)
 C E51LB60E (E51LB60ESS)
 D E51NB60E (E51NB60ESS)
 E E51CA60E (E51CA60ESS)

POS. NO	PART NO.		DESCRIPTION
1 #	5304444392	A B C D -	Guage, temperature
2	5304444629	A B C D -	Hood, grill
3	5304444630	A B C D -	Flavor Grid, burner cover, top, angle
4	5304444631	A B C D -	Flavor Grid, burner cover, bottom, angle
5 #	5304444439	A B C D -	Electrode, main burner
6 #	5304444632	A B C D -	Burner, main, 3 cell
7	5304444633	A B C D -	Flavor Grid, burner cover, top-right side, angle
8 #	5304444634	A B C D -	Burner, main, 2 cell
9 #	5304444635	A B C D -	Burner, infrared, bottom
10 #	5304444636	A B C D -	Electrode, infrared burner, bottom
11	5304444637	A B C D -	Grate, burner, main
12	5304444393	A B C D -	Electrode, infrared burner, back
13 #	5304444638	A B C D -	Burner, infrared, back
14	5304444639	A B C D -	Cover, infrared burner
15	5304444400	A B - - E	Grate, side burner
16	5304444525	A B - - E	Cap, burner, side
17	5304444526	A B - - E	Head, burner, side
18	5304444640	A B - - E	Shelf, burner, side
19	5304444530	A - - - E	Base, orifice, side burner, LP
19	5304444531	- B - - E	Base, orifice, side burner, NG
20	5304444412	A - - - E	Valve, burner, side, LP
20	5304444413	- B - - E	Valve, burner, side, NG
21	5304444406	A B C D E	Bezel, knob
22	5304444529	A B C D E	Knob, burner
23 #	5304444641	A B C D -	Manifold
24 #	5304444642	A B - - E	Igniter, 2-pole, no ground, with bracket
25	5304444643	A B C D -	Tray, drip pan
26	5304444404	A B - - E	Housing, igniter battery
27 #	5304444431	A B - - E	Wire, igniter, positive
28 #	5304444432	A B - - E	Wire, igniter, negative
29	5304444644	A B C D -	Panel, drip pan, front
30	5304444543	A B C D -	Handle End, warming tray
31	5304444645	A B C D -	Handle, drip pan
32 #	5304444533	A - C - -	Regulator, LP gas, dual hose
32 #	5304444424	- B - D -	Regulator, NG
32*	5304444534	- B - D E	Tubing, NG, side burner
33	5304444540	A B C D E	Handle, drawer/drip pan
34	5304444391	A B - - E	Magnet, door
35	5304444646	A B - - E	Panel, cart, right side
36	5304444647	A B - - E	Door, cart
37	5304444648	A B - - E	Channel, wheel, swivel
38	5304444538	A B - - E	Tray, gas tank
39	5304444649	A B - - E	Base, cart
40	5304444650	A B - - E	Panel, cart, left side
41	5304444542	A B - - E	Drawer, cart, storage
42	5304444651	A B C D -	Handle, warming tray

RECOMMENDED SPARE PARTS



E51-A

RECOMMENDED SPARE PARTS

Model Index: A E51LK60E (E51LK60ESS)
 B E51NK60E (E51NK60ESS)
 C E51LB60E (E51LB60ESS)
 D E51NB60E (E51NB60ESS)
 E E51CA60E (E51CA60ESS)

POS. NO	PART NO.		DESCRIPTION
43	5304444556	A B C D -	Panel, warming drawer, front
44	5304444652	A B C D -	Drawer, warming
45	5304444435	A - C - -	Valve, burner, main/side, LP
45	5304444436	- B - D -	Valve, burner, main/side, NG
46	5304444433	A - C - -	Valve, IR burner, back, LP
46	5304444434	- B - D -	Valve, IR burner, back, NG
47	5304444547	A B C D -	Knob, infrared burner
48	5304444429	A B C D -	Bezel, infrared knob
49 #	5304444555	A B C D -	Igniter, 4-pole, no ground, with bracket
50	5304444551	A B C D -	Fork, rotisserie
51	5304444653	A B - - E	Shelf, side
52 #	5304444548	A B C D -	Motor, rotisserie
53	5304444654	A B C D -	Spit, rotisserie
54	5304444655	A B C D -	Shelf, warming rack
55	5304444656	A B C D -	Handle, hood, 47 inch
56	5304444388	A B C D -	Handle End, hood, left
57	5304444390	A B C D -	Handle End, hood, right
58	5304444657	A B - - E	Panel, cart, back
59	5304447625	A - C - -	Elbow, LP fitting, infrared burner, rear
59	5304447626	- B - D -	Elbow, NG fitting, infrared burner, rear
60 #	5304447620	A B C D -	Hose, gas, infrared burner, rear
61	5304447621	A B C D -	Elbow, gas fitting, manifold/hose
62 #	5304447622	A B C D -	Hose, gas, 10", main supply
63 #	5304447623	A B C D -	Elbow, main connection
64 #	5304447624	A B C D -	Fitting, main connection
*	5304444658	A B C D -	Wire, igniter, bottom, infrared
*	5304444659	A B C D -	Wire, igniter, main burner, center
*	5304444660	A B C D -	Wire, igniter, main burner, left
*	5304444661	A B C D -	Wire, igniter, infrared burner
*	5304444662	A B C D -	Wire, igniter, main burner
*	5304444663	A B - - E	Wire, igniter, side burner
*	5304444441	A B C D -	Bolt, valve/manifold
*	5304444442	A B - - E	Bolt, wheel & cart
*	5304444443	A B - - E	Nut, door, bottom pivot
*	5304444444	A B - - E	Screw, door, bottom pivot
*	5304444445	A B C D E	Screw, bezel to valve
*	5304444446	A B C D -	Screw, hood handle end
*	5304444447	A B C D E	Screw, self-tapping
*	5304444558	A B C D E	Screw, handle end, door/drawer/pan