

Frigidaire

Factory Parts Catalog

Product No.	FD38LPDC	FD38NGDC	FD38HOLPDC	FD38HONGDC
Series	Grill & Cart	Grill & Cart	built-in	built-in
Market	North America	North America	North America	North America
Color	stainless steel	stainless steel	stainless steel	stainless steel
Owner's Guide	FD38IMD	FD38IMD	FD38IMD	FD38IMD

 **Electrolux**

Electrolux Major Appliances
North & Latin America
P.O. BOX 212378
AUGUSTA, GA 30917


Publication No.
5995436101
05/05/03
(EN/SERVICE/BJH)
099

GAS GRILL

Model No.
FD38LPD / FD38NGD /
FD38HOLPD /
FD38HONGD

Copyright © 2005 Electrolux Home Products, Inc.
All rights reserved.

RECOMMENDED SPARE PARTS




FD38-A

RECOMMENDED SPARE PARTS

Model Index: A FD38LPD (FD38LPDC)
 B FD38NGD (FD38NGDC)
 C FD38HOLPD (FD38HOLPDC)
 D FD38HONGD (FD38HONGDC)

POS. NO	PART NO.	A	B	C	D	DESCRIPTION
1	5304444388	A	B	C	D	Handle End, hood, left
2	5304444389	A	B	C	D	Handle, hood, 32 inch
3	5304444390	A	B	C	D	Handle End, hood, right
4	5304444391	A	B	-	-	Magnet, door
5 #	5304444392	A	B	C	D	Guage, temperature
6 #	5304444393	A	B	C	D	Electrode, infrared burner, back
7 #	5304444453	A	B	C	D	Burner, infrared, back
8	5304445084	A	B	C	D	Cover, infrared burner
9 #	5304444397	A	B	C	D	Burner, main
10	5304444398	A	B	C	D	Flavor Grid, igniter cover, bottom, angle
11	5304444399	A	B	C	D	Flavor Grid, burner cover, top, angle
12	5304444400	A	B	C	D	Grate, side burner
13	5304445076	A	B	-	-	Shelf, side burner, cart model
13	5304445077	-	-	C	D	Shelf, built-in, head only model
14	5304444420	A	B	-	-	Door, cart, left
15	5304444440	A	B	-	-	Door, cart, right
16	5304444404	A	B	C	D	Housing, igniter battery
17	5304444405	A	B	C	D	Knob, burner
18	5304444406	A	B	C	D	Bezel, knob
19	5304444407	A	B	C	D	Hood, grill
20	5304444408	A	B	C	D	Grate, main burner
21 #	5304444674	A	B	C	D	Igniter, 4-pole, no ground, with bracket
22 #	5304445080	A	B	C	D	Burner, side, with venturi
23 #	5304445078	A	-	C	-	Valve, side burner, LP
23 #	5304445079	-	B	-	D	Valve, side burner, NG
24 #	5304444414	A	B	C	D	Manifold
25	5304444415	A	B	-	-	Panel, cart, back
26	5304444416	A	B	-	-	Panel, cart, right side
27	5304444417	A	B	-	-	Base, cart
28	5304444418	A	B	-	-	Channel, wheel, swivel
29	5304444419	A	B	-	-	Door Stop
30	5304445083	A	B	-	-	Channel, wheel, fixed
31	5304444421	A	B	-	-	Handle, door, 9.375 inch
32 #	5304444675	A	-	C	-	Regulator, LP
32 #	5304444424	-	B	-	D	Regulator, NG
33	5304444425	A	B	-	-	Handle End, door, left
34	5304444426	A	B	-	-	Handle End, door, right
35	5304444427	A	B	-	-	Panel, cart, left side
36	5304444428	A	B	C	D	Knob, infrared burner
37	5304444429	A	B	C	D	Bezel, infrared knob
38	5304444430	A	B	C	D	Shelf, warming rack
39 #	5304444431	A	B	C	D	Wire, igniter, positive
40 #	5304444432	A	B	C	D	Wire, igniter, negative
41 #	5304445074	A	-	C	-	Valve, infrared burner, LP
41 #	5304445075	-	B	-	D	Valve, infrared burner, NG
42 #	5304445069	A	-	C	-	Valve, burner, main/side, LP
42 #	5304445070	-	B	-	D	Valve, burner, main/side, NG

RECOMMENDED SPARE PARTS



FD38-A

RECOMMENDED SPARE PARTS

Model Index: A FD38LPD (FD38LPDC)
 B FD38NGD (FD38NGDC)
 C FD38HOLPD (FD38HOLPDC)
 D FD38HONGD (FD38HONGDC)

POS. NO	PART NO.				DESCRIPTION	
43	5304444437	A	B	C	D	Shelf, left side
44	5304444438	A	B	C	D	Tray, drip pan
45 #	5304444439	A	B	C	D	Electrode, main burner
46 #	5304445081	A	B	C	D	Electrode, side burner
47	5304445082	A	B	C	D	Panel, igniter access
48 #	5304447641	A	-	C	-	Elbow, LP, IR burner rear, with orifice
48 #	5304447642	-	B	-	D	Elbow, NG, IR burner rear, with orifice
49 #	5304447646	A	B	C	D	Hose, gas, infrared burner, rear
50 #	5304447638	A	B	C	D	Elbow, gas fitting, manifold-to-T
51 #	5304447639	A	B	C	D	Connector, T
52 #	5304446174	A	B	C	D	Hose, gas, 10", main supply
53 #	5304447640	A	B	C	D	Hose, gas, 16", to side burner
54 #	5304447623	A	B	C	D	Elbow, main connection
55 #	5304447624	A	B	C	D	Fitting, main connection
*	5304444441	A	B	C	D	Bolt, valve/manifold
*	5304444442	A	B	-	-	Bolt, wheel & cart
*	5304444443	A	B	-	-	Nut, door, bottom pivot
*	5304444444	A	B	-	-	Screw, door, bottom pivot
*	5304445048	A	B	C	D	Screw, bezel/valve
*	5304444446	A	B	C	D	Screw, hood handle end
*	5304444447	A	B	C	D	Screw, self-tapping
*	5304444661	A	B	C	D	Wire, igniter, infrared burner
*	5304444449	A	B	C	D	Wire, igniter, main burner, left & right
*	5304444658	A	B	C	D	Wire, igniter, bottom, infrared