







Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator System Controller – For Models 2180EL(ER) and 2181EL(ER)





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER





Pralinator Digital System Controller - For Models 2181DEL, 2181DER




Pralinator Digital System Controller - For Models 2181DEL, 2181DER




Pralinator Digital System Controller - For Models 2181DEL, 2181DER




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle—Interior, Mounting, Drive, and Coupling (cont.)



Kettle—Interior, Mounting, Drive, and Coupling (cont.)




Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom




**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom



**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

Kettle Bottom



**Model 2181EL/ER Shown
(Model 2180EL/ER only has 2 Elements)**

ORDERING SPARE PARTS

1. Identify the needed part by checking it against the photos, illustrations, and/or the parts list.
2. When ordering, please include part number, part name, and quantity needed.
3. Please include the machine's model name, serial number, and date of manufacture (located on the machine nameplate) with your order.
4. Address all parts orders to:

Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807

or, place orders at:

(800) 543-0862

(513) 769-7676

Fax: (513) 769-8500

E-mail: info@gmpopcorn.com

Web Page: www.gmpopcorn.com