

# *Nacho Cheese Warmer*

Part No. 38409

## Instruction Manual

Model #2365, #2365LS and #2365EX



 **GOLD MEDAL**®

**FUNFOOD EQUIPMENT & SUPPLIES**

Cincinnati, OH 45241-4807 USA

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |

## CABINET ASSEMBLY PARTS LIST

| Item No. | Model #2365 Part No. | Model #2365LS Part No. | Model #2365EX Part No. | Description                        |
|----------|----------------------|------------------------|------------------------|------------------------------------|
| 1        | 22038                | 22038                  | 42369                  | Lead In Cord                       |
| 2        |                      | 38077                  |                        | Socket, Lamp Holder                |
| 3        | 38227                | 38227                  | 38227                  | Thermostat                         |
| 4        |                      | 38272                  |                        | Light Baffle                       |
| 5        | 38279                | 38279                  | 38208                  | Tank Heat Element                  |
| 6        |                      | 38284                  |                        | Sign Cover                         |
| 7        |                      | 38291                  |                        | Lamp, 6 Watt White                 |
| 8        | 38294                | 38294                  | 38294                  | Insulation Wrap                    |
| 9        | 38295                | 38295                  | 38295                  | Insulation Bottom                  |
| 10       |                      | 38297                  |                        | Retaining Angle                    |
| 11       | 38303                | 38303                  | 38303                  | Temperature Scale                  |
| 12       | 38389                | 38389                  | 38389                  | Knob, Heat Control                 |
| 13       | 38417                | 38417                  | 38417                  | Well Body, Welded Assembly         |
| 14       | 38419                | 38419                  | 38419                  | Panel, Control                     |
| 15       | 38420                | 38420                  | 38420                  | Label, Fill to Line (not shown)    |
| 16       |                      | 38421                  |                        | Lighted Cabinet, Welded Assembly   |
| 17       | 38403                |                        | 38403                  | Unlighted Cabinet, Welded Assembly |
| 18       |                      | 38423                  |                        | Bottom Cover, Lighted              |
| 19       | 38418                |                        | 38418                  | Bottom Cover, Unlighted            |
| 20       | 42532                | 42532                  | 40328                  | Switch, Rocker                     |
| 21       | 40353                | 40353                  | 40353                  | Wire Nut, Black                    |
| 22       | 42828                | 42828                  | 42828                  | Sheet Metal Screw                  |
| 23       | 47010                | 47010                  | 47010                  | Label, Safe                        |
| 24       | 47300                | 47300                  | 47300                  | Tinnerman Fastener                 |
| 25       | 74119                | 74119                  | 74119                  | Warning, Disconnect Power          |
| 26       | n/a                  | n/a                    | n/a                    |                                    |
| 27       | 76026                | 76026                  | 76026                  | Strain Relief, Cord                |
| 28       |                      | 82189                  |                        | Label, Max. Lamp                   |
| 29       | 87149                | 87149                  | 87149                  | Label, Caution Disconnect          |
| 30       |                      | 87223                  |                        | Sleeving, Fiberglass               |
| 31       | 87247                | 87247                  | 87247                  | Bumper, Headed Screw               |