

Reddy Apple Cooker

Instruction Manual

Models: 4008, 4008EX, 4016 and 4016EX



 **GOLD MEDAL**[®]
FUNFOOD EQUIPMENT & SUPPLIES
Cincinnati, OH 45241-4807 USA


Ordering Spare Parts

1. Identify the desired part by checking it against the photos, illustrations, and/or the parts list.
2. When ordering, please include part number, part name, and quantity desired.
3. Please include your model name and machine serial number (located on the machine nameplate) with your order.
4. Address all parts orders to:

Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807
or, place orders at:
(513) 769-7676
Fax: (513) 769-8500
E-mail: goldme19@eos.net

Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369



Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369



Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369




Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369



Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369




Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369




Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369



Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369




Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369




Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369



Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369




Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310


(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317

(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts – Apple Cooker Pot

Heat Control
P/N 87048
(EX) Heat Control 240v
P/N 87301



Lead-In Cord, 15 amp Plug
P/N 87085
(EX) Power Supply Cord
P/N 42369



Knob, Heat Control
P/N 87049

Pilot Light, 125v - Red
P/N 41033
(EX) Pilot Light, 240v - Red
P/N 41032

Heat Element, 120v
(4008) 1500 Watts
P/N 38235
(4016) 1800 Watts
P/N 38310

(4008EX) Heat Element, 220v 1500 Watts
P/N 38257
(4016EX) Heat Element, 230v 1800 Watts
P/N 38317


(On Underside of the Well Body)
High Limit Thermostat
P/N 76288



Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314




Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188

Parts - Apple Cooker Pot (cont.)

Rubber Feet (x4)
P/N 87247

Bottom Plate
P/N 38176



Paper Sign
P/N 38329
Sign Cover Lexan
P/N 38105
Sign Cover Acrylic
P/N 38106
Light Bulb – Clear (x2)
P/N 47422

*Not Available on
4008EX

Pot, Apple Cooker
P/N 38236
Steam N Clean Lid
P/N 38314



Parts Not Shown:
Insulation Blanket
P/N 38220
Bottom Insulation
38188