HOBART

CATALOG OF

REPLACEMENT PARTS




MODEL HP15ES
ELECTRIC PRESSURE FRYER

ML-126820

A product of HOBART CORPORATION 701 S. RIDGE AVENUE TROY, OHIO 45374-0001

FORM 43030 (November 2001)




LID ASSEMBLY

 © HOBART CORPORATION

LID ASSEMBLY


ILLUS. PL-55849	PART NO.	NAME OF PART	AMT.
1	00-360661	Stud – Aluminum Handle	3
2	00-360660	Handle – Aluminum	3
3	00-360758	Post – Locking Screw	1
4	00-360637	Collar – Knurled Screw Post	1
5	00-360659	Bearing – Threaded Bronze	1
6	SC-075-10	Set Screw 1/4-20 x 3/16 Soc. Hdls., Cup Pt.	2
7	00-360675	Valve – Relief	1
8	00-854317-00084	Arm – Lid Crossover	1
9	00-360774	Nut	1
10	00-360626	Post – Lock	1
11	00-360627	Catch – Overarm Post	1
12	WS-025-01	Washer	1
13	00-360774	Nut	1
14	00-360746	O-Ring (Inner Lid) 4.850 I.D.	1
15	00-360747	O-Ring (Outer) 12.475 I.D.	1
16	00-360775	Nut – Lock	1
17	00-360761	Spring – Plunger	1
18	00-360762	Gasket – Lock	1
19	SC-121-49	Mach. Screw 10-32 x 1/4 Flat Hd.	6
20	00-360764	Gasket – Retainer	1
21	00-360853-00163	Plunger – Locking	1
22	SC-117-73	Mach. Screw 10-32 x 5/8 Phil. Truss Hd.	6
23	00-360763	Plate – Inner	1
24	00-360760	Gear – Star Locking	1
25	00-360853-00151	Bearing – Thrust	2
26	00-854317-00081	Kit – Lift Arm Pin	1
27	00-360774	Nut	1
28	WS-025-01	Washer	1
29	00-360759	Lid	1
30	00-854317-00063	Post – Rear Swivel	1
31	00-360778	Bearing	1
32	00-854317-00077	Screw	4
33	00-854317-00082	Yoke – Crossover Arm	1
34	00-360778	Bearing	1
35	00-854317-00062	Nut	1
36	00-854317-00083	Plate – Yoke Inner	2
37	00-854317-00048	Bearing – Thrust	2
38	00-854317-00085	Pin – Stop	2
39	00-854317-00066	Plate – Overarm Skid	2
40	00-854317-00075	Pin 1/8 x 5/8	4
41	00-360623	Gauge – Pressure	1
42	00-360629	Pin – Stop Swivel	1
43	SC-075-10	Set Screw 1/4-20 x 3/16 Soc. Hdls., Cup Pt.	1
44	SC-047-12	Set Screw 1/4-20 x 3/8 Soc. Hdls., Cup Pt.	1
45	00-854317-00065	Bolt – Lid Pivot	1
46	00-360789	Key	1
47	00-360673	Hub – Handle	1
48	SC-055-03	Set Screw 3/8-16 x 3/8 Hdls., Cup Pt.	1
49	00-360789	Key	1



CONTROL PANEL

CONTROL PANEL


ILLUS. PL-55892	PART NO.	NAME OF PART	AMT.
1	NS-048-01	Wing Nut 1/4-20	2
2	00-360853-00072	Washer – Stop	2
3	00-854317-00020	Control Panel Housing	1
4	00-854317-00012	Decal – Control Panel Overlay	1
5	00-854317-00024	Rocker Switch	1
6	00-854317-00001	Controller – Mini Chef 2000®	1
7	00-360853-00148	Transformer (24 V.)	1
8	00-854317-00022	Connector – Molex	1


1
2
3
4-5-6
7-8-9
10
11
12
13
14
15
16
17
18
19
20
21
22-23-24
25 THRU 29
30-31-32
33
34
35
36
37
38
39
40
41
PL-56029

UNDERSIDE

UNDERSIDE


ILLUS. PL-56029	PART NO.	NAME OF PART	AMT.
1	00-360786	Cleaner – Drain (Wood)	1
2	00-360757	Scraper – Flexible	1
3	00-854317-00014	Cover – Countertop	1
4	00-360687	Catch – Magnetic Door	1
5	SC-019-28	Mach. Screw 8-32 x 1/4 Bndg. Hd.	2
6	WL-008-07	Lockwasher #8 Internal Shakeproof	2
7	00-360691	Pull – Door	1
8	SC-081-12	Mach. Screw 8-32 x 1 1/2 Rd. Hd.	1
9	WL-008-07	Lockwasher #8 Internal Shakeproof	1
10	00-854317-00019	Door	1
11	00-854317-00059	Valve – Condensate Drain	1
12	00-360853-00154	Pipe – Drain	1
13	00-854317-00005	Extension – Drain Pipe	1
14	00-854317-00071	Bracket – Quick Disconnect	1
15	00-854317-00026	Screw 10-32 x 1/2	2
16	00-854317-00049	Disconnect – Quick	1
17	00-360718	Extension – Shut Off Valve	1
18	00-854317-00004	Cotter Pin 3/32 x 1 (SST)	1
19	00-854317-00068	Elbow 1 x 90 Deg. Modified	1
20	00-854317-00086	Nipple 1 x 4 3/4	1
21	FP-013-27	Elbow 1 x 90 Deg.	1
22	00-360853-00101	Caster – Plain (Threaded)	2
23	00-360853-00102	Caster – W/Brake (Threaded)	2
24	00-360853-00103	Leg – Fryer (Threaded)	4
25	00-360853-00038	Flange – Front Leg	2
26	00-360853-00039	Flange – Rear Leg	2
27	00-360853-00123	Screw 1/2-13 x 2 Sq. Hd.	4
28	WL-008-17	Lockwasher 1/4 Internal Shakeproof	12
29	NS-046-38	Mach. Nut 1/4-20 Hex	12
30	00-854317-00010	Board – Terminal (AC Input)	1
31	00-854317-00038	Lug – Ground	1
32	00-854317-00035	Label – High Voltage	1
33	00-854317-00053	Hose – Flex	1
34	00-854317-00050	Elbow 1/2 x 90 Deg.	1
35	00-854317-00058	Valve – Check	1
36	00-854317-00051	Nipple 1/2	1
37	00-854317-00013	Fitting – Hex Kettle Drain	1
38	00-854317-00087	Drain – Kettle	1
39	00-854317-00032	Washer 9/16	1
40	00-360753	Spring	1
41	00-854317-00092	Cap Screw 1/4-20 x 1 1/4 Soc. Hd. (SST)	3
	00-854317-00091	Clamp – Kettle	3
	00-360755	Gloves (Pair)	1



SOLENOID AND EXHAUST

SOLENOID AND EXHAUST


ILLUS. PL-56026	PART NO.	NAME OF PART	AMT.
1	00-854317-00007	Receptacle – Solenoid	1
2	00-360853-00090	Housing – Coil (250 V.)	1
3	00-360635	Gasket – Upper Valve Body	1
4	00-360853-00193	Pressure Relief Valve Assy. (Incls. Items 3 & 5)	1
5	00-360853-00194	O-Ring	2
6	00-854317-00025	Mach. Screw 10-32 x 3/8 Truss Hd.	2
7	00-854317-00027	Mach. Screw 1/4-20 x 3/8 Truss Hd.	1
8	00-360853-00197	Thumb Screw (Brass)	1
9	00-360853-00196	O-Ring	1
10	00-360853-00172	Bracket – Support	1
11	00-360853-00195	Block – Solenoid	1
12	00-854317-00006	Pipe – Exhaust	1
13	00-360768	Union & Gasket	1
14	00-360734	Tank Assy. – Exhaust	1
15	00-360733	Gasket – Access Lid	1
16	00-360732	Lid – Exhaust Tank	1
17	SC-022-40	Mach. Screw 1/4-20 x 3/4 Flat Hd. (SST)	2
18	00-360853-00100	Pipe – Exhaust	1
19	00-360782	O-Ring	1
20	00-360771	Bushing – Exhaust	1
21	00-360632	Line – Exhaust (SST)	1
22	00-360773	Pipe 5/8 x 1/2 MPT	1
23	00-854317-00008	O-Ring	2
24	00-360744	Elbow – Exhaust	1



KETTLE ASSEMBLY

KETTLE ASSEMBLY


ILLUS. PL-56027	PART NO.	NAME OF PART	AMT.
1	00-360853-00192	Handle	1
2	00-360853-00191	Basket	1
3	00-360853-00173	Screen – Crumb	1
4	00-854317-00003	Element – Heating	1
5	00-854317-00093	Nut - Upper Element Mounting Special (SST)	2
6	SC-110-97	Mach. Screw 10-32 x 1/2 Slotted Truss Hd. (SST)	2
7	00-854317-00094	Nut – Lower Element Mounting 10-32 Hex (SST)	2
8	00-854317-00011	Probe – Temperature	1
9	00-854317-00009	Switch – High Limit	1
10	00-854317-00089	Bracket – High Limit Mounting	1
11	00-854317-00090	Plate – High Limit Mounting	1
12	SC-124-02	Mach. Screw 8-32 x 1/2 Slotted Truss Hd. (SST)	2
13	00-854317-00016	Kettle	1



ELECTRICAL CONTROLS

ELECTRICAL CONTROLS


ILLUS. PL-56024	PART NO.	NAME OF PART	AMT.
1	00-854317-00015	Cover Plate – Hood Wire Access	1
2	SC-019-28	Mach. Screw 8-32 x 1/4 Bndg. Hd.	2
3	00-854317-00037	Board Assy. – Terminal	1
4	00-360853-00218	Contactor (3 Pole, 240 V.)	2
5	00-854317-00018	Cabinet	1
6	SC-019-28	Mach. Screw 8-32 x 1/4 Bndg. Hd.	2
7	00-854317-00021	Holder – Fuse	2
8	00-854317-00002	Fuse	2
9	00-854317-00017	Cover – Contactor Cabinet	1
10	SC-019-28	Mach. Screw 8-32 x 1/4 Bndg. Hd.	6
11	00-854317-00036	Label – Warning	1
12	00-854317-00035	Label – High Voltage	1
	00-854317-00033	Grommet – Rubber 5/8	1
	00-854317-00034	Grommet – Rubber 1/2	1



EXHAUST HOOD AND FILTER

EXHAUST HOOD AND FILTER

ILLUS. PL-56025	PART NO.	NAME OF PART	AMT.
1	00-854317-00040	Panel – Access	1
2	00-360853-00129	Switch – Filter Interlock	3
3	00-360853-00130	Actuator – Filter Switch	3
4	00-360853-00131	Bracket – Interlock	1
5	00-360853-00009	Filter – Refillable Charcoal	1
6	00-360853-00208	Filter – Charcoal Refill Media	AR
7	00-360853-00008	Filter – Air	1
8	00-360853-00007	Filter – Grease	1
9	00-360853-00004	Cup – Grease	1
10	00-360853-00002	Manifold Assy. – Exhaust	1
11	00-360853-00003	Gasket – Exhaust Manifold	2
12	00-360853-00136	Hood – Housing	4
13	00-360733	Gasket – Condensation Tank	1
14	00-360853-00005	Tube Assy. – Exhaust	1
15	00-854317-00045	Board Assy. – PC	1
	00-854317-00023	Connector – Amp. (5 Pin)	1
	00-854317-00056	Connector – Amp. (5 Pin)	1



BLOWER AND DAMPER

ILLUS. PL-56028	PART NO.	NAME OF PART	AMT.
1	00-360853-00133	Guard – Blower	1
2	00-854317-00043	Damper Assy.	1
3	00-360853-00006	Cap – Hood	1
4	00-854317-00039	Blower and Motor	1
5	00-854317-00041	Cover – Enclosure	1
6	00-854317-00042	Enclosure – Air Flow Switch	1
7	00-854317-00046	Switch – Air Flow	1
8	00-854317-00047	Vane – Air	1
9	00-854317-00044	Damper Actuator Assy.	1