


AM16X PROGRAMMING CARD

EDIT PARAMETERS ENTER MANAGER SECURITY CODE: 1001




EDIT PARAMETERS IS REQUIRED TO CHANGE ALL CODES BELOW


CHEMICAL PUMP Enable or disable the detergent pump or rinse aid pump.



DELIME Enables or disables the delime reminder alert.




DELIME LOCKOUT Enables or disables the lockout on the machine if delime reminder is ignored 10 times.



DELIME CYCLE LIMIT Increase or decrease the cycles until the delime reminder appears.




TEMPERATURE UNITS Allows the choice of Fahrenheit or Celsius.



ENERGY SAVER MODE Set the time that the machine must sit idle until energy saver mode is activated.



LANGUAGE Allows the choice of English, French or Spanish language.



WASH PROGRAM Sets the default wash cycle to 1, 2, 4 or 6 minutes.



DOOR LOCKED INDIC. Enable or disable the visual to show when the door lock is engaged or disengaged.



POWER DOWN CONFIRM Enables or disables the screen to ask if the user would like to power down the machine after the power button is pressed.

→ until POWER DOWN CONFIRM → to YES or NO → → until EXIT MENU

CHEMICAL MONITORS Allows monitoring for sanitizer and detergent (when Hobart chemical pumps are installed). Disabled ignores chemical status. Enable provides a warning when chemical is not present. Lockout enabled will lock out the machine when chemical is not present.

→ until DETERGENT or SANITIZER MONITOR → to ENABLE DISABLE or LOCKOUT ENABLED → → until EXIT MENU

CHEMICAL PUMP LOC. Internal enables Hobart chemical pumps (when equipped). External indicates third party chemical pumps are equipped.

→ until CHEMICAL PUMP LOC. → to INTERNAL or EXTERNAL → → until EXIT MENU

RAPID FILL Enable or disable rapid fill function (accessory must be installed).

→ until RAPID FILL → to DISABLE or ENABLED → → until EXIT MENU

MODBUS Enable machine registers to be read by third party monitoring equipment.

→ until MODBUS → to DISABLE or ENABLED → → until EXIT MENU

WASH TANK TEMP DELAY Delay the wash cycle until the wash temperature has reached the NSF minimum.

→ until WASH TANK TEMP DELAY → to DISABLE or ENABLED → → until EXIT MENU

STRAINER BASKET Ignore, alert, or lockout the machine when the strainer basket is not in place.

→ until STRAINER BASKET → to Ignore, Alert, or Lockout → → until EXIT MENU

EXIT MENU TO MAIN MANAGER MENU

DELIME NOW Allows for a single delime cycle to be run from the menu at anytime.

Note: this operation takes 20-45 minutes depending on conditions.

→ until DELIME NOW → → to YES or NO → (this will exit menu)

PRIME CHEM PUMPS Allows for automatic priming of chemical pumps when chemicals are not sensed

→ until PRIME CHEM PUMPS → to START PRIMING, if not, EXIT MENU → to begin priming

EXIT MAIN MANAGER MENU

→ until EXIT MENU →

