




NOTE: Use this diagram with motor/pump part # [052982](#) (See parts list)

MOTOR/PUMP SIDE



WIRING DIAGRAM



NOTE: Use this diagram with motor/pump part # [055173](#) (See parts list)