

# 50HZ

MODELS

- 50MAX04 TS905053-353
- 50MRX04 TS905054-353
- 50MWX04 TS905055-353

# 50HZ

CAUTION: DISCONNECT POWER BEFORE WORKING  
ON ELECTRICAL CIRCUITRY.

SEE SERIAL PLATE FOR VOLTAGE

SHOWN IN THE OFF POSITION



