


THERMOSTAT

TEMPERATURE
SENSOR

POWER PLUG



OVERLOAD
PROTECTOR

COMPRESSOR

STARTER

CONDENSER FAN

EVAPORATOR FAN


EVAPORATOR FAN


EVAPORATOR FAN

LAMP
SWITCH

BALLAST

LAMP





TEMPERATURE
SENSOR

THERMOSTAT

POWER PLUG

G
L
N

OVERLOAD
PROTECTOR

COMPRESSOR

STARTER

CONDENSER FAN

EVAPORATOR FAN

EVAPORATOR FAN

LAMP
SWITCH

BALLAST

LAMP

