


Parts Breakdown

Model BS-IT-1829-L 45507



Parts Breakdown

Model BS-IT-1829-L 45507

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
34915	Door (Not Interchangeable) for 45507	1	34937	Knob Transporter Guide (n° 1) for 45507	25	34960	Cutting Guide to Subdivide to Pieces for 45507	49
34916	Knob to Close the Door for 45507	2	34938	Blade Guide Ring Nut in Aluminium (n° 1) for 45507	26	34961	Knob of the Transporter Guide Pole for 45507	50
34917	Rubber Washer for 45507	3	34939	Blade Guide Plug (n° 1) for 45507	27	34962	Nut for 45507	51
34918	Brass Closing Screw for 45507	4	34940	Blade Guide in Aluminium for 45507	28	34963	Pivot Meat Pusher for 45507	52
34919	Nut for 45507	5	34941	Blade Guide Pole for 45507	29	34964	Meat Pusher for 45507	53
34920	Lower Protection for 45507	6	34942	Washer for 45507	30	34965	Washer for 45507	54
34921	Upper Fly-Wheel Screw for 45507	7	34943	Nut for 45507	31	34966	Screw for 45507	55
34922	Screw to Protect from Dust for 45507	8	19953	Blade Protection for 45507	32	34967	Connection of Knob Meat Pusher for 45507	56
34923	Bearing 6203 2RS for 45507	9	34944	Upper Fly-Wheel Pivot for 45507	33	34968	Knob Meat Pusher for 45507	57
34924	Lower Fly-Wheel Screw for 45507	10	34945	Nut for 45507	34	34969	Carter Motor for 45507	58
34925	Screw for 45507	11	34946	Adjustment Fly-Wheel Screw for 45507	35	34970	Motor for 45507	59
19950	Upper Fly-Wheel for 45507	12	34947	Lamination for 45507	36	34971	Support to Close Cables for 45507	60
19951	Lower Fly-Wheel for 45507	13	34948	Slide for 45507	37	34972	Micro Support to Close Cables for 45507	61
10328	Band Saw Blade for 45507	14	34949	Washer for 45507	38	34973	Motor Support for 45507	62
34927	Hinge for 45507	15	34950	Nut for 45507	39	34974	Screw for 45507	63
34928	Screw for 45507	16	34951	Tension Grip Bearing for 45507	40	34975	Meat Table for 45507	64
34929	Washer for 45507	17	34952	Tension Grip Spring for 45507	41	17853	Bakelite Plate for 45507	65
34930	Shavehook (n° 1) for 45507	18	34953	Tension Grip Knob for 45507	42	19954	Microswitch for 45507	66
34931	Shavehook Pivot (n° 1) for 45507	19	34954	Opening for 45507	43	34976	Cable Closer PG 11 for 45507	67
34932	Rubber Washer for 45507	20	34955	Screw for 45507	44	34977	Cable Closer PG 9 for 45507	68
34933	Screw to Face the Working Surface for 45507	21	34956	Screw to Support Cutting Guide for 45507	45	34978	Screw for 45507	69
34934	Bearing Pivot for 45507	22	34957	Knob to Support Guide for 45507	46	34979	Body (Not Interchangeable) for 45507	70
34935	Bearing to Control the Push for 45507	23	34958	Cutting Guide Support for 45507	47	34980	Switch ON-OFF + Plastic Box for 45507	71
34936	Nut for 45507	24	34959	Cutting Guide Pole for 45507	48	34981	Power Cord for 45507	72