


# Parts Breakdown

Model MS-IT-0195-S 13607



# Parts Breakdown

## Model MS-IT-0195-S 13607

| Item No. | Description                       | Position | Item No. | Description                     | Position | Item No. | Description                         | Position |
|----------|-----------------------------------|----------|----------|---------------------------------|----------|----------|-------------------------------------|----------|
| 33883    | Sharpener Base for 13607          | A1       | 14863    | Thickness Adj. Plate for 13607  | B19      | 33880    | Washer for 13607                    | B61      |
| 33884    | Washer for 13607                  | A3       | 14864    | Strain Relief for 13607         | B20      | 33881    | Cam for 13607                       | B62      |
| 33885    | Screw for 13607                   | A4       | 14865    | Tie Rod for 13607               | B21      | 14905    | Cam Screw for 13607                 | B63      |
| 33886    | Sharpener Shaft for 13607         | A5       | 14866    | Deflector Screw for 13607       | B22      | 14906    | Slide Support for 13607             | B64      |
| 33887    | Screw for 13607                   | A6       | 14867    | Slice Deflector for 13607       | B23      | 14907    | Slide Pin for 13607                 | B65      |
| 33888    | Nut for 13607                     | A7       | 14868    | Screw for 13607                 | B24      | 14908    | Screw TC for 13607                  | B66      |
| 33889    | Screw for 13607                   | A8       | 14869    | Circlip for 13607               | B25      | 14909    | Screw TC for 13607                  | B67      |
| 33890    | Washer for 13607                  | A9       | 14870    | Circlip for 13607               | B26      | 14910    | Nut for 13607                       | B68      |
| 33891    | Screw for 13607                   | A10      | 14871    | Pulley Bearing for 13607        | B27      | 14911    | Screw Testa CACC for 13607          | B69      |
| 33892    | Push Knob for Sharpener for 13607 | A11      | 14872    | Pulley for 13607                | B28      | 14912    | Screw for 13607                     | B70      |
| 33893    | Ball Bearing for 13607            | A12      | 14873    | Belt for 13607                  | B29      | 14913    | Plate for 13607                     | B71      |
| 33894    | Spring for 13607                  | A13      | 14876    | Shaft for 13607                 | B30      | 14914    | Screw TC for 13607                  | B72      |
| 33895    | Washer for 13607                  | A14      | 14877    | Screw for 13607                 | B31      | 14915    | Slide Bar Spring for 13607          | B73      |
| 33896    | Screw for 13607                   | A15      | 14878    | Screw TC for 13607              | B32      | 14916    | Slide Bar for 13607                 | B74      |
| 33897    | Washer for 13607                  | A16      | 13584    | Blade 30-3-155 for 13607        | B33      | 14917    | Carriage for 13607                  | B75      |
| 33898    | Sharpener Housing for 13607       | A17      | 14880    | Screw for 13607                 | B34      | 14918    | Carriage Screw for 13607            | B76      |
| 33899    | Grinding Shaft for 13607          | A18      | 14881    | Blade Cover for 13607           | B35      | 14919    | Carriage Nut for 13607              | B77      |
| 14883    | Omcn F Stone 40x08x06 for 13607   | A19      | 14882    | Nut for 13607                   | B36      | 14920    | Pin for 13607                       | B78      |
| 33901    | Washer for 13607                  | A20      | 14885    | Pin for 13607                   | B39      | 14921    | Bearing for 13607                   | B79      |
| 33902    | Nut for 13607                     | A21      | 14886    | Pin for 13607                   | B40      | 14923    | Screw for 13607                     | B80      |
| 33914    | G Stone 40x08x06 for 13607        | A22      | 14887    | Support for 13607               | B41      | 14924    | Wing Nut for 13607                  | B81      |
| 33904    | Honing Shaft for 13607            | A23      | 14888    | Spring for 13607                | B42      | 14925    | Plate for 13607                     | B82      |
| 33905    | Sharpener Cover for 13607         | A24      | 14889    | Spring for 13607                | B43      | 14926    | Motor Adjustment Bar for 13607      | B83      |
| 33906    | Spring for 13607                  | A25      | 14890    | Small Push Button for 13607     | B44      | 14927    | Spring for Adjustment Bar for 13607 | B84      |
| 14849    | Casing for 13607                  | B1       | 14976    | Wrist Guard Plate for 13607     | B46      | 14928    | Motor for 13607                     | B85      |
| 14850    | Screw for 13607                   | B2       | 14893    | Meat Grip Knob for 13607        | B47      | 14929    | Screw for 13607                     | B86      |
| 14875    | Index Knob for 13607              | B3       | 14894    | Screw TPSV for 13607            | B48      | 14930    | Ventosa for 13607                   | B87      |
| 14852    | Screw for 13607                   | B4       | 14895    | Meat Grip for 13607             | B49      | 14931    | Motor Pin for 13607                 | B88      |
| 14853    | Rivet for 13607                   | B5       | 14896    | Pin for 13607                   | B50      | 14932    | Circlip for 13607                   | B89      |
| 14854    | Screw for 13607                   | B6       | 14897    | Spring for 13607                | B51      | 14933    | Foot for 13607                      | B90      |
| 14855    | Plate for 13607                   | B7       | 14898    | Lock for 13607                  | B52      | 14934    | Wrist Guard Screw for 13607         | B91      |
| 14922    | On / Off Switch for 13607         | B8       | 14899    | Meat Plate for 13607            | B53      | 14935    | Pulley Assembly for 13607           | B93      |
| 14856    | Capacitor for 13607               | B9       | 14900    | Screw for 13607                 | B54      | 21252    | Bottom Cover for 13607              | D4       |
| 14857    | Clamp for 13607                   | B10      | 14901    | Knob for 13607                  | B55      | 33907    | Screw for 13607                     | D13      |
| 14858    | Screw TC for 13607                | B11      | 14902    | Meat Plate Support for 13607    | B56      | 33908    | Safety Switch Holder for 13607      | D14      |
| 14859    | Power Cord for 13607              | B15      | 14903    | Carriage Knob for 13607         | B57      | 33909    | Pivot Chuck for 13607               | D15      |
| 14860    | Screw TE for 13607                | B16      | 33877    | Screw for Support Bar for 13607 | B58      | 33882    | Slide Support Complete for 13607    |          |
| 14861    | Washer for 13607                  | B17      | 33878    | Support Bar for 13607           | B59      | 14937    | Complete Sharpening Assy. for 13607 |          |
| 14862    | Support for 13607                 | B18      | 33879    | Screw for 13607                 | B60      |          |                                     |          |