


# Parts Breakdown

Model MS-IT-0250-C 31343



# Parts Breakdown

## Model MS-IT-0250-C 31343

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33968	Sharpener Base for 31343	A1	15098	Deflector Screw for 31343	B22	15133	Plate for 31343	B71
33969	Thumb Screw for Sharpener for 31343	A2	17687	Slice Deflector for 31343	B23	15134	Screw TC for 31343	B72
33970	Washer for 31343	A3	15099	Screw for 31343	B24	15135	Slide Bar Spring for 31343	B73
33971	Screw for 31343	A4	33953	Circlip for 31343	B25	15136	Slide Bar for 31343	B74
33972	Sharpener Shaft for 31343	A5	33954	Circlip for 31343	B26	15137	Carriage for 31343	B75
33973	Screw for 31343	A6	33955	Pulley Bearing for 31343	B27	33966	Carriage Screw for 31343	B76
33974	Nut for 31343	A7	33956	Pulley for 31343	B28	15140	Carriage Nut for 31343	B77
33975	Screw for 31343	A8	15100	Belt TB2310 1/8 8 Ribs for 31343	B29	15141	Pin for 31343	B78
33976	Washer for 31343	A9	33957	Shaft for 31343	B30	15142	Bearing for 31343	B79
33977	Screw for 31343	A10	33958	Screw for 31343	B31	15143	Screw for 31343	B80
33978	Push Knob for Sharpener for 31343	A11	15101	Screw TC for 31343	B32	15144	Wing Nut for 31343	B81
33979	Ball Bearing for 31343	A12	13586	Blade 40-3-210 for 31343	B33	15145	Plate for 31343	B82
33980	Spring for 31343	A13	15103	Screw for 31343	B34	15146	Motor Adjustment Bar for 31343	B83
33981	Washer for 31343	A14	15105	Nut for 31343	B36	15147	Spring for Adjustment Bar for 31343	B84
33982	Screw for 31343	A15	15106	Pin for 31343	B39	15148	Motor for 31343	B85
33983	Washer for 31343	A16	15107	Pin for 31343	B40	15149	Screw for 31343	B86
33984	Sharpener Housing for 31343	A17	15108	Support for 31343	B41	15150	Ventosa for 31343	B87
33985	Grinding Shaft for 31343	A18	15109	Spring for 31343	B42	15151	Motor Pin for 31343	B88
33914	G Stone 40x08x06 for 31343	A19	15110	Spring for 31343	B43	15152	Circlip for 31343	B89
33987	Washer for 31343	A20	15111	SM Push Button for 31343	B44	14933	Foot for 31343	B90
33988	Nut for 31343	A21	15112	Screw for 31343	B45	15154	Pulley Assembly for 31343	B93
17212	F Stone 45x08x06 for 31343	A22	15114	Meat Grip for 31343	B49	64791	Screw for 31343	D1
33990	Honing Shaft for 31343	A23	15115	Pin for 31343	B50	64792	Spacer for 31343	D2
33991	Sharpener Cover for 31343	A24	15117	Lock for 31343	B52	64793	Nut for 31343	D3
33992	Spring for 31343	A25	15118	Meat Plate for 31343	B53	25162	Bottom Cover for 31343	D4
15082	Casing for 31343	B1	15119	Screw for 31343	B54	64794	Circuit Board for 31343	D5
15083	Screw for 31343	B2	AG040	Aluminum Arm.X AFF. for 31343	B56	64795	Screw for 31343	D6
14940	Index Knob for 31343	B3	AG041	Bushing BP for 31343	B56	64796	On/Off Switch for 31343	D7
33951	Screw for 31343	B4	15122	Screw for Support Bar for 31343	B58	64797	Terminal Block for 31343	D9
15085	Rivet for 31343	B5	15123	Support Bar for 31343	B59	18933	Micro Switch for 31343	D10
15086	Screw for 31343	B6	15124	Screw for 31343	B60	33993	Tie Rod for 31343	D11
15087	Plate for 31343	B7	15125	Washer for 31343	B61	33994	Screw for 31343	D13
15088	Capacitor 12.5UF 370-470V for 31343	B9	15126	Cam for 31343	B62	25163	Tie Rod Ring for 31343	D14
15089	Clamp for 31343	B10	15127	Cam Screw for 31343	B63	33996	Pivot Chuck for 31343	D15
15090	Screw TC for 31343	B11	15019	Slide Support for 31343	B64	64798	Screw for 31343	D16
14859	Power Cord for 31343	B15	33965	Slide Pin for 31343	B65	64799	Washer for 31343	D17
15092	Screw TE for 31343	B16	15128	Screw TC for 31343	B66	64800	Support Ring for 31343	D18
15093	Washer for 31343	B17	15129	Screw TC for 31343	B67	64801	Nut for 31343	D19
15094	Support for 31343	B18	15130	Nut for 31343	B68	64802	Ring for 31343	D20
15095	Thickness Adj. Plate for 31343	B19	15131	Screw Testa CACC for 31343	B69	14828	Blade Shield for 31343	D21
15096	Strain Relief for 31343	B20	15132	Screw for 31343	B70	41167	Complete Sharpening Assembly for 31343	