


Parts Breakdown

Model MS-IT-0300-U 13628



Parts Breakdown

Model MS-IT-0300-U 13628

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AJ331	Case for 13628	A1	AJ338	Bearing for 13628	A40	AJ345	Screw Inox for 13628	A77
34360	Set Screw TC for 13628	A2	34399	Spacer for 13628	A41	34419	Light for 13628	A78
34361	Set Screw TC for 13628	A3	15179	Belt TB2-360x12 for 13628	A42	15195	Switch - On/Off for 13628	A79
AJ332	Small Group Pin for 13628	A4	15180	Spindle Pulley for 13628	A43	AJ346	Square Bar for 13628	A80
AJ333	Screw TC for 13628	A5	AJ339	Spindle Pin for 13628	A44	AJ347	Bearing for 13628	A81
34365	Stop Plate for 13628	A6	34401	Set Screw for 13628	A45	34420	Bearing Pin for 13628	A82
34366	Strain Relief for 13628	A7	13594	Blade 40-3-250 (19) for 13628	A46	AJ348	Iron Bead for 13628	A83
34367	Set Screw TP for 13628	A8	15181	Screw TPSV for 13628	A47	15196	Set Screw PVC for 13628	A84
15176	Tie Rod for 13628	A9	15182	Blade Shield for 13628	A48	19246	Slide Bar Spring for 13628	A85
34368	Sharpener Tie Rod for 13628	A10	15183	Meat Grip Handle for 13628	A49	15197	Carriage Support for 13628	A86
AJ334	Pipette for 13628	A11	15184	Meat Grip Handle Screw for 13628	A50	34422	Screw TC for 13628	A87
34370	Washer for 13628	A12	AJ340	Presser for 13628	A51	AJ349	Round Bar for 13628	A88
34371	Screw TE for 13628	A13	34403	Plastic Dowel for 13628	A52	34424	Stop Plate for 13628	A89
34372	Shaft for Sharpener for 13628	A14	18937	Meat Tray Shaft Spring for 13628	A53	15073	Foot for 13628	A90
34373	Sharpener Pin for 13628	A16	34404	Meat Tray Shaft for 13628	A54	15198	Capacitor for 13628	A91
18016	Omcans Stone 50x08x06 for 13628	A17	AJ341	Plate for 13628	A55	AJ350	Condenser Clamp for 13628	A92
34375	Washer for 13628	A18	17690	Guide Plate for 13628	A56	34427	Screw TC for 13628	A93
34376	Nut for 13628	A19	AJ342	Arm for 13628	A57	AJ351	Nut for 13628	A94
34377	Set Screw for 13628	A20	15187	Carriage Knob for 13628	A58	AJ352	Nut for 13628	A96
34378	Nut for 13628	A21	34406	Screw TE for 13628	A59	34431	Washer for 13628	A97
34379	Screw TGS for 13628	A22	34407	Screw TE for 13628	A60	34432	Hinge for 13628	A98
34380	Sharpener Push Button for 13628	A23	15188	Guide Plate Support for 13628	A61	34433	Motor Support Shaft for 13628	A99
34381	Ball Bearing for 13628	A24	AJ343	Group Plate for 13628	A62	34434	Motor Tie Rod for 13628	A100
33032	45x9x6 Sharpening Stone for 13628	A25	34409	Screw TC for 13628	A63	15199	Guide Plate Support Cover for 13628	A101
34383	Sharpener Pin for 13628	A26	34410	Set Screw TC for 13628	A64	15078	Motor for 13628	A103
34384	Sharpener Pin Spring for 13628	A27	15189	Cam Guide for 13628	A65	AJ353	Cord for 13628	A104
AJ335	Sun Canopy EXCE for 13628	A28	15190	Nut for 13628	A66	AJ354	White Ring for 13628	A108
AJ336	Sharpening Body for 13628	A29	34412	Cam Screw for 13628	A67	AJ355	Protection of Electrical Parts for 13628	C4
34388	Washer for 13628	A31	AJ344	Corrugated Washer for 13628	A68	34437	Bearing Shaft for 13628	C23
34389	Screw TC for 13628	A32	34414	Set Screw for 13628	A69	25164	Tie Rod Ring for 13628	C24
34390	Sharpener Push Button for 13628	A33	15191	Cam for 13628	A70	34438	Set Screw for 13628	C25
34391	Sharpener Pin Spring for 13628	A34	34415	Screw TE for 13628	A71	34439	Set Screw for 13628	C26
AJ337	Bead for 13628	A35	34416	Screw TC for 13628	A72	34440	Tie Rod with Spring for 13628	C27
34393	Washer for 13628	A36	15192	Meat Deflector for 13628	A73	34441	Micro Switch for 13628	C28
34394	Screw TC for 13628	A37	15193	Deflector Screw for 13628	A74	15350	Complete Sharpener Assy for 13628	
34395	Clip for 13628	A38	34417	Copper Rivet for 13628	A75			
34397	Clip for 13628	A39	15194	Index Knob for 13628	A76			