


# Parts Breakdown

Model Santos 10 39687



# Parts Breakdown

## Model Santos 10 39687

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
39729	Complete Lever for 39687	10100	40699	Complete Friction Clutch for 39687	10600	73139	Washer 6x18 for 39687	10725
40683	Black Lever for 39687	10101	40700	Friction Clutch and Disc (Welded) for 39687	10601	73140	Capacitor 4 MF (110V and 220V) for 39687	10726
40421	Lever Axle (Pin) D8x34 for 39687	10102	40701	Screw HC M5x10 Stainless Steel for 39687	10605	AC370	Complete Rotor with Shaft for 39687	10731
40684	Complete Cup with Screw and Washer for 39687	10103	40529	Stainless Steel Driving Pin for 39687	10606	AC371	Lower Flange for 39687	10741
40685	Cup Locking Screw for 39687	10104	40702	Fiber Pushing Pin for 39687	10607	AC372	Ondulated Washer for 39687	10742
40686	Stainless Steel Cup Only for 39687	10105	40703	Steel Ball D6 for 39687	10608	73141	Stainless Steel Housing for 39687	10800
40687	Stainless Steel Washer for 39687	10106	40704	Brake Stainless Steel Spring for 39687	10609	44061	Complete Chromed Base NSF 110V for 39687	10900CB
73114	Stainless Steel Cover Only for 39687	10107	40705	Complete Drive Plate for 39687	10610	44062	Chromed Base Only for 39687	10901C
73115	Stainless Steel Spring for 39687	10108	AC367	Screw HC M6x8 for 39687	10613	40706	Plastic Drip Tray for 39687	10903
73116	Stainless Steel Spring Cap for 39687	10109	44060	Complete Motor 110V 60Hz for 39687	10700B	73144	Bottom Plate for 39687	10904
73117	Lever Washer for 39687	10110	73125	Complete Upper Flange for 39687	10701	40707	Switch for 39687	10905
40688	Perforated Strainer Stainless Steel for 39687	10200	73126	Upper Flange for 39687	10702	73145	On-Off Plate for 39687	10906
40689	Complete Stainless Steel Bowl with Nut for 39687	10300	73127	Bearing 6201 for 39687	10703	73146	Rubber Foot 22x10 for 39687	10907
73118	Stainless Steel Bowl for 39687	10301	73128	Bearing Washer for 39687	10704	73147	Washer 4x10 for 39687	10908
40690	Nylon Nut for 39687	10304	73129	Screw H4x8 Zn for 39687	10705	73148	Screw H4x16 Zn for 39687	10909
40691	Gasket D12x22x5 for 39687	10305	73130	Complete Lower Flange for 39687	10710	73149	Screw H4x8 for 39687	10910
40692	Polyethylene Washer for 39687	10306	73131	Lower Flange for 39687	10711	44063	Power Cord with USA Plug for 39687	10912B
44058	Chromed Aluminum Top (Bowl) with 4 Nuts for 39687	10400C	73132	Bearing 6201 for 39687	10712	73151	Screw 4.8x16 Zn for 39687	10913
44059	Chromed Aluminum Top Only (Bowl) for 39687	10401C	73133	Bearing Washer for 39687	10713	73152	Screw H M4x8 Zn Autotar for 39687	10914
40695	Bowl Locking Nut for 39687	10402	73134	Screw H4x10 Zn for 39687	10714	73153	Screw 4x10 for 39687	10917
40696	Complete Intermediate Flange for 39687	10500	AC368	Stator Only 120V 60HZ for 39687	10715NB	73154	Screw H4x10 for 39687	10918
40697	Bronze Bearing for 39687	10502	AC369	Complete Rotor with Shaft for 39687	10718NB	73155	Washer AZ4 for 39687	10919
40698	Gasket 12x22x5 for 39687	10503	73135	Assembling Threaded Rod M5 for 39687	10721	73156	Screw H M5x12 Zn for 39687	10920
73120	Friction Plate for 39687	10504	73136	Nut H M5 Zn for 39687	10722	73157	Nut H M4 Stainless Steel for 39687	10921
73121	Intermediate Flange Only for 39687	10505	73137	Split Washer D5 for 39687	10723			
73122	Screw H4x12 for 39687	10506	73138	Washer AZ 5 for 39687	10724			