

OPERATING INSTRUCTIONS

PRINCE CASTLE INC. 
WORLDWIDE

Four-Pak Egg Ring and cover™ Model No. 246 Series



The Four-Pak egg rings make breakfast sandwiches in a snap. A non-stick coating allows operators to cook without waste by eliminating sticking. Cook up to four individual portions for egg sandwiches and signature breakfast entreés. Compact size makes efficient use of grill space.

PARTS LIST

Part No.	Description
246-2	Four Pak Egg Ring Cover Assembly
70-032	Knob
76-489	Screw
122-4	Egg Ring

LIMITED WARRANTY

This product is warranted to be free from defects in material and/or workmanship for a period of one year from the date of original installation. Any component which proves to be faulty during the warranty period will be replaced without cost to the customer.

OPERATION

1. Before using, wash cover and ring set with mild soap and water.
2. Place egg ring on grill surface.
3. Season grill & inside of rings.
4. Crack egg into each ring.
5. Cook until eggs reach desired consistency.

CLEANING

1. Remove egg rings for cleaning by snapping each ring out of the holder.
2. Use a non-abrasive cleaner.

IMPORTANT: Egg ring and cover are dishwasher safe.

PRINCE CASTLE INC. 
WORLDWIDE

355 East Kehoe Blvd. • Carol Stream, IL 60188

Tel: (630) 462-8800 • Fax: (630) 462-1460

Toll Free: 1-800-PCASTLE