



# Model: XO-1N

## Tabletop Convection Oven

Reference#	Description	Part #
ELECTRICAL COMPONENTS:		
1	Power Cord Assembly (120V)	<a href="#">2E-50-0375</a>
4	Motor Assy w/blower wheel (120V)	<a href="#">2U-250-1059</a>
5	Heating Element (120V)	<a href="#">2N-60-0205-A</a>
6	Cooling Fan (120V)	<a href="#">2U-50-0049</a>
	Cooling Fan (240V)	<a href="#">2U-97525</a>
8	Thermal Overload Safety (Auto Reset)	<a href="#">2T-66-1014</a>
9	Door Microswitch	<a href="#">PS-252-2004</a>
10	Fuse Holder	<a href="#">2E-50-0368</a>
11	20A Fuse	<a href="#">2E-50-0369</a>
12	Relay, DPDT, 20 amp, (120V)	<a href="#">2E-50-0433</a>
13	Relay, 3DPDT, (240V)	<a href="#">2E-66-9025</a>
CONTROLS:		
14	Power Switch (120V)	<a href="#">2E-50-1355</a>
	Power Switch (240V)	<a href="#">2E-66-3008</a>
15	Temperature Control - Oven	<a href="#">2T-66-1159</a>
	Temperature Control Knob	<a href="#">2R-50-0727</a>
16	Temperature Control Indicator Light (120V)	<a href="#">2J-50-0029</a>
	Temperature Control Indicator Light (240V)	<a href="#">2J-50-0030</a>
17	Timer 60-Minute Mechanical (120V, 60Hz)	<a href="#">2E-50-1094-B</a>
	Timer Knob	<a href="#">2R-50-1277</a>
18	Buzzer (120V)	<a href="#">2E-50-0419</a>
INTERIOR COMPONENTS:		
19	Element Cover	F7-98-1214
EXTERIOR COMPONENTS:		
20	Glass Door: (Left Hinge)	F7-98-9401-RP
21	Door Catch Assembly	<a href="#">2R-50-0421</a>
22	Gasket	<a href="#">2I-254-1008</a>
23	4" Appliance Leg	<a href="#">2R-1523B8301</a>
24	Handle	<a href="#">2R-50-1360</a>