
POWER SWITCH
L
E
N
POWER
PLUG
L
COMPRESSOR
SENSOR
EVAP.
COLDROOM
TRANSFORMER
M
CONDENSER FAN
OVERLOAD
PROTECTOR
STARTER
COMPRESSOR
DOORFRAME HEATER
M
EVAPORATOR FAN


POWER SWITCH
L
E
N
POWER
PLUG
L
COMPRESSOR
EVAP.
SENSOR
COLDROOM
TRANSFORMER
M
CONDENSER FAN
OVERLOAD
PROTECTOR
STARTER
COMPRESSOR
DOORFRAME HEATER
M
EVAPORATOR FAN
M
EVAPORATOR FAN


POWER SWITCH
L
E
N
POWER
PLUG
L
COMPRESSOR
EVAP.
SENSOR
COLDROOM
TRANSFORMER
M
CONDENSER FAN
OVERLOAD
PROTECTOR
STARTER
COMPRESSOR
HEATER
DOORFRAME
M
EVAPORATOR FAN
M
EVAPORATOR FAN
M
EVAPORATOR FAN