


# Unit Information


120 Volts – 60 Hz – 1200 Watts - 10 Amps  
 Produce up to 25 bubble waffles per hour  
 Beep signals when unit is ready and when waffle is cooked



## Bubble Waffle Maker with Replaceable Plates WBW300X




**037496**  
 WBW300X Unit




**032350**  
 Drip Pan



**032364**  
 Cup



**NEMA 5-15**



WWYY →  
 week week | year year



Illustration#	Part#	Description
1a	037497	Bubble Top Plate
1b	037509	Bubble Bottom Plate
2	037357	Screw (1 top plate - 1 bottom plate)
3	037356	Screw (5 top plate - 5 bottom plate)
4	037493	Screw (10 top inner plate - 10 bottom inner plate)
5	032352	Knob
6	016236	Hex Nut
7	032356	Washer
8	036241	Connector Pole
9	035316	Darkness Control Board (short tape)
10	032359	Screw (3 required)
11	032368	Toggle Switch
12	012409	Small Crimp Connector (5 required)
	019123	Large Crimp Connector
13	013731	Wire Tie (7 required)
14	037490	PCB Board
15	032359	Screw (4 required)
16	030638	Power Board Shield
17	037492	15.5" Red Lead Assembly (2 required)
18	037491	8" Green Lead Assembly
19	035298	Ground Screw (2 required)
20	032751	Ground Spring Washer (2 required)
21	032371	Cord Plate
22	033494	Cord Set
23	035476	Strain Relief
24	037494	Green Light with Leads
25	037495	Red Light with Leads
26	032351	Bottom Plate
27	032353	Foot (4 required)
28	032354	Foot Washer (4 required)
29	032355	Screw (4 required)

Illustration#	Part#	Description
30	032750	Bottom Plate Screw (4 required)
31	037488	Top Handle
32	037489	Bottom Handle
33	037493	Screw (2 top handle - 2 bottom handle)
34	037502	Heating Element (1 top - 1 bottom)
35	037503	Clamp (3 top heating element - 3 bottom heating element)
36	032359 037504	Screw (3 top clamps - 3 bottom clamps) Spring Washer (3 top clamps - 3 bottom clamps)
37	032751	Spring Washer (2 top heating element - 2 bottom heating element)
38	037505	Screw (2 top heating element - 2 bottom heating element)
39	037506	Insulated Sleeve (2 top heating element - 2 bottom heating element)

