

# Installation Operation and Maintenance Instructions

115 Volt  
Commercial Refrigerator  
Refrigerator / Freezer  
Freezer



## UNPACKING YOUR APPLIANCE

### Remove Packaging

Your refrigerator has been packed for shipment with all parts that could be damaged by movement securely fastened. Before using, be sure all packing materials and tape have been removed.

### Important

Keep your carton packaging until your refrigerator has been thoroughly inspected and found to be in good condition. If there is damage, the packaging will be needed as proof of damage in transit.

### Note to Customer

This merchandise was carefully packed and thoroughly inspected before leaving our plant. Responsibility for its safe delivery was assumed by the carrier upon acceptance of the shipment. Claims for loss or damage sustained in transit must be made on the carrier as follows:

- **Exterior Damage:** Make thorough damage notation on your delivery receipt and have driver acknowledge by signature and date. Send a written request asking for an inspection report from carrier. Include the name of the carrier representative and the date the inspection was requested. Retain inspection report and receipt for filing of a claim.
- **Concealed Damage:** This must be reported to carrier within fifteen days. Obtain inspection report from carrier. Retain the inspection report for filing of the claim.

**DO NOT RETURN DAMAGED MERCHANDISE TO THE MANUFACTURER - FILE THE CLAIM WITH THE CARRIER.**

**IMPORTANT  
SAFETY  
INSTRUCTIONS**

WARNING- When using this appliance, always exercise basic safety precautions, including the following:

- This refrigerator must be properly installed in accordance with the installation instructions before it is used.
- Never unplug your unit by pulling on the power cord. Always grip plug firmly and pull straight out from the outlet.
- Repair or replace immediately all electrical service cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion damage along its length or at either the plug or connector end.
- After your unit is in operation, do not touch the cold surfaces, particularly when your hands are damp or wet. Skin may adhere to these extremely cold surfaces.
- Unplug your refrigerator:
  - A) Before making any repairs. NOTE: We strongly recommend any servicing to be performed by a qualified individual.
  - B) Before cleaning.
  - C) Before replacing a burned out light bulb, for units with optional interior light. Turning the temperature control to "O" or "OFF" position does not remove power from the light circuit.

\* Do not operate your product in the presence of explosive fumes.

## INSTALLATION:

### Select Location

The proper location will ensure peak performance of your appliance. Choose a location where the unit will be out of direct sunlight and away from heat sources.

Do not install the unit where the temperature will go below 60°F, because it will not run often enough to maintain proper temperatures.

Do install it on a floor strong enough to support a fully loaded unit.

### Cabinet Clearance

Ventilation is required from the bottom front section of the unit. Keep this area open and clear of any obstructions.

Units with fan cooled condensers can be built in. The adjacent cabinets and countertop can be built around the unit as long as no top trim or countertop is installed lower than the top of the hinge.

### Leveling Legs

(If supplied) Adjustable legs at the front corners of the unit should be set so the unit is firmly positioned on the floor and the front is raised just enough so the door closes easily when opened about halfway.

Turn leveling legs clockwise to raise unit, counterclockwise to lower it.

### Electrical Connection

Check serial plate for correct power supply. Use only electrical power supply as specified on your appliance serial nameplate. **DO NOT USE AN EXTENSION CORD.**

### Grounding Method

This product is factory equipped with a power supply cord that has a three-pronged, grounded plug. It must be plugged into a mating grounding type receptacle in accordance with the National Electrical Code and applicable local codes and ordinances (see Figure 1). If the circuit does not have a grounding type receptacle, it is the responsibility and obligation of the customer to exchange the existing receptacle in accordance with the National Electrical Code and applicable local codes and ordinances. The third ground prong should not, under any circumstances, be cut or removed. All U.L. listed refrigerated products are equipped with this type of plug.




Figure 1

**INTERIOR LIGHT (Optional feature):**

When supplied with an interior light, to replace the light bulb, proceed as follows:

1. Unplug the power cord from the wall receptacle.
2. Open the cabinet door.
3. Unscrew the existing bulb and replace with an equivalent watt, threaded, intermediate base appliance bulb. Do not replace with a bulb higher than the watts of the replaced bulb.
4. Reassemble.

To clean the light assembly disconnect the power cord and wipe the assembly with a mildly damp cloth. Dry the unit completely before connecting the power cord.

**TEMPERATURE CONTROL:**

On a temperature control knob, the bigger numbers indicate colder temperature. initially set the temperature control knob midway between the numbers. After at least 2 hours, adjust the temperature that suits you.

### **DEFROSTING INSTRUCTIONS:**

Never use a scraper or any tool that might scratch or pierce the cooling plate or cooling tube. Follow these steps whenever 1/4 inch or more of frost accumulates:

1. Disconnect the power cord and set the cold control knob to "OFF" position.
2. Remove contents and leave door open.
3. Place pans of hot water on the cooling plate, if you wish, to speed up defrosting.
4. Wipe out the interior and replace contents.
5. Connect power cord to outlet.
6. Set temperature control to desired level.

NOTE: All refrigerator models and the refrigerator compartment of 2 door models automatically defrost their cooling plate during each compressor off cycle. No manual defrosting is required.

### **ENERGY SAVING TIPS:**

Ways to save power, save money, and still enjoy your unit.

1. Reduce door openings.
2. Close the door as soon as you can.
3. Keep the coils on bottom or back of the unit clean.
4. Adjust the temperature control to a warmer setting when practical.
5. Do not put hot commodities in the unit.
6. Keep unit away from heat sources and direct sunlight.

## CARE AND CLEANING:

### Condenser

The condenser tubing under the cabinet for forced air units does not require frequent cleaning; however, satisfactory cooling depends on adequate ventilation over the condenser. Be sure nothing obstructs the required air flow openings in the lower front of the cabinet. At least once or twice a year, brush or vacuum lint and dirt from the condenser for efficient performance by unplugging the power cord from the wall receptacle and unscrewing the grille on the bottom front of the cabinet. Static condenser units with exposed coils on the back of the unit should be inspected periodically and cleaned as required.

### Cabinet

The painted cabinet can be washed with mild soap and water and thoroughly rinsed with clear water. NEVER use abrasive scouring cleaners.

### Interior and Door Gasket

Wash interior compartment with mild soap and water. A mixture of 2 tablespoons baking soda to 1 quart of water may be used. Do NOT use an abrasive cleaner, solvent, polish cleaner or undiluted detergent.

## THINGS TO REMEMBER:

1. Allow 24 hours for your unit to reach a new temperature setting.
2. The motor will start and stop often. It must do this to maintain the temperature you select.
3. Keep your unit reasonably level.
4. Unplug the unit before working on anything with the electrical system.
5. Exercise caution when sweeping, vacuuming, or mopping near the front of the unit. Damage to the grille and / or the light fixtures switch can occur.
6. For all cleaning of the unit, mix 2 tablespoons of baking soda with 1 quart of warm water. Do not use strong cleaners or scouring powder or pads.
7. Keep all flame or sparks away from flammable material storage refrigerators when opening the door to remove or store commodities.
8. Disconnect electrical power before removing F.M.S. refrigerator electrical plug.

## MARVEL COMMERCIAL

---

### TROUBLESHOOTING CHART:

#### Before Calling for Service

Before calling for service, check the troubleshooting table on this page.

This table lists possible problems that you can remedy without difficulty to avoid an unnecessary service call.

PROBLEM	POSSIBLE CAUSES/SOLUTIONS
Odor in cabinet	1. Interior needs cleaning
Noisy operation	1. Cabinet not level
	2. Weak floor
Cabinet vibrates	1. Cabinet not level
	2. Weak floor
Cabinet light not working (optional feature)	1. Bulb burned out
	2. No power at outlet
Appliance will not run	1. Temperature control turned to "OFF"
	2. Power cord not plugged in
	3. No power at electrical outlet
	4. Circuit breaker tripped.
Appliance runs too long	1. Prolonged door openings
	2. Control set too cold
	3. Condenser needs cleaning
Moisture collects inside	1. Too many door openings
	2. Prolonged door openings
	3. Hot, humid weather increases condensation
Moisture collects on outside surface	1. Hot, humid weather increases condensation (as humidity decreases, moisture will disappear)
	2. Control improperly set
Interior too hot/too cold	1. Control improperly set
	2. Faulty thermometer.

#### Help Prevent Tragedies

Each year children die because they climb inside a discarded refrigeration product, get trapped inside and suffocate. Take precautions to prevent such tragedies by removing the door or by taping or chaining it shut before discarding.

**OBTAINING SERVICE:**

**How to Obtain Service**

Your refrigerator/freezer requires little service because the best and most up to date materials, equipment and quality methods are employed throughout the manufacturing process.

If trouble occurs during normal operation, first check the problems in the troubleshooting chart to see if any of these simple steps may correct the problem. If service becomes necessary refer to the warranty enclosed with the owners guide for instructions.

IT IS IMPORTANT THAT YOU SEND IN YOUR WARRANTY RECORD CARD IMMEDIATELY AFTER TAKING DELIVERY OF YOUR REFRIGERATION APPLIANCE.

Every new refrigeration appliance that leaves the factory contains this owners guide. Keep this owners guide in a safe place for convenient reference.

**If You Do Need Service**

If you do need service, contact your dealer or Northland - Marvel. In any correspondence, refer to the model number and serial number of your unit which is located on the upper left hand side of the wall liner. Flammable material storage models have their serial nameplates on the back of the cabinets. You may want to record these numbers in the space below.

For Your Records	
Date of Purchase	
Dealer's Name	
Dealer's Address	
Dealer's City	
Dealer's State	
Dealer's Zip	
Appliance Serial Number	
Model Number	
Date Warranty Card Sent (Must be within 10 Days of Purchase)	

## COMMERCIAL REFRIGERATION PRODUCTS WARRANTY

---

### Marvel Refrigeration (Marvel) Limited Warranty

#### ONE YEAR LIMITED PARTS & LABOR WARRANTY

For one year from the date of original purchase, this warranty covers all parts and labor to repair or replace any part of the product that proves to be defective in materials or workmanship. For products installed and used for normal residential use, material cosmetic defects are included in this warranty, with coverage limited to 60 days from the date of original purchase. All service provided by Marvel under the above warranty must be performed by a Marvel factory authorized servicer, unless otherwise specified by Marvel. Service provided during normal business hours.

#### TWO YEAR LIMITED PARTS & LABOR WARRANTY (MARVEL PROFESSIONAL PRODUCTS)

For two years from the date of original purchase, this warranty covers all parts and labor to repair or replace any part of the product that proves to be defective in materials or workmanship. For products installed and used for normal residential use, material cosmetic defects are included in this warranty, with coverage limited to 60 days from the date of original purchase. All service provided by Marvel under the above warranty must be performed by a Marvel factory authorized servicer, unless otherwise specified by Marvel. Service provided during normal business hours.

#### AVAILABLE THIRD YEAR LIMITED WARRANTY (MARVEL PROFESSIONAL PRODUCTS)

For designated Marvel Professional product, Marvel offers a one year extension of the two year warranty coverage from the date of purchase, free of charge. To take advantage of this third year warranty, you must register your product with Marvel within 60 days from the date of purchase at [marvelrefrigeration.com](http://marvelrefrigeration.com) and provide proof of purchase.

#### LIMITED FIVE YEAR SEALED SYSTEM WARRANTY

For five years from the date of original purchase, Marvel will repair or replace the following parts, labor not included, that prove to be defective in materials or workmanship: compressor, condenser, evaporator, drier, and all connecting tubing. All service provided by Marvel under the above warranty must be performed by a Marvel factory authorized servicer, unless otherwise specified by Marvel. Service provided during normal business hours.

#### WARRANTY TERMS

These warranties apply only to products installed in any one of the fifty states of the United States, the District of Columbia, or the ten provinces of Canada. The warranties do not cover any parts or labor to correct any defect caused by negligence, accident or improper use, maintenance, installation, service, repair, acts of God, fire, flood or other natural disasters. The product must be installed, operated, and maintained in accordance with the Marvel User Guide.

The remedies described above for each warranty are the only ones that Marvel will provide, either under these warranties or under any warranty arising by operation of law. Marvel will not be responsible for any consequential or incidental damages arising from the breach of these warranties or any other warranty, whether express, implied, or statutory. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. These warranties give you specific legal rights, and you may also have other rights which vary from state to state.

Any warranty that may be implied in connection with your purchase or use of the product, including any warranty of merchantability or any warranty fit for a particular purpose is limited to the duration of these warranties, and only extends to five years in duration for the parts described in the section related to the five year limited warranty above. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

- The warranties only apply to the original purchaser and are non-transferable.
- These warranties cover products installed and used for normal residential use only.
- The warranties apply to units operated outside only if designed for outdoor use by model and serial number.
- Replacement water filters, light bulbs, and other consumable parts are not covered by these warranties.
- The start of Marvel's obligation is limited to four years after the shipment date from Marvel.
- In-home instruction on how to use your product is not covered by these warranties.
- Food, beverage, and medicine loss are not covered by these warranties.
- If the product is located in an area where Marvel factory authorized service is not available, you may be responsible for a trip charge or you may be required to bring the product to a Marvel factory authorized service location at your own cost and expense.
- Units purchased after use as floor displays, and/or certified reconditioned units, are covered by the limited one year warranty only and no coverage is provided for cosmetic defects.
- Signal issues related to Wi-Fi connectivity are not covered by these warranties.

For parts and service assistance, or to find Marvel factory authorized service near you, contact Marvel Refrigeration:

[MarvelRefrigeration.com](http://MarvelRefrigeration.com) • [techsupport@MarvelRefrigeration.com](mailto:techsupport@MarvelRefrigeration.com) • +616.754.5601

1260 E. Van Deine St., Greenville, MI 48838

**NOTES:**



[www.marvelrefrigeration.com](http://www.marvelrefrigeration.com)

Marvel Refrigeration  
P.O. Box 400  
1260 E. Van Deirse St.  
Greenville MI  
48838-0400

800.223.3900

41004385 Rev E  
1/14/20

All specifications and product designs subject to change without notice. Such revisions do not entitle the buyer to corresponding changes, improvements, additions, replacements or compensation for previously purchased products.